**Bajaj Majesty 4500 TMCSS**

# Bajaj Majesty 4500 TMCSS 45-Litre Oven Toaster Grill User Manual

Model: Majesty 4500 TMCSS

## 1. Important Safety Instructions

Read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always ensure the appliance is unplugged from the power outlet before cleaning or when not in use.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Supervise children closely when the appliance is in use.
- Avoid touching hot surfaces. Use oven mitts or gloves when handling hot items or parts.
- Do not operate the appliance with a damaged cord or plug, or if it has been dropped or damaged in any way.
- Ensure adequate ventilation around the appliance during operation. Do not place it near walls or under cabinets.
- Do not place paper, cardboard, plastic, or similar materials inside the oven.
- Use only accessories recommended by the manufacturer.
- This appliance is for household use only.

## 2. Product Overview

The Bajaj Majesty 4500 TMCSS is a 45-litre Oven Toaster Grill (OTG) designed for versatile cooking, including baking, grilling, and toasting. It features a durable stainless steel body, a transparent tempered glass door for easy viewing, and a motorized rotisserie function.




Image: Front and side view of the Bajaj Majesty 4500 TMCSS OTG, showing the control panel with temperature, selector, and timer knobs.

### Key Components:

- Temperature Control Knob
- Function Selector Knob (Bake, Grill, Toast, Convection)
- Timer Knob (up to 60 minutes)
- Power Indicator Light
- Transparent Tempered Glass Door
- Stainless Steel Body
- Heating Elements (Top and Bottom)
- Rotisserie Rod and Forks
- Crumb Tray

## 3. Setup

### Unpacking and Initial Placement:

1. Carefully remove the OTG from its packaging. Retain packaging for future transport or storage.
2. Remove all internal packing materials, accessories, and any protective films or stickers from the appliance.
3. Place the OTG on a stable, heat-resistant, and level surface. Ensure there is at least 10-15 cm of clear space on all sides (back, top, and sides) for proper ventilation.
4. Do not place the appliance near flammable materials, curtains, or under wall cabinets.

### Initial Cleaning:

1. Before first use, wipe the interior and exterior surfaces of the oven with a damp cloth.
2. Wash all accessories (grill tray, baking tray, crumb tray, rotisserie attachment, tongs, skewer rods) in warm, soapy water, rinse thoroughly, and dry completely.
3. Plug the appliance into a grounded electrical outlet.

### Included Accessories:

- Cooking Tray / Baking Tray
- Grill and Barbeque Rack
- Crumb Tray
- Rotisserie Attachment (rod and forks)
- Tongs (for rotisserie attachment and trays)
- Skewer Rods (4 pieces)

## 4. Operating Instructions

Familiarize yourself with the control knobs before operation.




Image: Interior view of the OTG, showing the heating elements, grill rack, and the motorized rotisserie rod in place.

### Control Functions:

- **Temperature Control Knob:** Adjusts the desired cooking temperature (e.g., from 100°C to 250°C).
- **Function Selector Knob:** Selects the cooking mode:
  - *Upper Heating:* For grilling and browning.
  - *Lower Heating:* For baking and gentle cooking.
  - *Upper & Lower Heating:* For general baking, roasting, and convection cooking.
  - *Convection Fan:* Activates the convection fan for even heat distribution.
  - *Rotisserie:* Engages the motorized rotisserie for even roasting.
- **Timer Knob:** Sets the cooking duration up to 60 minutes. The oven will automatically turn off when the timer reaches zero. A 'Stay On' function may also be available for continuous operation.

### General Operation:

1. Place food on the appropriate tray or rack. For rotisserie cooking, secure the food onto the rotisserie rod.
2. Close the oven door securely.
3. Turn the Temperature Control Knob to the desired temperature.
4. Turn the Function Selector Knob to the desired cooking mode (e.g., Bake, Grill, Toast, Convection, Rotisserie).

5. Turn the Timer Knob to the desired cooking time. The power indicator light will illuminate, indicating the oven is operating.
6. When cooking is complete, the timer will chime, and the oven will turn off.
7. Carefully remove cooked food using oven mitts or the provided tongs.

## 5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your OTG.

### Before Cleaning:

- Always unplug the appliance from the power outlet.
- Allow the oven and all accessories to cool completely before cleaning.

### Cleaning Procedure:

- **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner. Avoid using steel wool, abrasive pads, or harsh chemicals.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or polishes.
- **Glass Door:** Clean the glass door with a glass cleaner or a damp cloth.
- **Crumb Tray:** Pull out the crumb tray from the bottom of the oven. Empty crumbs and wash the tray in warm, soapy water. Rinse and dry thoroughly before reinserting.
- **Accessories:** Wash all trays, racks, rotisserie parts, and tongs in warm, soapy water. Rinse and dry completely.

### Storage:

Ensure the oven is clean and dry before storing. Store in a cool, dry place.

## 6. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Oven does not turn on. | Not plugged in; power outage; timer not set. | Ensure plug is securely in outlet; check household circuit breaker; set the timer knob. |
| Food not cooking evenly. | Incorrect temperature/function setting; overcrowding oven; uneven food placement. | Verify settings; avoid overcrowding; rotate food or use convection function if available. |
| Excessive smoke during operation. | Food spills or grease buildup; food too close to heating elements. | Clean oven interior and crumb tray thoroughly; ensure food is not touching heating elements. |
| Rotisserie not turning. | Rotisserie not properly engaged; food too heavy or unbalanced. | Ensure rotisserie rod is correctly seated in the motor drive; balance food evenly on the rod. |

If the problem persists after trying these solutions, contact customer support.

## 7. Specifications

| Feature | Detail |
|---|---|
| Brand | Bajaj |
| Model Name | Majesty 4500 TMCSS |
| Colour | Silver |
| Capacity | 45 litres |
| Wattage | 1800 Watts |
| Special Features | Temperature Control, Timer, Convection, Motorized Rotisserie |
| Control Type | Knob |
| Power Source Type | Electric |
| Item Weight | 12.31 Kilograms |
| Material Type | Stainless Steel |
| Finish Type | Steel |
| Door Material Type | Tempered Glass |
| Door Style | Dropdown Door |

## 8. Warranty and Support

### Warranty Information:

This Bajaj Majesty 4500 TMCSS Oven Toaster Grill comes with a**2-year warranty** from the date of purchase. The warranty covers manufacturing defects under normal household use. Please retain your purchase receipt as proof of purchase for warranty claims.

### Customer Support:

For any service, repair, or warranty-related inquiries, please contact your retailer or the manufacturer's authorized service center. Refer to your purchase documentation for specific contact details.

© 2023 Bajaj Appliances. All rights reserved.