ALLIMITY BLAU3D

ALLIMITY BLAU3D Remote Control User Manual

Model: BLAU3D

Compatible with various BLAUPUNKT 3D TV models

Introduction

Welcome to the user manual for your ALLIMITY BLAU3D replacement remote control. This remote is designed to provide seamless control over your compatible BLAUPUNKT 3D TV, offering identical functionality to your original remote without requiring any complex setup. Please read this manual carefully to ensure proper use and longevity of your remote control.

Setup

Battery Installation

The ALLIMITY BLAU3D remote control operates on alkaline batteries. Ensure you have two new batteries ready for installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two new alkaline batteries, ensuring the correct polarity (+ and –) as indicated inside the compartment.
4. Close the battery cover securely.

No programming or pairing is required. The remote is ready for use once batteries are installed.



Image: Front view of the ALLIMITY BLAU3D Remote Control, showing its ergonomic design and button layout.

Operating Instructions

This section details the functions of the buttons on your ALLIMITY BLAU3D remote control.

Button Layout and Functions



Image: Angled view of the ALLIMITY BLAU3D Remote Control, highlighting the various control buttons.

The remote control features a standard layout for easy navigation and control of your television. Below is a list of common buttons and their primary functions:

- **POWER (Red Button)**: Turns the TV on or off.
- **MUTE (Blue Button)**: Mutes or unmutes the TV sound.
- **DTV** / **RADIO** / **USB** / **DVD**: Selects the input source (Digital TV, Radio, USB, DVD).
- **Number Buttons (0-9)**: Directly selects channels or inputs numerical values.
- **TV GUIDE**: Displays the electronic program guide.
- **MENU**: Accesses the TV's main menu.
- **OK**: Confirms selections within menus.
- **Arrow Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **EXIT**: Exits the current menu or screen.
- **SOURCE**: Cycles through available input sources.
- **INFO**: Displays information about the current program or input.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes the channel up or down.
- **P.MODE (Picture Mode)**: Cycles through picture presets.
- **S.MODE (Sound Mode)**: Cycles through sound presets.
- **FAV (Favorite)**: Accesses favorite channels list.
- **ASPECT**: Changes the screen aspect ratio.
- **SLEEP**: Sets a sleep timer for the TV.
- **AUDIO**: Selects audio tracks or languages.
- **SUBTITLE**: Toggles subtitles on/off.
- **DISPLAY**: Displays on-screen information.
- **TEXT** / **DVD MENU** / **TEXT HOLD** / **TEXT ZOOM** Teletext functions and DVD menu navigation.
- **PVR/DVD Control Buttons (Play, Pause, Stop, Fast Forward, Rewind, Next, Previous)**: Controls playback of PVR recordings or DVD content.
- **REC LIST** / **GOTO** / **A-B** / **ANGLE** / **REPEAT**: Advanced playback and recording functions.
- **3D (Yellow Button)**: Activates or deactivates 3D mode (if supported by TV).
- **Color Buttons (Red, Green, Yellow, Blue)**: Context-sensitive functions within menus or applications.

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries. Dispose of used batteries according to local regulations.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding	Dead batteries	Replace batteries with new ones.
Remote not responding	Obstruction between remote and TV	Ensure there is a clear line of sight between the remote's IR emitter and the TV's IR receiver.
Remote not responding	Incorrect TV input selected	Press the SOURCE button to cycle through inputs until the correct one is selected.
Some buttons not working	TV model incompatibility (rare)	Verify your TV model is listed as compatible. While designed for broad compatibility, some specific functions may vary.
Short operating range	Weak batteries	Replace batteries.
Short operating range	Interference	Ensure no strong light sources (like direct sunlight or fluorescent lights) are interfering with the IR signal.

If issues persist after following these steps, please refer to your TV's original manual or contact customer support for further assistance.

Specifications

- **Brand**: ALLIMITY

- **Model**: BLAU3D
- **Connectivity Technology**: Infrared (IR)
- **Compatible Devices**: BLAUPUNKT 3D TV models including 185/189J-GB-4B-HKU-EU, 236/189J-GB-4B-HKDUP-EU, 32/122I-GB-5B-HBKU-UK, 32/1480-GB-11B-EGP-UK, 40/122-6B-5BFHKUP-EU, 50/211I-GB-5B-FHBKUP-EU, and other compatible models as listed in the product description.
- **Battery Type**: Alkaline
- **Maximum Range**: Approximately 10 meters (33 feet)
- **Special Features**: Ergonomic design

Note: Specifications are subject to change without notice.