Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AEG 405539632

AEG 4055396321 Dough Hook Instruction Manual

Model: 405539632 | Brand: AEG

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your AEG 4055396321 Dough Hook. This accessory is designed as a replacement or spare part for AEG KM3300 and KM3200 series kitchen machines, specifically for kneading various types of dough.

Please read this manual thoroughly before using the dough hook to ensure safe and efficient operation and to prolong the life of your product.

2. Safety Information

Always observe the following safety precautions when handling and using the dough hook:

- **Unplug the Kitchen Machine:** Always ensure the kitchen machine is unplugged from the power outlet before attaching, detaching, or cleaning the dough hook.
- **Proper Attachment:** Verify that the dough hook is securely and correctly attached to the machine's drive shaft before operation.
- **Keep Hands Clear:** Never insert hands or utensils into the mixing bowl while the kitchen machine is operating.
- **Intended Use:** Use the dough hook only for its intended purpose of kneading dough. Do not use it for other tasks or with incompatible machines.
- **Children and Pets:** Keep the dough hook and the kitchen machine out of reach of children and pets.

3. Package Contents

Your package should contain the following item:

- 1 x AEG 4055396321 Dough Hook

4. Setup

Follow these steps to attach the dough hook to your AEG KM3300 or KM3200 kitchen machine:

1. Ensure the kitchen machine is unplugged from the power outlet.
2. Lift the motor head of your kitchen machine (if applicable) or tilt it back to access the attachment hub.
3. Align the top of the dough hook with the drive shaft in the attachment hub.
4. Push the dough hook upwards onto the shaft and twist slightly until it locks securely into place. Ensure it does not wobble.
5. Lower the motor head or return it to the operating position.



Image: The AEG 4055396321 Dough Hook. This black, curved attachment features a robust design with a circular top for secure fitting into compatible kitchen machines, essential for effective dough kneading.

For detailed instructions on operating your specific kitchen machine model, please refer to the main instruction manual provided with your AEG KM3300 or KM3200 appliance.

5. Operating Instructions

The AEG 4055396321 Dough Hook is specifically designed for kneading various types of dough, from light batters to heavy bread doughs.

1. After securely attaching the dough hook (as per Section 4), add your ingredients to the mixing bowl.
2. Ensure the bowl is properly seated and locked into the kitchen machine base.
3. Plug in the kitchen machine and select the appropriate speed setting for kneading. Start at a low speed to combine ingredients, then gradually increase as needed.
4. Allow the machine to knead the dough for the recommended time according to your recipe.
5. Once kneading is complete, switch off the machine and unplug it before removing the dough hook and bowl.

Always refer to your kitchen machine's main manual for specific speed recommendations and operational guidelines for different dough types.

6. Maintenance and Cleaning

Proper care will ensure the longevity and performance of your dough hook.

Cleaning

- **Hand Wash Only:** To preserve the coating and finish of the dough hook, it is strongly recommended to wash it by hand using warm, soapy water.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- **Rinse Thoroughly:** Rinse the dough hook thoroughly under running water to remove all soap residue.
- **Dry Immediately:** Dry the dough hook completely with a soft cloth immediately after washing to prevent water spots or corrosion.

Storage

Store the clean and dry dough hook in a dry place, away from direct sunlight and extreme temperatures, preferably with your kitchen machine accessories.

7. Troubleshooting

If you encounter issues with your dough hook, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Dough hook does not fit the machine.	Incorrect model compatibility.	Ensure your kitchen machine is an AEG KM3300 or KM3200 model.
Dough hook coating is peeling or chipping.	Dishwasher use or abrasive cleaning.	Always hand wash the dough hook. Avoid dishwashers and abrasive cleaners.
Dough is not kneading effectively.	Hook not properly attached; incorrect speed; dough consistency.	Re-attach the hook securely. Refer to your kitchen machine manual for optimal speed settings. Adjust dough consistency if too stiff or too wet.

8. Specifications

Key specifications for the AEG 4055396321 Dough Hook:

Feature	Detail
Brand	AEG
Model Number	405539632
Compatible Kitchen Machines	AEG KM3300, KM3200 series
Package Dimensions	15.4 x 13.2 x 7.9 cm
Item Weight	100 Grams
ASIN	B08MRZTRFH
First Available Date	October 18, 2020

9. Warranty and Support

For information regarding warranty coverage for your AEG 4055396321 Dough Hook, please refer to the warranty documentation provided with your original kitchen machine or contact the retailer from whom you purchased this accessory.

For technical support or further inquiries, please visit the official AEG website or contact their customer service department. Contact details can typically be found on the AEG website or in the main kitchen machine manual.

© 2024 AEG. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08MRZTRFH

More documents and user manuals: **https://manuals.plus/**