Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Warner Home Video B08MSFDQ6F

The Lego Movie / The Lego Movie 2: The Second Part DVD Instruction Manual

Model: B08MSFDQ6F

INTRODUCTION

This instruction manual provides essential information for the proper use and care of your "The Lego Movie / The Lego Movie 2: The Second Part" DVD. This single DVD disc contains both feature films, offering a comprehensive viewing experience. Please read this manual thoroughly to ensure optimal enjoyment and longevity of your product.



This image displays the front cover of the DVD, showcasing characters from both 'The Lego Movie' and 'The Lego Movie 2: The Second Part'. The top half features Emmet from the first movie, while the bottom half shows Emmet, Lucy, Batman, and other characters from the second movie.

Setup

1. **Unpack the DVD:** Carefully remove the DVD disc from its packaging. Hold the disc by its edges to avoid touching the playback surface.
2. **Prepare Your DVD Player:** Ensure your DVD player is connected to your television or display device and powered on.
3. **Insert the Disc:** Open the disc tray of your DVD player. Place the DVD disc into the tray with the label side facing up. Gently close the disc tray.
4. **Select Input:** On your television, select the correct input source (e.g., HDMI 1, AV) that corresponds to your DVD player connection.

Operating Instructions

Once the DVD is inserted and your player is ready, the disc should automatically load and display a main menu. Use your DVD player's remote control to navigate the menu options.

- **Main Menu:** The main menu will typically present options to play "The Lego Movie" or "The Lego Movie 2: The Second

Part".

- **Play Movie:** Select "Play" or "Start Movie" to begin playback of your chosen film.
- **Scene Selection:** Use the "Scene Selection" or "Chapters" option to jump to specific parts of the movie.
- **Audio/Subtitles:** If available, use the "Audio" or "Subtitles" options to change language tracks or enable/disable subtitles. Refer to your DVD player's manual for specific button functions.
- **Navigation:** Use the arrow keys on your remote to move between menu items and the "Enter" or "OK" button to make a selection.

Maintenance and Care

Proper care will extend the life of your DVD and ensure consistent playback quality.

- **Handling:** Always hold the DVD by its outer edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If the disc becomes dirty or smudged, gently wipe it with a soft, lint-free cloth. Wipe from the center of the disc outwards in a straight line, not in a circular motion. Do not use abrasive cleaners or solvents.
- **Storage:** Store the DVD in its original case, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not place the disc on rough surfaces or expose it to objects that could scratch it.

Troubleshooting

If you encounter issues during playback, consider the following common solutions:

- **Disc Not Playing/Loading:**
  - Ensure the disc is inserted correctly with the label side up.
  - Check if the disc is clean and free of smudges or scratches. Clean if necessary.
  - Verify your DVD player is functioning correctly by trying another known-good DVD.
  - Ensure your TV is on the correct input channel.
- **Skipping or Freezing:**
  - Clean the disc thoroughly as described in the Maintenance section.
  - Inspect the disc for deep scratches or damage. Severely damaged discs may not play correctly.
  - Ensure your DVD player's lens is clean. Refer to your player's manual for cleaning instructions.
- **No Audio/Video:**
  - Check all cable connections between your DVD player and TV.
  - Ensure your TV's volume is not muted and is turned up.
  - Verify the correct audio track is selected in the DVD menu (if applicable).

Specifications

Title	The Lego Movie / The Lego Movie 2: The Second Part
Format	DVD (NTSC)
Number of Discs	1

Run Time	107 minutes
MPAA Rating	PG (Parental Guidance Suggested)
Release Date	July 28, 2020
Studio	Warner Home Video
ASIN	B08MSFDQ6F

Warranty and Support

This product is distributed by Warner Home Video. For any manufacturing defects or issues not resolved by the troubleshooting steps, please contact the retailer where the DVD was purchased or refer to the contact information provided on the DVD packaging for Warner Home Video customer support. Please retain your proof of purchase for any warranty claims.

© 2024 Warner Home Video. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08MSFDQ6F

More documents and user manuals: **https://manuals.plus/**