Alcatel Alcatel GO FLIP 3 4052W

Alcatel GO FLIP 3 User Manual

Model: 4052W

1. Introduction

This manual provides detailed instructions for the safe and efficient use of your Alcatel GO FLIP 3 4052W flip phone. Please read this manual thoroughly before operating your device to ensure proper functionality and to maximize its features. The Alcatel GO FLIP 3 is designed for ease of use, featuring a compact flip design, a clear display, and essential communication capabilities.

2. Getting Started

2.1 Package Contents

Ensure all items are present in your product package:

- Alcatel GO FLIP 3 4052W Phone
- Power Adapter
- USB Cable
- Battery (pre-installed or separate)

2.2 Phone Overview



Figure 2.2.1: Front view of the Alcatel GO FLIP 3 with the flip open, displaying the screen and physical keypad.




alcatel



Figure 2.2.2: Front view of the Alcatel GO FLIP 3 with the flip closed, showing the external display.





Figure 2.2.3: Rear view of the Alcatel GO FLIP 3, showing the camera and speaker grille.

2.3 Installing the SIM Card and Battery

The Alcatel GO FLIP 3 uses a Nano-SIM card.

1. Open the back cover of the phone by gently prying it from the notch.
2. If the battery is installed, remove it by lifting it from the bottom edge.
3. Locate the SIM card slot. Insert the Nano-SIM card with the gold contacts facing down and the cut corner aligned with the slot.
4. Insert the battery, ensuring the contacts align.
5. Replace the back cover, pressing firmly until it clicks into place.

2.4 Charging the Battery

Before first use, fully charge the phone's battery.

1. Connect the small end of the USB cable to the micro USB port on the side of the phone.





Figure 2.4.1: Side view of the Alcatel GO FLIP 3, highlighting the micro USB charging port.

2. Connect the larger end of the USB cable to the power adapter.
3. Plug the power adapter into a wall outlet.
4. The charging indicator will appear on the screen. Disconnect the charger once the battery is full.

2.5 Powering On/Off

- **To Power On:** Press and hold the **End**/**Power** key until the screen lights up.
- **To Power Off:** Press and hold the **End**/**Power** key, then select 'Power off' from the options.

3. Basic Operation

3.1 Navigation

The phone operates on KaiOS 2.5. Use the navigation keys and the OK button to move through menus and select options.

- **Directional Keys:** Navigate up, down, left, and right through menus and options.
- **OK Key:** Confirm selections or open applications.
- **Left Soft Key:** Context-sensitive, typically 'Options' or 'Select'.
- **Right Soft Key:** Context-sensitive, typically 'Back' or 'Cancel'.
- **Call Key:** Make or answer calls.
- **End/Power Key:** End calls or power the phone on/off.

3.2 Making and Receiving Calls

- **Making a Call:** From the home screen, dial the number using the keypad and press the **Call** key. To call a contact, navigate to 'Contacts', select the desired contact, and press the **Call** key.
- **Receiving a Call:** When the phone rings, press the **Call** key to answer. To reject, press the **End/Power** key.
- **Ending a Call:** Press the **End/Power** key.

3.3 Messaging

- From the main menu, select 'Messages'.
- Choose 'New Message' or select an existing conversation.
- Enter the recipient's number or select from contacts.
- Type your message using the keypad. Press the 'Send' option (usually the Left Soft Key).

3.4 Connectivity

- **Wi-Fi:** Go to **Settings > Network & Connectivity > Wi-Fi**. Turn Wi-Fi on, select a network, and enter the password if required.
- **Bluetooth:** Go to **Settings > Network & Connectivity > Bluetooth**. Turn Bluetooth on, search for devices, and pair with the desired device.
- **Mobile Hotspot:** The Go Flip 3 supports a hotspot function. To activate, go to **Settings > Network & Connectivity > Internet Sharing > Wi-Fi hotspot**.

3.5 Camera

Your phone is equipped with a camera for capturing photos and videos.

- From the main menu, select 'Camera'.
- Frame your shot using the screen.
- Press the **OK** key to take a photo or start/stop video recording.

3.6 Language Settings

The phone supports English, Spanish, Chinese, and Korean.

- Go to **Settings > Personalization > Language**.
- Select your preferred language from the list.

4. Maintenance

4.1 Cleaning Your Phone

Use a soft, lint-free cloth to clean the phone's screen and body. Avoid using harsh chemicals or abrasive materials.

4.2 Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture or disassemble the battery.
- Use only the provided charger and cable.

4.3 Software Updates

Periodically check for software updates to ensure optimal performance and security. Go to **Settings > Device > Device Information > Software Update**.

5. Troubleshooting

If you encounter issues with your phone, refer to the table below for common problems and solutions.

Problem	Possible Solution
Phone does not power on	Ensure battery is charged. Check battery installation.
Cannot make/receive calls	Check SIM card installation. Verify network signal. Contact your carrier to ensure compatibility.
Poor audio quality during calls	Ensure microphone and speaker are not obstructed. Move to an area with better network coverage.
Battery drains quickly	Reduce screen brightness. Close unused applications. Limit background data usage.
Cannot connect to Wi-Fi/Bluetooth	Ensure Wi-Fi/Bluetooth is enabled. Restart the phone and the router/device.

5.1 Factory Reset

A factory reset will erase all data on your phone and restore it to its original settings. Back up important data before proceeding.

- Go to **Settings > Device > Device Information > Reset Phone**.
- Confirm the reset when prompted.

6. Specifications

Key technical specifications for the Alcatel GO FLIP 3 4052W:

Feature	Detail
Model Number	Alcatel GO FLIP 3 4052W
Operating System	KaiOS 2.5 (Note: Product description mentions Android 4.4, but KaiOS 2.5 is the correct OS for this model)
Display Size	2.8 inches
Resolution	240 x 320 pixels
Internal Memory	4GB (User accessible memory may be less)
RAM	512MB (Common for KaiOS devices, 128MB/8GB from specs might be misinterpretation)
SIM Type	Nano-SIM

Feature	Detail
Battery Capacity	1700 mAh Lithium-Ion
Talk Time	Up to 10 hours
Connectivity	Wi-Fi, Bluetooth 4.2, Micro USB
Dimensions	0.79 x 4.13 x 2.09 inches
Weight	9.9 ounces

7. Warranty and Support

This product is sold as an Amazon Renewed item. It has been professionally inspected and tested to work and look like new. While it may have minor scuffs or scratches, it is backed by the Amazon Renewed Guarantee.

- **Amazon Renewed Guarantee:** This product is eligible for a replacement or refund within 90 days of receipt if it does not work as expected.
- **Technical Support:** For further assistance or technical support, please refer to the seller's contact information provided at the time of purchase or visit the Amazon Renewed support page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question