Simac 6193

Simac 6193 Steam Iron User Manual

Model: 6193

Introduction

Thank you for choosing the Simac 6193 Steam Iron. This appliance is designed to make your ironing tasks efficient and effective. With its 2400W power, ceramic soleplate, and ECO function, it provides excellent performance while being mindful of energy consumption. Please read this manual carefully before first use to ensure safe operation and optimal results. Keep this manual for future reference.



Image: The Simac 6193 Steam Iron positioned next to neatly folded laundry, illustrating its purpose in garment care.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury. Read all instructions before using this iron.

- Always ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not leave the iron unattended while it is connected to the mains supply.
- Unplug the iron from the power outlet before filling with water, emptying, or cleaning, and after each use.
- Keep the iron and its cord out of reach of children.
- Do not immerse the iron, power cord, or plug in water or other liquids.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Use the iron only for its intended purpose.
- The soleplate of the iron can become extremely hot and cause burns. Avoid direct contact.
- Always place the iron on a stable, heat-resistant surface when resting.

Product Overview

Familiarize yourself with the components of your Simac 6193 Steam Iron.



Image: A detailed view of the Simac 6193 Steam Iron, highlighting its ergonomic design and green accents.





Image: An overhead view of the iron, showing the temperature dial, steam control, spray button, and self-clean function.

1. **Water Inlet Cover:** For filling the water tank.
2. **Spray Nozzle:** Emits a fine mist of water.
3. **Steam Control Slider:** Adjusts steam output or selects dry ironing.
4. **Spray Button:** Activates the spray function.
5. **Steam Shot Button:** Provides an extra burst of steam.
6. **Temperature Control Dial:** Selects the desired ironing temperature.
7. **Water Tank:** Transparent reservoir for water.
8. **Indicator Light:** Illuminates when the iron is heating and turns off when the set temperature is reached.
9. **Ceramic Soleplate:** The heating surface that glides over fabrics.
10. **Power Cord:** Connects the iron to the electrical outlet.

Setup

Before First Use

- Remove any labels or protective film from the soleplate.
- It is normal for a slight odor or smoke to occur during the first few minutes of use as manufacturing residues burn off. This will disappear after a short time.
- For optimal performance, iron an old piece of fabric first to ensure the soleplate is clean.

Filling the Water Tank



Image: A hand carefully pouring water into the iron's water tank, demonstrating the refilling process.

1. Ensure the iron is unplugged from the power outlet.
2. Set the steam control slider to the 'Dry Ironing' position (no steam).
3. Open the water inlet cover.
4. Using a measuring cup, carefully pour tap water into the water tank up to the 'MAX' fill line. Do not overfill.
5. Close the water inlet cover securely.

Operating Instructions

Temperature Selection

1. Check the fabric care label on your garment.
2. Plug the iron into a suitable power outlet.
3. Turn the temperature control dial to the desired setting. The indicator light will illuminate.
4. Wait for the indicator light to turn off, indicating the iron has reached the selected temperature.

Dry Ironing

For dry ironing, ensure the water tank is empty or the steam control slider is set to the 'Dry Ironing' position. Select the appropriate temperature for your fabric and wait for the indicator light to turn off before ironing.

Steam Ironing



Image: The Simac 6193 Steam Iron actively releasing steam, demonstrating its powerful steam function.

1. Fill the water tank as described in the 'Setup' section.
2. Set the temperature control dial to the steam zone (usually indicated by three dots or 'MAX' on the dial).

Steam ironing is only effective at higher temperatures.

3. Wait for the indicator light to turn off.
4. Adjust the steam control slider to the desired steam output.
5. Begin ironing.

Steam Shot Function

Press the Steam Shot button for an extra burst of steam to remove stubborn creases. This function is most effective when the iron is at a high temperature. Allow a few seconds between bursts for the steam to regenerate.

Spray Function

Press the Spray button to emit a fine mist of water onto the fabric. This helps to dampen dry areas and make ironing easier. This function can be used with or without steam.

ECO Function

The ECO function is designed to optimize steam output and temperature for efficient ironing while reducing energy and water consumption. To activate, ensure the temperature dial is set to the ECO position (if available) or select a lower steam setting. This function is suitable for most common fabrics and helps in environmental conservation.



Image: The Simac 6193 Steam Iron smoothly gliding over a white shirt, demonstrating its ironing capability.

Maintenance

After Each Use

1. Unplug the iron and allow it to cool completely.
2. Empty any remaining water from the tank.
3. Store the iron upright on its heel rest.

Cleaning the Soleplate

To clean the soleplate, wipe it with a damp cloth and a non-abrasive cleaner after the iron has cooled down. Do not use abrasive scouring pads or metal cleaners as these can damage the ceramic coating.





Image: A close-up view of the iron's ceramic soleplate, showing its smooth surface and steam holes.

Self-Clean Function

The Simac 6193 iron is equipped with a self-clean function to remove mineral deposits and impurities from the steam chamber. It is recommended to use this function monthly or more frequently if you live in a hard water area.

1. Fill the water tank to the 'MAX' line.
2. Plug in the iron and set the temperature control dial to 'MAX'.
3. Wait for the indicator light to turn off.
4. Unplug the iron.
5. Hold the iron horizontally over a sink.
6. Press and hold the 'CLEAN' button (located near the steam control). Hot water and steam will be expelled from the soleplate, carrying impurities.
7. Gently shake the iron back and forth until the water tank is empty.
8. Release the 'CLEAN' button.
9. Allow the iron to cool completely before storing.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature dial set to 'OFF' or too low.	Check power connection; try another outlet; set temperature dial to desired heat.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to 'Dry Ironing'; mineral deposits.	Fill water tank; set temperature to steam zone; adjust steam control; perform self-clean.

Problem	Possible Cause	Solution
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled; iron left horizontal when hot.	Increase temperature to steam zone; do not overfill water tank; store iron upright.
Soleplate is dirty.	Starch or fabric residue.	Clean soleplate with a damp cloth after cooling.

Specifications

Feature	Detail
Brand	Simac
Model Number	6193 (00S619300SIIT)
Power	2400 Watts
Voltage	240 Volts
Soleplate Material	Ceramic
Water Tank Capacity	350 ml (approximate, based on product description)
Special Features	ECO Function, Spray Button, Steam Shot, Self-Clean
Color	White/Green
Item Weight	1.49 Kilograms
Package Dimensions	31.5 x 16.7 x 13.7 cm

Warranty and Support

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or contact Simac customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

© 2023 Simac. All rights reserved.