Bajaj ICX-130

Bajaj ICX 130 Push Button Induction Cooktop User Manual

Model: ICX-130

1. Important Safety Instructions

Please read all instructions carefully before using the Bajaj ICX 130 Induction Cooktop. Keep this manual for future reference.

- **Electrical Safety:** Ensure the power supply matches the cooktop's requirements (230 Volts, 1400 Watts). Do not use with damaged cords or plugs. Avoid overloading electrical outlets.
- **Placement:** Place the cooktop on a stable, flat, heat-resistant surface. Ensure adequate ventilation around the unit. Do not place near flammable materials or heat sources.
- **Cookware:** Use only induction-compatible cookware (magnetic base). Non-compatible cookware will not heat.
- **Hot Surface:** The glass surface may remain hot after cooking. Avoid touching it immediately after use.
- **Children and Pets:** Keep children and pets away from the cooktop during operation and while it is cooling down.
- **Cleaning:** Always unplug the cooktop before cleaning. Do not immerse the unit in water or any other liquid.
- **Ventilation:** Do not block the ventilation openings of the cooktop.
- **Medical Implants:** Individuals with pacemakers or similar medical implants should consult their doctor before using an induction cooktop.

2. Product Overview

The Bajaj ICX 130 is a compact and efficient push-button induction cooktop designed for modern kitchens. It features a sleek glass worktop and intuitive controls for various cooking needs.



Image 2.1: Bajaj ICX 130 Push Button Induction Cooktop (Black)

This image displays the Bajaj ICX 130 Induction Cooktop. It features a black glass surface with a central induction coil marking and a control panel at the bottom. The control panel includes various push buttons for different cooking functions and power adjustments, along with a digital display.

Key Features:

- **Type:** Induction Cooktop

- **Power Consumption:** 1300 W
- **Controls:** Push Button
- **Worktop Material:** Glass
- **Color:** Black

3. Setup

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging materials for future transport or storage.
2. **Placement:** Place the cooktop on a dry, stable, and level surface. Ensure there is at least 10-15 cm of clear space around all sides for proper ventilation. Do not place it on a metal surface.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet that meets the specified voltage and wattage requirements (230V, 1400W).
4. **Initial Cleaning:** Before first use, wipe the glass surface with a soft, damp cloth.

4. Operating Instructions

The Bajaj ICX 130 Induction Cooktop is designed for ease of use with its intuitive push-button controls.

4.1. Compatible Cookware

For induction cooking, use cookware made of magnetic materials such as cast iron, enameled iron, stainless steel with a magnetic base, or flat-bottomed pots/pans with a diameter of 12-26 cm. Non-magnetic materials like glass, ceramic, aluminum, or copper will not work unless they have an induction-compatible base.

4.2. Basic Operation

1. **Power On:** Place an induction-compatible pot or pan with food on the center of the cooktop. Plug the cooktop into the power outlet. Press the "ON/OFF" button to turn on the unit. The display will light up.
2. **Select Cooking Mode:** Choose a desired cooking function by pressing the corresponding push button (e.g., "Curry," "Fry," "Milk," "Dosa," "Roti," "Soup," "Slow Cook"). Each mode has a preset power level and time.
3. **Adjust Power/Temperature:** If available for the selected mode, use the "+" and "-" buttons to adjust the power level or temperature.
4. **Set Timer:** Some modes may allow timer adjustment. Use the timer button and "+"/"-" to set the desired cooking duration.
5. **Power Off:** After cooking, press the "ON/OFF" button to turn off the cooktop. Unplug the unit from the power outlet when not in use.

4.3. Product Features Video

Your browser does not support the video tag.

Video 4.1: Overview of Bajaj ICX 130 Induction Cooktop features.

This video provides a brief visual overview of the Bajaj ICX 130 Push Button Induction Cooktop, highlighting its design, key specifications such as type (Induction Cooktop), power consumption (1300 W), push-button controls, glass worktop material, and black color. It demonstrates the product's appearance and basic attributes.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction cooktop.

- **Before Cleaning:** Always unplug the cooktop from the power outlet and allow it to cool completely before cleaning.
- **Glass Surface:** Wipe the glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic hob cleaner. Rinse with a clean, damp cloth and dry thoroughly.
- **Control Panel:** Wipe the control panel with a soft, damp cloth. Avoid excessive moisture.
- **Ventilation Openings:** Ensure the ventilation openings are free from dust and debris. Use a soft brush or vacuum cleaner to gently clear them.
- **Do Not Use:** Abrasive cleaners, scouring pads, harsh chemicals, or steam cleaners, as these can damage the surface.

6. Troubleshooting

If you encounter issues with your Bajaj ICX 130 Induction Cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; power cord not plugged in; power outage.	Check if the power cord is securely plugged in. Verify the power outlet is working. Check your home's circuit breaker.
Cookware is not heating.	Non-induction compatible cookware; cookware too small/large; no cookware detected.	Use induction-compatible cookware. Ensure the cookware base covers the induction zone adequately. Place the cookware centrally.
Display shows an error code.	Specific internal error; overheating.	Refer to the specific error code in a more detailed manual (if available) or contact customer support. Turn off and unplug the unit, let it cool, then restart.
Unusual noise during operation.	Normal fan operation; resonance from cookware.	A low humming sound from the cooling fan is normal. Some cookware may produce a slight buzzing sound due to vibration; this is not a fault.

If the problem persists after trying these solutions, please contact Bajaj customer support.

7. Specifications

Feature	Detail
Brand	Bajaj
Model Number	ICX-130
Type	Induction Cooktop
Heating Elements	1
Color	Black

Feature	Detail
Power Source	Corded Electric
Fuel Type	Electric
Special Features	Electric
Burner Type	Induction
Control Type	Push Button
Installation Type	Countertop
Voltage	230 Volts
Wattage	1400 Watts
Heater Surface Material	Glass
Material Type	Glass
Item Dimensions (D x W x H)	23D x 23W x 5H Centimeters
Item Weight	2.4 Kilograms

8. Warranty and Support

For warranty information, service requests, or technical support, please refer to the warranty card included with your product or visit the official Bajaj website. Keep your purchase receipt as proof of purchase.
Included Components: Instruction manual (this document).

© 2023 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question