GCC B12SW

GCC White Shaker 12 Inch Kitchen Base Cabinet Instruction Manual

Model: B12SW

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your GCC White Shaker 12 Inch Kitchen Base Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

WARNING: Potential pinch hazard when using drawers. Follow assembly instructions carefully to avoid injury.

Included Components

Before assembly, ensure all parts are present:

- Shaker style door
- Drawer front
- Solid wood face frame (3/4 inch thick)
- Drawer box with soft-close, full extension drawer glides
- Assembly instructions (this document)
- Cabinet panels (sides, back, bottom, top supports)
- Shelf
- Hardware (screws, cam locks, dowels, hinges, drawer slides, handles - implied)



Image: The GCC White Shaker 12 Inch Kitchen Base Cabinet, shown with its door open revealing an interior shelf and a partially open drawer above. The cabinet features a white finish and shaker style design.

Assembly Instructions

Your GCC White Shaker 12 Inch Kitchen Base Cabinet is designed for ready-to-assemble convenience. Follow these steps carefully:

1. **Prepare Workspace:** Clear a spacious, clean, and well-lit area for assembly. Lay out all components and hardware.
2. **Assemble Cabinet Box:** Connect the side panels, back panel, and bottom panel using the provided hardware (e.g., cam locks, dowels, screws). Ensure all connections are secure and square.
3. **Attach Face Frame:** Secure the 3/4 inch thick solid wood face frame to the front of the assembled cabinet box.
4. **Install Drawer Glides:** Mount the full extension drawer glides to the interior sides of the cabinet box according to the pre-drilled holes.
5. **Assemble Drawer Box:** Construct the solid wood dovetail drawer box. Ensure all joints are tight.

6. **Attach Drawer Front:** Secure the shaker style drawer front to the assembled drawer box.
7. **Insert Drawer Assembly:** Carefully slide the assembled drawer box with its front onto the installed drawer glides. Test for smooth, soft-close operation.
8. **Install Door Hinges:** Attach the hinges to the shaker style door and then mount the door to the cabinet face frame. Adjust hinges for proper door alignment and soft-close function.
9. **Install Shelf:** Place the adjustable shelf inside the cabinet at your desired height using the shelf pins.
10. **Final Checks:** Verify all screws are tightened, and all components are securely in place.

For detailed diagrams and specific hardware instructions, refer to the printed assembly guide included in your packaging.

Operating Instructions

Drawer Operation

The drawer features soft-close, full extension glides. To open, gently pull the drawer front. To close, push the drawer until the soft-close mechanism engages, allowing it to close smoothly and quietly. Avoid forcing the drawer.

Door Operation

The cabinet door is equipped with soft-close hinges. Open the door by pulling the handle (if installed). Close by gently pushing the door until the soft-close mechanism engages.

Maintenance and Care

Cleaning

Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals, abrasive pads, or excessive moisture, which can damage the finish.

General Care

Regularly check all hardware connections (screws, hinges, drawer glides) and tighten if necessary. Avoid placing excessively heavy items on shelves or in drawers.
Product Care Instructions: Hand Wash (implies gentle cleaning for cabinet surfaces).

Troubleshooting

Drawer Not Closing Smoothly

- Check for obstructions in the drawer glides.
- Ensure the drawer glides are properly aligned and securely fastened.
- Verify the drawer box is assembled correctly and not warped.

Door Misalignment

- Adjust the hinges using a screwdriver. Most cabinet hinges allow for vertical, horizontal, and depth adjustments.
- Ensure the cabinet box is level and square.

Loose Hardware

- Periodically inspect and tighten all screws and fasteners. Do not overtighten.

Specifications

Feature	Detail
Brand	GCC
Model Number	B12SW
Dimensions (D x W x H)	24"D x 12"W x 34.5"H
Color	White
Material	Engineered Wood, Wood
Door Style	Shaker
Drawer Glides	Soft-close, Full Extension
Drawer Construction	Solid Wood Dovetail
Face Frame	3/4 inch Solid Wood
Number of Drawers	1
Number of Shelves	1
Installation Type	Freestanding
Mounting Type	Floor Mount
UPC	619660007085

Warranty and Support

For warranty information or technical support, please contact GCC customer service. Refer to your purchase documentation for specific warranty terms and contact details.
Visit the GCC Brand Store on Amazon

© 2023 GCC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question