Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine Replacement Remote Control for Haier TVs

Instruction Manual for JustFine Replacement Remote Control for Haier LED HDTV TVs

Compatible with Haier LE24F33800, 39D3005, LE46H3280A, 32E2000, 32D3005F, 24D3000A, 32E3000B, LE39M600M80, 42D3500, LE50H32800A, 40E3500A, 55E3500 models.

1. Introduction

This document provides instructions for the JustFine Replacement Remote Control, designed for use with various Haier LED HDTV television models. This remote control is pre-programmed and does not require any additional setup or coding to operate with compatible Haier TVs. Simply insert batteries, and it is ready for use.

Compatible Haier TV Models:

- LE24F33800
- 39D3005
- LE46H3280A
- 32E2000
- 32D3005F
- 24D3000A
- 32E3000B
- LE39M600M80
- 42D3500
- LE50H32800A
- 40E3500A
- 55E3500

2. Setup: Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 1: Back view of the remote control, illustrating the battery compartment.

After battery installation, the remote control is ready for immediate use with your compatible Haier TV.

3. Operating Instructions

This remote control provides full functionality for your compatible Haier LED HDTV. Below is a general overview of common buttons and their functions. Refer to your TV's original manual for specific features.



Image 2: Front view of the remote control, displaying all function buttons.

Key Functions:

- **Power (●)**: Turns the TV on or off.
- **INPUT**: Selects the input source (e.g., HDMI, AV, USB).
- **Number Buttons (0-9)**: Directly select TV channels.
- **USB**: Accesses media from a connected USB device.
- **CC (Closed Caption)**: Toggles closed captions on or off.
- **VOL (+/-)**: Adjusts the volume level.
- **CH (▲/▼)**: Changes TV channels up or down.
- **MUTE**: Mutes or unmutes the TV audio.
- **MENU**: Opens the TV's main menu.
- **BACK**: Returns to the previous menu or screen.

- **EXIT**: Exits the current menu or function.
- **DISPLAY**: Shows current channel information or TV status.
- **SAP (Secondary Audio Program)**: Selects alternative audio tracks.
- **SLEEP**: Sets the sleep timer.
- **WIDE**: Adjusts the screen aspect ratio.
- **AUDIO**: Selects audio modes.
- **PICTURE**: Accesses picture settings.
- **Navigation Buttons (▲ ▼ ◄ ►) & OK**: Navigate through menus and confirm selections.
- **CH.LIST**: Displays the channel list.
- **FAVORITE**: Accesses favorite channels.
- **Color Buttons (Red, Green, Yellow, Blue)**: Functionality varies by TV model and context, often used for interactive features or specific menu options.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward)**: Controls media playback from USB or other sources.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning**: Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Store in a cool, dry place away from direct sunlight.
- **Avoid Damage**: Do not drop the remote control, expose it to extreme temperatures, or immerse it in liquids.

5. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding**:
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Point the remote directly at the TV's infrared sensor. Ensure there are no obstructions between the remote and the TV.
  - Check if the TV's power is on.
- **Limited Range**:
  - Ensure batteries are fresh.
  - Remove any objects blocking the line of sight between the remote and the TV.
  - Avoid strong light sources (e.g., direct sunlight, bright fluorescent lights) that might interfere with the infrared signal.
- **Specific Buttons Not Working**:
  - This remote is pre-programmed for Haier TVs. Ensure your TV model is listed as compatible.

- Clean the remote control, especially around the buttons, to ensure no debris is preventing contact.

If problems persist after trying these steps, please contact customer support.

6. Specifications

Feature	Detail
Brand	JustFine
Compatible Devices	Haier LED HDTV Televisions (various models)
Connectivity Technology	Infrared
Max Number of Supported Devices	1 (one television)
Special Feature	Ergonomic design
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.65 ounces

7. Warranty and Support

This product is sold with a money-back guarantee and hassle-free return policy. A 30-day quality warranty is provided from the date of purchase.
For any problems, questions, or support needs, please contact the seller directly via email. Please refer to your purchase documentation for specific contact information.

© 2025 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08NWT6W74

More documents and user manuals: **https://manuals.plus/**