Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 721353808395

JustFine Replacement Remote Control User Manual

FOR YAMAHA AUDIO VIDEO AV RECEIVERS

Compatible Models: RX-V373, YHT-493BL, HTR-3065, YHT-595, RX-V473BL, YHT-699U, HTR-6240, YHT-897BL, RXV371BL, YHT493, HTR3064, YHT593BL, RXV473

Model: 721353808395

1. Introduction

This manual provides instructions for the JustFine replacement remote control, designed for seamless operation with a range of Yamaha Audio Video AV Receivers. This remote offers a direct replacement experience, requiring no programming.

Compatible Yamaha AV Receiver models include: RX-V373, YHT-493BL, HTR-3065, YHT-595, RX-V473BL, YHT-699U, HTR-6240, YHT-897BL, RXV371BL, YHT493, HTR3064, YHT593BL, RXV473.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control, highlighting the battery compartment for easy access and battery insertion.

3. Operating Instructions

This section details the primary functions of the buttons on your JustFine replacement remote control.



Image: Front view of the remote control, displaying all buttons and their labels for operational reference.

3.1 Power and System Control

- **SOURCE ON/OFF**: Powers the AV receiver on or off.
- **SLEEP**: Sets the sleep timer for automatic power-off.
- **RECEIVER ON/OFF**: Specific power control for the receiver unit.

3.2 Input Selection

- **HDMI 1-4**: Selects HDMI input sources.
- **AV 1-4**: Selects analog video input sources.
- **AUDIO 1-4**: Selects analog audio input sources.
- **USB**: Selects the USB input.
- **V-AUX**: Selects the front panel auxiliary input.
- **MODE**: Cycles through various input modes.

3.3 Tuner Functions

- **FM/AM**: Switches between FM and AM radio bands.
- **INFO**: Displays tuner information.
- **MEMORY**: Stores radio presets.
- **PRESET UP/DOWN**: Navigates through stored radio presets.
- **TUNING UP/DOWN**: Manually tunes radio frequencies.

3.4 Sound and Scene Control

- **MOVIE/MUSIC**: Selects sound fields optimized for movies or music.
- **SUR. DECODE**: Activates surround sound decoding.
- **STRAIGHT**: Bypasses sound processing for direct audio.
- **ENHANCER**: Activates compressed music enhancer.
- **BD/DVD, TV, CD, RADIO**: One-touch scene selection buttons for common activities.

3.5 Navigation and Volume

- **SETUP**: Accesses the receiver's setup menu.
- **OPTION**: Displays options for the current source.
- **ENTER**: Confirms selections in menus.
- **ARROW BUTTONS (Up, Down, Left, Right)**: Navigates menus and settings.
- **RETURN**: Goes back to the previous menu or screen.
- **DISPLAY**: Changes display information.
- **VOLUME UP/DOWN**: Adjusts the master volume level.
- **MUTE**: Mutes or unmutes the audio.

3.6 Playback and Numeric Entry

- **TOP MENU/POP-UP MENU**: Accesses disc menus for connected players.
- **HOME**: Returns to the main menu.
- **PLAY/PAUSE, STOP, FAST FORWARD, REWIND, SKIP FORWARD, SKIP BACKWARD**: Standard playback controls.
- **NUMERIC KEYPAD (0-9, +10, ENT)**: For direct input of numbers, such as track numbers or radio frequencies.

3.7 TV Control (Limited Functionality)

- **TV VOL UP/DOWN**: Adjusts TV volume (if programmed or compatible).
- **TV CH UP/DOWN**: Changes TV channels (if programmed or compatible).
- **TV INPUT**: Cycles through TV inputs (if programmed or compatible).
- **TV MUTE**: Mutes TV audio (if programmed or compatible).

4. Care and Maintenance

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or inconsistent. Always replace both batteries at the same time with new ones of the same type.
- **Storage**: If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Avoid Exposure**: Keep the remote away from direct sunlight, heat sources, and moisture.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote is unresponsive	Dead or incorrectly inserted batteries	Check battery orientation. Replace batteries with new ones.
Remote does not control the receiver	Obstruction between remote and receiver; remote not pointed correctly	Ensure a clear line of sight to the receiver's IR sensor. Point the remote directly at the receiver.
Some buttons do not work	Button malfunction or specific function not supported by your receiver model	Test other buttons. If only specific buttons fail, contact support. Confirm your receiver supports the function.
Remote interferes with other devices (e.g., LED lights)	Infrared signal overlap	This can sometimes occur due to IR signal characteristics. Try repositioning the receiver or the interfering device if possible.

If problems persist after attempting these solutions, please contact customer support.

6. Product Specifications

- **Brand**: JustFine
- **Model Number**: 721353808395
- **Compatible Devices**: Yamaha Audio Video AV Receivers (RX-V373, YHT-493BL, HTR-3065, YHT-595, RX-V473BL, YHT-699U, HTR-6240, YHT-897BL, RXV371BL, YHT493, HTR3064, YHT593BL, RXV473)
- **Connectivity Technology**: Infrared
- **Max Number of Supported Devices**: 1 (specifically for the Yamaha receiver)
- **Special Feature**: Ergonomic design
- **Product Dimensions**: 4.53 x 1.57 x 1.38 inches
- **Item Weight**: 2.65 ounces
- **Batteries Required**: 2 x AAA (not included)
- **Date First Available**: November 26, 2016

7. Warranty and Customer Support

This JustFine replacement remote control is sold with a money-back guarantee and hassle-free return policy, including 30 days of quality assurance.

For any issues or inquiries, please contact JustFine customer support via email. Refer to your purchase documentation for specific contact details.

© 2023 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08NX7K6XZ

More documents and user manuals: **https://manuals.plus/**