Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anker B08P4QMDT8

User Manual: Made for Amazon, Kids Portable Charger

Model: B08P4QMDT8

Brand: Anker

1. Introduction and Overview

This manual provides essential information for the safe and effective use of your Anker Kids Portable Charger. Designed specifically for Fire Kids & Kids Pro Tablets, this high-capacity power bank ensures your child's device stays charged on the go.

Key features include a durable, kid-friendly design, high battery capacity, and broad compatibility with various Fire Kids tablet models.



Figure 1.1: Top view of the Anker Kids Portable Charger, highlighting its compact and ergonomic design.

2. What's Included

Please verify that all items listed below are present in your package:

- Anker Kids Portable Charger (Pink)
- Welcome Guide / User Manual

Note: Charging cables and power adapters are not included and must be purchased separately.



Figure 2.1: The portable charger shown alongside its included welcome guide.

3. Setup and Initial Use

3.1 Charging the Portable Charger

Before first use, fully charge your portable charger. This ensures optimal performance and battery longevity.

1. Connect a compatible USB-C or Micro USB charging cable (not included) to the "Input/Output" port on the portable charger.
2. Connect the other end of the cable to a USB wall adapter (not included) or a powered USB port.
3. The LED indicator lights on the charger will illuminate to show charging progress. All lights will be solid when fully charged.

A full charge typically takes approximately 3.5 hours.



Figure 3.1: Detail of the charging ports on the portable charger.

3.2 Connecting to a Device

The portable charger is compatible with Fire 7 Kids, Fire HD 8 Kids, Fire HD 10 Kids, Fire 7 Kids Pro, Fire HD Kids Pro, and Fire HD 10 Kids Pro tablets.

1. Ensure your portable charger is sufficiently charged.
2. Connect a compatible charging cable (USB-A to Micro USB or USB-A to USB-C, depending on your tablet) to the "Output" USB-A port on the portable charger.
3. Connect the other end of the cable to your Fire Kids tablet.
4. The tablet should begin charging automatically.



Figure 3.2: The portable charger actively charging a Fire Kids tablet.

4. Operating Instructions

4.1 Checking Battery Level

Press the power button on the portable charger once to view the current battery level indicated by the LED lights. Each light represents a portion of the charge.

- Four lights: 75-100% charge
- Three lights: 50-75% charge
- Two lights: 25-50% charge
- One light: 0-25% charge (recharge soon)

4.2 Charging Multiple Devices (if applicable)

The portable charger is designed primarily for single-device charging. While it features multiple port types, simultaneous charging of multiple devices is not recommended for optimal performance and safety.

5. Maintenance

5.1 Cleaning

To clean the portable charger, gently wipe the surface with a soft, dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the device.

5.2 Storage

Store the portable charger in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, it is recommended to charge the unit to approximately 50% every 3-6 months to maintain battery health.

5.3 Durability

The charger is constructed with BPA-free silicone and features a durable rubber finish, making it easy for kids to grip and resistant to minor bumps and drops. Despite its robust design, avoid intentional dropping or subjecting the device to severe impacts.



Figure 5.1: The underside of the portable charger, displaying regulatory markings and specifications.

6. Troubleshooting

6.1 Charger Not Charging

- Ensure the charging cable is securely connected to both the portable charger and the power source.
- Verify that the wall adapter or USB port is functional. Try a different adapter or port.
- Try a different charging cable.

6.2 Device Not Charging from Portable Charger

- Check if the portable charger has sufficient battery charge (refer to Section 4.1).
- Ensure the cable connecting the charger to your device is securely plugged in at both ends.
- Try a different charging cable.
- Confirm your device is compatible with the portable charger (refer to Section 7.1).

6.3 Slow Charging

- Ensure you are using a high-quality charging cable.
- Some devices may charge slower if they are in active use while charging.
- Verify the power adapter used to charge the portable charger provides adequate output.

7. Specifications

Feature	Detail
Battery Capacity	10,000 mAh
Recharge Time	Approx. 3.5 hours (with compatible adapter)
Input Ports	Micro USB, USB-C
Output Ports	USB-A
Compatibility	Fire 7 Kids, Fire HD 8 Kids, Fire HD 10 Kids, Fire 7 Kids Pro, Fire HD Kids Pro, Fire HD 10 Kids Pro
Material	BPA-free silicone, durable rubber finish

8. Warranty and Support

Anker products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the contact information provided in your Welcome Guide or visit the official Anker website.

Please retain your proof of purchase for warranty claims.

© 2025 Anker Innovations Limited. All rights reserved.
Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08P4QMDT8

More documents and user manuals: **https://manuals.plus/**