Wancle P00273

Wancle Electric Coffee Grinder User Manual

Model: P00273

Product Overview

The Wancle Electric Coffee Grinder is a versatile, one-touch appliance designed for grinding coffee beans, spices, seeds, nuts, and herbs. It features a pure copper motor and stainless steel blades for efficient and consistent grinding. Its compact design saves counter space, making it an ideal addition to any kitchen.



Image: The Wancle Electric Coffee Grinder in black, shown alongside whole coffee beans and ground coffee, highlighting its primary function.

Safety Precautions

- Always ensure the grinder is unplugged before cleaning or when not in use.
- Do not immerse the motor base in water or any other liquid.
- Keep out of reach of children.
- Do not operate the grinder without the transparent lid securely in place.
- Avoid grinding excessively hard or wet ingredients.
- Do not overfill the grinding chamber; refer to the maximum capacity.

Setup

Before first use, wipe the exterior of the grinder with a damp cloth. Ensure the grinding chamber and lid are clean and dry.



Image: A close-up view of the grinder's interior, showing the stainless steel blades and chamber, ready for use.

Place the grinder on a stable, dry, and flat surface.

Plug the power cord into a 120 VAC / 60 HZ electrical outlet.

Operating Instructions

Grinding Coffee Beans

1. Open the transparent lid.
2. Pour up to 60g of coffee beans into the grinding chamber. Do not overfill.



Image: Coffee beans being poured into the grinding chamber of the Wancle Electric Coffee Grinder.

3. Securely place the transparent lid back onto the grinder. Ensure it clicks into place.



Image: A hand placing the transparent lid onto the Wancle Electric Coffee Grinder, ensuring it is properly seated.

4. Press down on the control button located on the lid to start grinding. The grinder will operate as long as the button is pressed.



Image: A finger pressing the one-touch button on the lid of the Wancle Electric Coffee Grinder to initiate the grinding process.

5. Release the button to stop grinding. You can observe the grinding progress through the transparent lid.
6. For desired fineness, refer to the grinding time guidelines below:
    - Coarse (French Press): 6-8 seconds
    - Medium (Moka Pot): 10-12 seconds
    - Medium Fine (Pour Over): 16-18 seconds
    - Fine (Aeropress): 22-24 seconds
    - Ultra Fine (Turkish): 28-30 seconds



Image: A visual guide illustrating different coffee grind fineness levels (Coarse, Medium, Medium Fine, Fine, Ultra Fine) with corresponding grinding times and recommended brewing methods.

7. Once the desired fineness is achieved, unplug the grinder and carefully remove the lid.



Image: Freshly ground coffee inside the grinder's chamber, with the included cleaning brush visible, ready for easy removal.

8. Pour out the ground coffee.

Grinding Spices, Seeds, Nuts, and Herbs

The Wancle Electric Coffee Grinder is also suitable for grinding various dry ingredients. Follow the same operating steps as for coffee beans, adjusting the grinding time to achieve the desired consistency for your specific ingredients.



Image: The Wancle Electric Coffee Grinder positioned on a counter with various spices, herbs, and a cup of coffee, illustrating its versatility beyond just coffee beans.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder.

Cleaning the Grinding Chamber and Blades

1. Always unplug the grinder before cleaning.
2. Use the included cleaning brush to remove any remaining ground particles from the grinding chamber and around the blades.
3. For stubborn residue, wipe the chamber and blades with a dry cloth. Do not use water or abrasive cleaners on the motor base or blades.

Cleaning the Lid and Exterior

1. The transparent lid can be washed with warm, soapy water. Rinse thoroughly and dry completely before reattaching.
2. Wipe the exterior of the grinder with a soft, damp cloth.

Troubleshooting

Grinder Does Not Turn On

- Ensure the power cord is securely plugged into a working electrical outlet.
- Verify that the transparent lid is correctly and securely placed on the grinder. The grinder has a safety mechanism that prevents operation if the lid is not properly aligned.

Inconsistent Grinding

- Ensure you are not overfilling the grinding chamber. Reduce the amount of ingredients.
- Adjust the grinding time according to the desired fineness. Pulsing the grinder in short bursts can help achieve a more consistent grind.

Specifications

Feature	Detail
Brand	Wancle
Model Number	P00273
Product Dimensions	3.5"L x 3.5"W x 6.6"H
Item Weight	15.9 ounces
Voltage / Frequency	120 VAC / 60 HZ
Product Power	150 Watts
Capacity	Up to 60g
Material	Stainless Steel Blades & Bowl, Plastic Body

Warranty and Support

For warranty information or technical support, please contact Wancle customer service. You can find more information and contact details on the official Wancle website: www.wancle.net.
Wancle is committed to providing quality products and customer satisfaction.