LKPower AC Adapter

LKPower Wall Charger AC Adapter for DURALAST BP DL750 Jump Starter User Manual

Model: AC Adapter

Introduction

This manual provides essential instructions for the safe and effective use of your LKPower AC Wall Charger Adapter. This adapter is designed to power and charge compatible devices, specifically the DURALAST BP DL750 Jump Starter. Please read this manual thoroughly before use and retain it for future reference.

Important Safety Information

WARNING: Failure to follow these safety instructions could result in fire, electric shock, injury, or damage to the product or property.

- Use only with the specified DURALAST BP DL750 Jump Starter or other compatible devices as indicated by the manufacturer.
- Do not expose the adapter to rain, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the power outlet voltage matches the adapter's input specifications (AC 100-240V).
- Avoid placing the adapter in direct sunlight or near heat sources.
- Keep out of reach of children.
- Unplug the adapter from the power outlet when not in use or during electrical storms.

Product Overview

The LKPower AC Wall Charger Adapter is designed to provide reliable power for your DURALAST BP DL750 Jump Starter. It features a compact design and universal voltage input.



Figure 1: LKPower AC Wall Charger Adapter. This image shows the black AC adapter with its two-prong plug and the coiled DC output cable, highlighting its compact design.



Figure 2: Front and Side Views of the Adapter. This image displays the front of the adapter with its input specifications and regulatory marks, alongside a side profile view showing its textured casing.



Figure 3: Adapter Dimensions. This image illustrates the physical dimensions of the adapter, showing a length of 2.6 inches, a width of 1.6 inches, and a thickness of 1.2 inches. The cable length is indicated as 76 inches.

Setup Instructions

1. **Inspect the Adapter:** Before first use, carefully inspect the AC adapter and its cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Plug the DC output connector of the LKPower AC Adapter into the charging port of your DURALAST BP DL750 Jump Starter. Ensure a secure connection.
3. **Connect to Power Outlet:** Insert the AC input plug of the adapter into a standard AC 100-240V wall outlet.
4. **Verify Charging:** Confirm that the DURALAST BP DL750 Jump Starter indicates it is receiving charge (e.g., charging indicator light).

Note: Always connect the adapter to the device first, then to the wall outlet.

Operating Instructions

The LKPower AC Wall Charger Adapter operates automatically once connected. It converts AC power from the wall outlet to the DC power required by your DURALAST BP DL750 Jump Starter.

- The adapter is designed for continuous charging until the connected device's battery is full.
- It features built-in over-voltage and over-heat protection to ensure safe operation.
- Once charging is complete, disconnect the adapter from the wall outlet first, then from the device.



Figure 4: Adapter in Use. This image shows the AC adapter plugged into a power strip, illustrating a typical usage scenario for charging a compatible device (represented by a generic white device).

Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage. If damage

is found, discontinue use immediately and replace the adapter.

Troubleshooting

Problem	Possible Cause	Solution
Adapter not charging device.	No power from outlet. Loose connection. Damaged adapter or cable. Incompatible device.	Test outlet with another device. Ensure all connections are secure. Inspect adapter and cable for damage; replace if necessary. Verify device compatibility with the adapter.
Adapter feels hot during use.	Normal operation (slight warmth). Poor ventilation. Overload or internal fault.	A slight warmth is normal. Ensure adapter is in a well-ventilated area. If excessively hot, disconnect immediately and discontinue use.

If troubleshooting steps do not resolve the issue, contact customer support.

Specifications

- **Input:** AC 100-240V, 50/60Hz (Worldwide AC Input)
- **Output:** Matches device requirements
- **Protection Features:** Over Voltage Protection, Over Heat Protection
- **Compatibility:** DURALAST BP DL750 Jump Starter
- **Manufacturer:** LKPower
- **ASIN:** B08Q87DSLT

Warranty and Customer Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact LKPower customer service directly. Contact details are typically available on the manufacturer's website or through your retailer.
Please have your product model (AC Adapter) and ASIN (B08Q87DSLT) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question