Galanz GSWWD09S1A09A

Galanz 0.9 Cu. Ft Air Fry Microwave Stainless Steel User Manual

Model: GSWWD09S1A09A | Brand: Galanz

Introduction

The Galanz 0.9 Cu. Ft Air Fry Microwave Stainless Steel is a versatile kitchen appliance combining the functionalities of a microwave, air fryer, and convection oven. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting.

Important Safety Information

- Read all instructions before use.
- Do not operate the oven empty.
- Do not use metal containers or foil in microwave mode.
- Ensure proper ventilation around the unit.
- Keep the door seals clean and free from debris.
- Supervise children when the appliance is in use.

Setup

Unpacking

Carefully remove the microwave and all accessories from the packaging. Ensure all packing materials, including any protective film, are removed.

Placement

Place the microwave on a flat, stable surface capable of supporting its weight (38.9 pounds). Ensure there is adequate space (at least 4 inches) around the unit for proper ventilation. Do not block any ventilation openings.

Power Connection

Plug the microwave into a grounded electrical outlet.

Initial Setup: Setting the Clock

To set the clock, press the "Clock/Timer" button. Use the "+" and "-" buttons to adjust the hour and minute. Press "Clock/Timer" again to confirm.



Image: Front view of the Galanz 0.9 Cu. Ft Air Fry Microwave in Stainless Steel, showing the digital display and control panel.

Operating Instructions

Control Panel Overview

The control panel features dedicated buttons for various cooking modes including Bake, Air Fry, Roast, Micro, Conv (Convection), and Micro+Conv (Microwave + Convection). It also includes Auto Cook, Popcorn, Auto Reheat, time adjustment buttons (+5 Min, +1 Min, +30 Sec), Defrost (Time/Weight), Clock/Timer, Unlock, Start, and Stop/Cancel.

Microwave Functions

Basic Heating

To quickly heat food, press the "+30 Sec" button for 30-second increments. For longer times, press the "+/-" buttons to set the desired time, then press "Start".

Auto Cook

Press "Auto Cook" and select the desired food type by opening the door and referencing the cooking table inside the microwave. Press "Start" to confirm and begin cooking.

Auto Reheat

Press "Auto Reheat" and select the desired food type. Press "Start" to confirm and begin reheating.

Defrost

Press "Defrost Time/Weight". Use the "+/-" buttons to select the weight of the food, then press "Start".

Air Fry Functions

The air fry function allows for healthier frying with little to no oil. Use the included easy-clean air fry kit for optimal results.

Using the Air Fry Kit

Place food on the air fry basket, which sits on top of the air fry pan. This assembly then sits on the turntable inside the microwave.

Setting Air Fry Temperature and Time

Press the "Air Fry" button. Use the "+/-" buttons to select the desired temperature (300°F to 400°F). Press "Start" to confirm. Then, use the "+/-" buttons to set the cooking time and press "Start" again.

Convection Functions (Bake/Roast)

Press the "Bake/Air Fry/Roast" button once. Use the "+/-" buttons to select the desired temperature. Press "Start" to confirm. Then, use the "+/-" buttons to set the cooking time and press "Start" again.

Combi Speed Cooking

This intelligent combination of True Convection and microwave cooking allows for faster cooking with optimal texture. Refer to the internal cooking table for specific programs.

Maintenance

Cleaning the Interior

Wipe the interior with a damp cloth after each use. For stubborn stains, use a mild detergent. Ensure the turntable and air fry kit are removed and cleaned separately.

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.

Cleaning the Air Fry Kit

The easy-clean air fry kit (basket and pan) can be separated for thorough cleaning. It is dishwasher safe.

Troubleshooting

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly / Power cord unplugged	Close the door firmly / Check power connection
Food not heating	Incorrect power level / Time set too short	Adjust power level and cooking time
Air fry function not crisping	Food overloaded / Incorrect temperature/time	Do not overload the basket; cook in batches if necessary / Adjust temperature and time according to recipe

Problem	Possible Cause	Solution
Door requires "Unlock" button	Safety lock engaged	This is a design feature; press "Unlock" before opening the door.

Specifications

- Product Dimensions: 15.75 x 19.02 x 11.06 inches
- Item Weight: 38.9 pounds (17.69 Kilograms)
- Capacity: 0.9 Cubic Feet
- Wattage: 900 watts
- Voltage: 120 Volts
- Material: Stainless Steel
- Installation Type: Countertop
- Special Feature: Auto Cook
- Included Components: Easy-Clean Air Fry Kit

Warranty and Support

For warranty information or technical support, please refer to the full instruction manual included with your product or visit the official Galanz website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question