Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro L2836HD

Replacement Remote Control for PROLINE L2836HD TV

Model: L2836HD | Brand: Passion-Electro

1. Introduction

This manual provides instructions for the Passion-Electro replacement remote control, specifically designed for the PROLINE L2836HD television model. This remote is a specialized replacement, not a generic universal remote, and is intended to provide access to all functions of the original remote control without requiring any programming.



Figure 1: Passion-Electro Replacement Remote Control. This image illustrates the general appearance of the remote control. The actual button layout may vary slightly depending on the specific original remote model it replaces.

2. Setup

The replacement remote control requires no programming. Simply install the batteries to begin operation.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) 1.5V AAA (LR03) batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. *(Batteries are not included)*.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

The remote control is now ready for use with your PROLINE L2836HD TV.

3. Operating Instructions

This replacement remote control is designed to replicate the functionality of your original PROLINE L2836HD TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

3.1 Basic Functions

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Selects TV channels directly.
- **Volume Up/Down (+/-):** Adjusts the sound volume.
- **Channel Up/Down (P+/P-):** Changes TV channels sequentially.
- **Mute Button:** Silences the TV audio.
- **Source/Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Buttons (Arrows, OK):** Used to navigate menus and confirm selections.

Note: Some users have reported that the Volume and Program (Channel) buttons may be inverted compared to their original remote. Please test these functions upon first use.

4. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If not used for extended periods, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

Problem	Solution

Problem	Solution
Remote is not responding.	• Check if the batteries are inserted correctly with the correct polarity. • Replace old batteries with new 1.5V AAA batteries. • Ensure there are no obstructions between the remote and the TV's infrared receiver. • Point the remote directly at the TV.
Some buttons do not work or are inverted (e.g., Volume/Program).	• This remote is designed to be compatible, but minor button layout differences or inversions can occur with some TV models. Familiarize yourself with the remote's specific button functions. • Ensure the remote is indeed for the PROLINE L2836HD model.
LED indicator on remote does not light up.	• Check battery installation. • Replace batteries. • If the issue persists, the remote may be faulty.

6. Specifications

Feature	Detail
Brand	Passion-Electro
Model Number	L2836HD
Compatible Devices	PROLINE L2836HD TV
Connectivity Technology	Infrared
Color	Black
Battery Type	2 x 1.5V AAA (LR03) batteries (not included)
Maximum Range	10 Meters
Number of Buttons	35
Special Feature	Specialized replacement, no programming required

7. Warranty & Support

7.1 Manufacturer's Warranty

This product comes with a**2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact your retailer or the manufacturer, Passion-Electro, through the platform where the product was purchased. Please refer to your purchase details for specific contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08R8XG7P8

More documents and user manuals: **https://manuals.plus/**