ALLIMITY RM-ADP022

ALLIMITY RM-ADP022 Replacement Remote Control User Manual

Model: **RM-ADP022**
Brand: **ALLIMITY**

1. Introduction

This user manual provides comprehensive instructions for the ALLIMITY RM-ADP022 replacement remote control. Designed to function as a direct replacement, this remote offers seamless control over compatible Sony DVD Home Theatre Systems without requiring any complex setup or programming.

Please read this manual carefully to ensure proper use and to maximize your experience with the remote control.

2. Compatibility

The ALLIMITY RM-ADP022 remote control is compatible with the following Sony DVD Home Theatre System models:

- DAVDZ870W
- DAVDZ660
- DAV-DZ860W
- DAV-DZ870W
- DAVDZ77T
- DAV-DZ660
- DAV-DZ777
- DAV-DZ77T
- DAVDZ860W
- DAVDZ777
- HCDDZ77T

- HCDDZ860W
- HCDDZ777
- HCDDZ870W

No programming is required for these models; simply insert batteries and begin use.

3. Setup: Battery Installation

To begin using your ALLIMITY RM-ADP022 remote control, you will need to install two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, illustrating where to insert AAA batteries. Ensure correct polarity.

The remote control is now ready for use with your compatible Sony DVD Home Theatre System.

4. Operating Instructions

The ALLIMITY RM-ADP022 remote control provides full functionality for your Sony DVD Home Theatre System. Below is a general overview of the remote's layout and key button functions.





Image: Front view of the ALLIMITY RM-ADP022 remote control, showing the arrangement of all control buttons.

Key Button Functions:

- **Power (I/O)**: Turns the system on or off.
- **TV I/O**: Controls the power of a connected television.
- **THEATRE** / **ONE-TOUCH PLAY**: Activates theatre mode or initiates one-touch playback.
- **S-AIR MODE** / **BRAVIA Sync** / **SLEEP** / **NIGHT** / **FUNCTION** Various mode and function selections.
- **DISPLAY** / **DIMMER** / **DYNAMIC BASS**: Adjusts display settings, screen brightness, or bass levels.
- **Number Buttons (0-9)**: For direct track selection, channel input, or numerical entries.
- **CLEAR** / **ENTER**: Clears input or confirms selections.
- **PICTURE NAVI** / **AUDIO** / **SUBTITLE** / **ANGLE** Accesses picture navigation, audio tracks, subtitle options, or camera angles.
- **D.TUNING**: Digital tuning function.
- **DVD TOP MENU** / **DVD MENU**: Navigates to the DVD's top menu or main menu.
- **Navigation Pad (Up, Down, Left, Right, Center ENTER)**: Used for menu navigation and selection.
- **RETURN** / **MENU** / **DISPLAY** / **TOOLS** / **SYSTEM MENU** Accesses various system menus and tools.
- **Playback Controls (PRESET-, REPLAY, ADVANCE, PRESET+, TUNING-, PLAY, PAUSE, STOP, TUNING+, FAST FORWARD, REWIND)**: Standard media playback and tuning controls.
- **TV VOL +/-** / **MUTING** / **PROG** / **SOUND MODE** Controls television volume, mutes audio, selects program modes, or adjusts sound modes.

Refer to your Sony DVD Home Theatre System's original manual for specific functions and advanced operations of each button.

5. Maintenance

Cleaning the Remote Control:

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

Battery Replacement:

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new AAA alkaline batteries.

- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

6. Troubleshooting

Remote Control Not Working:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA alkaline batteries.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the infrared sensor on your Sony DVD Home Theatre System. Obstructions can block the signal.
- **Distance:** Operate the remote within a reasonable distance from the system.
- **System Power:** Confirm that your Sony DVD Home Theatre System is powered on.
- **Interference:** Strong light sources (like direct sunlight or fluorescent lights) can sometimes interfere with infrared signals. Try operating the remote in a different lighting condition.

Specific Functions Not Responding:

- **Compatibility:** Verify that your specific Sony DVD Home Theatre System model is listed in the compatibility section. While this remote is a replacement, some very specific advanced functions might vary slightly from the original remote for certain models.
- **System State:** Ensure the system is in the correct mode (e.g., DVD mode for DVD functions, TV mode for TV functions) for the button to operate.

7. Specifications

Model Number	RM-ADP022
Brand	ALLIMITY
Connectivity Technology	Infrared (IR)
Compatible Devices	Sony DVD Home Theatre Systems (specific models listed in Section 2)
Batteries Required	2 x AAA (Alkaline recommended)
Special Feature	No Programming Required
Product Dimensions	6 x 2 x 1 inches (approximately)
Item Weight	2 ounces (approximately, without batteries)

8. Warranty and Support

This ALLIMITY RM-ADP022 replacement remote control is designed for reliable performance. For any issues or questions regarding the product, please contact the seller or manufacturer directly through the platform where the purchase was made.

Please retain your proof of purchase for any warranty claims or support inquiries.