**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## NECCHI NH9206

# Necchi NH9206 Cordless Vacuum Cleaner User Manual

Model: NH9206

## 1. Introduction

Thank you for choosing the Necchi NH9206 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

### Important Safety Instructions

- Always ensure the appliance is switched off and unplugged before cleaning or performing maintenance.
- Do not use the vacuum cleaner to pick up water or wet substances.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up burning or smoking materials, such as cigarettes, matches, or hot ashes.
- Use only manufacturer-recommended attachments.
- Store the vacuum cleaner indoors in a dry place.

## 2. Product Overview

Familiarize yourself with the components of your Necchi NH9206 cordless vacuum cleaner.



**Figure 1:** The Necchi NH9206 Cordless Vacuum Cleaner, illustrating its upright configuration with the main motor unit, extension tube, and motorized floor brush.

### Main Components:

- **Main Motor Unit:** Contains the motor, dustbin, and battery.
- **Extension Tube:** Connects the main unit to the floor brush or other attachments for extended reach.
- **Motorized Floor Brush:** Equipped with a scratch-resistant roller and LED light for effective cleaning on various surfaces.
- **2-in-1 Brush Attachment:** Versatile tool for crevices and upholstery.
- **Charger:** For recharging the removable lithium battery.

## 3. Setup

### Assembly

1. **Attach the Extension Tube:** Insert the extension tube into the main motor unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the motorized floor brush to the other end of the extension tube, ensuring it locks firmly.
3. **Install Battery:** If not already installed, insert the removable lithium battery into the designated slot on the main motor unit.

### Initial Charging

Before first use, fully charge the battery. The charging time is approximately 5.5 hours.

1. Connect the charger to the charging port on the main motor unit.
2. Plug the charger into a suitable power outlet.

3. The LED display will indicate the charging status. Once fully charged, disconnect the charger.

## 4. Operating Instructions

### Power On/Off and Speed Selection

- To turn on the vacuum cleaner, press the power button on the main motor unit.
- The vacuum cleaner has 2 suction speeds. Press the speed selection button to switch between the low and high power modes.
- To turn off the vacuum cleaner, press the power button again.

### Using Attachments

- **Motorized Floor Brush:** Ideal for cleaning floors, carpets, and rugs. The integrated LED light illuminates the cleaning path. The 180° swivel joint facilitates cleaning in corners and under furniture.
- **2-in-1 Brush Attachment:** Detach the extension tube and connect this attachment directly to the main motor unit. Use it for cleaning upholstery, car interiors, mattresses, sofas, and tight spaces.

The operating time ranges from 15 to 30 minutes, depending on the selected speed setting.

## 5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### Emptying the Dustbin

1. Ensure the vacuum cleaner is switched off.
2. Locate the dustbin release button on the main motor unit.
3. Press the button to detach the 1.2 L dustbin.
4. Empty the contents into a waste bin.
5. Reattach the dustbin securely until it clicks.

### Cleaning the HEPA Filter

The advanced cyclonic filtration system includes a washable HEPA filter that removes over 99% of dust and allergens.

1. Remove the dustbin as described above.
2. Carefully remove the HEPA filter from the dustbin assembly.
3. Tap the filter gently to dislodge loose dust.
4. Rinse the filter under cold running water until the water runs clear. Do not use detergents.
5. Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use heat to dry.
6. Replace the filter if it shows signs of damage or excessive wear.

### Cleaning the Motorized Brush

- Turn off the vacuum cleaner and detach the floor brush.

- Inspect the brush roller for tangled hair or debris.
- Use scissors or a brush to carefully remove any obstructions from the roller.
- Ensure the roller spins freely before reattaching the brush.

### Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the vacuum cleaner with a partially charged battery if not used for extended periods.
- Only use the original charger provided with the appliance.

## 6. Troubleshooting

Refer to this section for solutions to common issues you might encounter.

| Problem | Possible Cause | Solution |
|---|---|---|
| Vacuum cleaner does not turn on. | Battery is discharged. | Charge the battery fully. |
| | Battery not properly installed. | Ensure the battery is securely clicked into place. |
| Loss of suction power. | Dustbin is full. | Empty the dustbin. |
| | HEPA filter is clogged. | Clean or replace the HEPA filter. |
| | Obstruction in the nozzle or tube. | Check and clear any blockages. |
| Motorized brush not rotating. | Hair or debris tangled in the brush. | Clean the brush roller. |
| | Brush attachment not properly connected. | Ensure the brush is securely attached. |
| Short operating time. | Battery not fully charged. | Charge the battery completely. |
| | Using high speed continuously. | High speed consumes more power; use low speed for longer runtime. |

## 7. Specifications

Detailed technical specifications for the Necchi NH9206 Cordless Vacuum Cleaner.

- **Model:** NH9206
- **Type:** 2-in-1 Cordless Bagless Electric Broom

- **Motor:** DC 100 W
- **Suction Power:** 5.5 kPa
- **Battery:** Removable Lithium 22.2 V - 2200 mAh
- **Filter System:** Cyclonic with HEPA filter
- **Dustbin Capacity:** 1.2 L (with easy emptying)
- **Operating Time:** 15 - 30 minutes (depending on speed)
- **Suction Speeds:** 2
- **Charging Time:** 5.5 hours (with LED display)
- **Features:** Space-saving resting position, Motorized rotating brush with scratch-resistant roller and LED light
- **Included Accessories:** 2-in-1 brush attachment, Battery charger
- **Product Dimensions (including tube):** 110 x 25 x 21.5 cm
- **Color:** Black
- **EAN Code:** 8056039100800

## 8. Warranty and Support

Your Necchi NH9206 Cordless Vacuum Cleaner is covered by a manufacturer's warranty. Please refer to the warranty card included in the product packaging for specific terms and conditions.

For technical support, spare parts, or warranty claims, please contact your retailer or the authorized Necchi service center. Keep your proof of purchase for warranty validation.

For further assistance, you may visit the official Necchi website or contact customer service.

© 2023 NECCHI. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B08RP93Z7Y**

More documents and user manuals: **https://manuals.plus/**