Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY AMT-2IN1-NS-RCFNA-21-3RD-VOICE

User Manual for ALLIMITY NS-RCFNA-21 Replacement Remote Control

Model: AMT-2IN1-NS-RCFNA-21-3RD-VOICE

1. Introduction

This manual provides instructions for the ALLIMITY NS-RCFNA-21 Replacement Remote Control, designed for Insignia LED HD Smart TV Edition models. This remote offers standard control functions, voice command capabilities, and direct access buttons for popular streaming services.

2. Product Overview

The NS-RCFNA-21 remote control is a new replacement unit made of durable plastic. It features a comprehensive button layout for TV navigation and specific shortcut buttons for quick access to streaming applications.





Figure 2.1: Front view of the NS-RCFNA-21 remote control, displaying its primary buttons including power, voice control, directional pad, and media playback controls.





Figure 2.2: The NS-RCFNA-21 remote control, showing the dedicated shortcut buttons for Prime Video, Netflix, HBO, and Hulu, located at the lower section of the remote.

Key Features:

- **Voice Remote:** Control your TV, launch apps, search for content, switch inputs, and manage smart home devices using voice commands.
- **Shortcut Buttons:** Instant access to Prime Video, Netflix, HBO, and Hulu with dedicated buttons.
- **Standard Controls:** Includes power, volume, channel, navigation, and playback controls.

3. Setup and Pairing Instructions

To ensure proper functionality, the remote control must be paired with your Insignia TV Edition television.

Pairing Procedure:

1. Ensure your TV is powered on and functioning correctly.
2. Insert two AAA batteries into the remote control, observing the correct polarity.
3. Press and hold the **Home** button on the remote control for approximately 30 seconds.
4. Release the **Home** button. The remote will enter pairing mode.
5. Wait for approximately 60 seconds. During this time, the remote will attempt to automatically pair with your TV.
6. A "Pairing success" message should appear on your TV screen once the pairing process is complete.

If the remote does not pair successfully, repeat the steps. Ensure there are no obstructions between the remote and the TV during the pairing process.

4. Operating Instructions

Once paired, the remote control provides full functionality for your Insignia TV.

Using Voice Control:

- Press the **Voice** button (microphone icon) on the remote.
- Speak clearly into the microphone located at the top of the remote.
- You can issue commands such as "Open Netflix," "Search for action movies," "Switch to HDMI 1," or "Turn off the TV."

Using Shortcut Buttons:

- Press the dedicated buttons for **Prime Video**, **Netflix**, **HBO**, or **Hulu** to instantly launch the respective application.

General Navigation:

- Use the directional pad and **Select** button for menu navigation.
- The **Home** button returns you to the TV's main menu.
- Volume and channel controls function as standard.

5. Compatibility

This replacement remote control is compatible with the following Insignia TV Edition models:

- NS-24DF310NA21
- NS-39DF310NA21
- NS-50DF710NA21
- NS-55DF710NA21
- NS24DF310NA21

- NS39DF310NA21
- NS50DF710NA21
- NS55DF710NA21
- F20 Series
- F30 Series
- F50 Series
- NS-50F301NA22
- NS-58F301NA22
- NS-75F301NA22
- NS-70F501NA22

6. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always use new AAA batteries and replace both at the same time.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

7. Troubleshooting

Remote Not Controlling TV:

If the remote control does not respond to your TV, ensure that the CEC (Consumer Electronics Control) feature is enabled on your television. This feature allows devices connected via HDMI to communicate and control each other.
Steps to Enable CEC Control:

1. From the TV's Home menu, navigate to **Settings**.
2. Select **Display & Sounds**.
3. Choose **HDMI CEC Device Control**.
4. Change the setting to **On**.

If the issue persists after enabling CEC, try re-pairing the remote control as described in Section 3.

8. Specifications

Model Number	AMT-2IN1-NS-RCFNA-21-3RD-VOICE
Product Dimensions	6 x 2 x 0.65 inches
Item Weight	2 ounces
Batteries Required	2 AAA batteries (not included)
Material	Plastic
Color	Black
Special Feature	Ergonomic, Voice Control, Shortcut Buttons

Compatible Devices	Insignia LED HD Smart TV Edition (specific models listed in Section 5)

9. Warranty and Support

For warranty information or technical support regarding your ALLIMITY NS-RCFNA-21 Replacement Remote Control, please refer to the seller's return policy or contact the manufacturer directly. Keep your purchase receipt for any warranty claims.
Manufacturer: ALLIMITY inc

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08RX9SC5S

More documents and user manuals: **https://manuals.plus/**