Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BoxWave FineTouch Capacitive Stylus

BoxWave FineTouch Capacitive Stylus Pen Instruction Manual for Topcon Allegro 2

Model: FineTouch Capacitive Stylus

1. Introduction and Overview

The BoxWave FineTouch Capacitive Stylus Pen is designed to provide precise and accurate interaction with your Topcon Allegro 2 device and other capacitive touch screens. This stylus offers an enhanced user experience for writing, drawing, and navigating your device.
Key features include:

- **Versatile Compatibility:** Works with the Topcon Allegro 2 and all similar capacitive touch screens.
- **Precision Clear Tip:** An innovative clear disc tip allows for vision-enhancing precision, enabling you to see exactly where you are interacting on the screen.
- **Ease of Use:** No Bluetooth pairing or batteries required. Simply touch the tip to your screen to begin use.
- **Portable Design:** Features a built-in metal clip for easy attachment to clothing or cases, and a compact, lightweight pen-like form factor.
- **Protective Cap:** Includes a threaded cap to protect the stylus tip when not in use.



Figure 1: The BoxWave FineTouch Capacitive Stylus Pen shown alongside a Topcon Allegro 2 device, illustrating its intended use.

2. Setup

The BoxWave FineTouch Capacitive Stylus Pen requires no complex setup. It is designed for immediate use with any capacitive touch screen, including the Topcon Allegro 2.

1. **Unpack the Stylus:** Remove the stylus from its packaging.
2. **Remove Protective Cap:** Unscrew the threaded cap from the stylus tip.
3. **Begin Use:** Gently touch the clear disc tip to your device's screen. The stylus will function immediately.

Note: This stylus does not require Bluetooth pairing or batteries. It operates by simulating the touch of a finger on a capacitive screen.



Figure 2: A detailed view of the stylus tip with the protective cap removed, highlighting the clear disc.

3. Operating Instructions

The FineTouch Capacitive Stylus is designed for intuitive use. Follow these guidelines for optimal performance:

- **Holding the Stylus:** Hold the stylus as you would a traditional pen or pencil. Its ergonomic design ensures a comfortable grip.
- **Screen Interaction:** Use the clear disc tip to tap, swipe, draw, or write on your device's screen. The clear tip allows you to see through to the screen, providing precise placement.
- **Precision Tasks:** For detailed work, position the clear disc directly over the desired point on the screen. The transparent nature of the disc ensures you can accurately target small icons or fine lines.



Figure 3: A user demonstrating the stylus in action on a tablet, highlighting its comfortable use and precision.

Important Note: The FineTouch Capacitive Stylus does not support advanced features such as Palm Rejection or Pressure Sensitivity. It functions as a highly accurate finger substitute.

4. Maintenance

Proper care will extend the life and maintain the performance of your BoxWave FineTouch Capacitive Stylus Pen.

- **Tip Protection:** Always replace the threaded cap over the clear disc tip when the stylus is not in use. This protects the delicate tip from damage and debris.
- **Cleaning:** If the stylus tip or body becomes dirty, gently wipe it with a soft, dry, lint-free cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the stylus in a safe place where it will not be subjected to excessive force or extreme temperatures. The built-in metal clip can be used to secure it to a pocket or case.



Figure 4: The threaded cap and stylus tip, demonstrating how the cap protects the clear disc when not in use.

5. Troubleshooting

If you encounter issues with your stylus, consider the following:

- **Stylus Not Responding:**
  - Ensure your device's screen is clean and free of smudges or debris.
  - Verify that your device has a capacitive touch screen. The stylus is not compatible with resistive screens.
  - Gently press the tip against the screen. Excessive force is not required.
- **Inaccurate Input:**
  - Check if the clear disc tip is clean. Any dirt or oil can affect accuracy.
  - Ensure the clear disc is fully seated and not damaged.

For further assistance, refer to the support information provided in Section 7.

6. Specifications

Feature	Detail
Model Name	FineTouch Capacitive Stylus
Brand	BoxWave
Color	Metallic Silver
Item Weight	1 Ounce (approximately 28 grams)
Batteries Required	No
Compatibility	Topcon Allegro 2 and all capacitive touch screens

7. Warranty and Support

BoxWave provides limited third-party technical support for your device (up to 3 inquiries via messaging) related to the use of this stylus. This support is not affiliated with or endorsed by Topcon.
For support inquiries, please contact BoxWave directly through the messaging system of your purchase platform.
Please note: The Topcon Allegro 2 device is not included with the stylus.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08RZD3GZY

More documents and user manuals: **https://manuals.plus/**