Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Digitgarden 32MP 1296P Wireless Trail Camera

Digitgarden 32MP 1296P Wireless Trail Camera User Manual

Model: 32MP 1296P Wireless Trail Camera (ASIN: B08SBWG7FK)

Introduction

Thank you for choosing the Digitgarden 32MP 1296P Wireless Trail Camera. This manual provides detailed instructions for setting up, operating, and maintaining your camera to ensure optimal performance. Please read this manual thoroughly before using the product.



Figure 1: Digitgarden 32MP 1296P Wireless Trail Camera. This image displays the camera unit with two antennas and various icons representing its features such as HD resolution, Wi-Fi signal, 360-degree rotation, motion detection, auto-tracking, remote monitoring, two-way audio, alerts, night vision, cloud storage, sharing, internet-free monitoring, and waterproof design.

Setup Guide

Follow these steps to set up your Digitgarden Trail Camera for the first time.

1. Power Source Installation

The camera is battery-powered. Ensure you use the recommended battery type and install them correctly according to the polarity markings inside the battery compartment.

2. Micro SD Card Installation

Insert a Micro SD card (not included) into the designated slot. The camera supports local storage on an SD card. Ensure the card is inserted correctly until it clicks into place.



Figure 2: Storage options for the camera. The image shows the camera with a cloud icon, indicating support for cloud storage, and a diagram illustrating the insertion of an SD card into the camera's slot for local storage.

3. Mounting the Camera

The camera is designed for wall mounting. Use the provided mounting hardware to securely attach the camera to a desired location. Ensure the camera has a clear field of view.

4. Network Connection

The camera supports both wireless (Wi-Fi) and wired (Ethernet cable) connections. For wireless setup, ensure your smartphone is connected to a 2.4GHz Wi-Fi network.

1. **Wireless Connection:** Download the recommended mobile application (compatible with Android smartphones). Follow the in-app instructions to pair your camera with your Wi-Fi network.
2. **Wired Connection:** Connect an Ethernet cable from your router to the camera's Ethernet port.



Figure 3: Connectivity options. This image illustrates how the camera can be connected either wirelessly via Wi-Fi or through a wired internet cable to a router.

Operating Instructions

1. Motion Detection and Alerts

The camera features motion-activated recording and alerts. When motion is detected, the camera will begin recording and send a notification to your connected smartphone.



Figure 4: Motion detection and notification. This image shows the camera detecting movement with a red light, and a smartphone displaying a notification of the detected activity, along with a laptop showing live footage.

2. Night Vision Capabilities

The camera is equipped with advanced night vision. It can capture clear images in low-light conditions using infrared light, and can switch to color night vision when white light is activated upon motion detection.



Figure 5: Day and night vision modes. The image displays a clear color image during the day, a black and white infrared image at night, and a color image at night when motion is detected and white lights are activated, demonstrating the combination of infrared and white light for enhanced night vision.

3. Two-Way Audio

Utilize the camera's two-way audio feature to communicate through the camera. This allows you to speak to individuals near the camera and hear their responses via the mobile application.



Figure 6: Two-way audio functionality. This image highlights the camera's ability to support two-way audio communication, with sound waves emanating from and towards the camera, indicating both speaking and listening capabilities.

4. Remote Monitoring and Playback

Access live video feeds and review recorded footage remotely through the mobile application. Ensure a stable internet connection for seamless monitoring.

Maintenance

1. Cleaning the Camera

Regularly clean the camera lens and housing with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface or lens.

2. Waterproof Design

The camera is IP66 rated, making it resistant to dust and water splashes. While designed for outdoor use, avoid submerging the camera in water.



Figure 7: IP66 waterproof and dustproof rating. The image shows the camera being exposed to rain, illustrating its resistance to water and dust, suitable for outdoor environments.

3. Battery Replacement

Replace batteries when the low battery indicator appears in the app or on the camera. Always use fresh, high-quality batteries for optimal performance.

4. Firmware Updates

Check the mobile application periodically for available firmware updates. Keeping your camera's firmware updated ensures access to the latest features and improvements.

Troubleshooting

- **Camera not powering on:** Ensure batteries are correctly installed and fully charged. Check for any damage to the battery compartment.
- **No Wi-Fi connection:** Verify that the camera is within range of your 2.4GHz Wi-Fi network. Restart your router and the camera. Ensure correct Wi-Fi password entry in the app.
- **No recordings:** Check if the Micro SD card is properly inserted and has sufficient free space. Ensure motion detection is enabled in the app settings.
- **Poor image/video quality:** Clean the camera lens. Ensure there are no obstructions in the camera's field of view. Check network stability for live streaming quality.
- **Notifications not received:** Check your smartphone's app notification settings and ensure they are enabled for the camera application. Verify internet connectivity.

Specifications

Feature	Detail
Brand	Digitgarden
Model	32MP 1296P Wireless Trail Camera
Recommended Uses	Game & Trail
Connectivity Technology	Wireless (Wi-Fi)
Special Feature	Waterproof (IP66)
Compatible Devices	Smartphone (Android)
Mount Type	Wall Mount
Alert Type	Motion Only
Photo Sensor Resolution	2 MP
Video Capture Resolution	1296p
Power Source	Battery Powered
Video Capture Format	MPEG-4
Storage	Micro SD Card, Cloud Storage
Color	White
UPC	788495005891
ASIN	B08SBWG7FK

Warranty Information

Digitgarden products typically come with a limited warranty. Please refer to the product packaging or the official Digitgarden website for specific warranty terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or any questions regarding your Digitgarden Trail Camera, please contact our customer support team. You can usually find contact information on the official Digitgarden website or through your retailer's support channels.

- **Online Support:** Visit the official Digitgarden website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or website for the support email address.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08SBWG7FK

More documents and user manuals: **https://manuals.plus/**