FurReal F19265X1

FurReal Fuzzalots Puppy Interactive Pet: User Manual

Model: F19265X1

INTRODUCTION

The FurReal Fuzzalots Puppy is an interactive pet designed to express its moods through color changes and sounds. This manual provides essential information for setup, operation, and care to ensure an enjoyable experience with your new companion.

Image: The FurReal Fuzzalots Puppy, a small, fluffy brown and white toy, being gently petted on its head. A small blue bottle accessory is visible next to it.

PACKAGE CONTENTS

- 1 x FurReal Fuzzalots Puppy Interactive Pet
- 1 x Feeding Bottle Accessory
- 1 x AA Battery (pre-installed)

SETUP

1. Battery Installation

The FurReal Fuzzalots Puppy comes with one (1) AA battery pre-installed. If the toy does not respond or its lights and sounds are weak, the battery may need replacement.

1. Locate the battery compartment on the underside of the pet.
2. Using a Phillips head screwdriver (not included), open the battery compartment cover.
3. Remove the old AA battery and insert a new 1.5V AA alkaline battery, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Important: Always use fresh alkaline batteries. Do not mix old and new batteries, or different types of batteries.

OPERATING INSTRUCTIONS

The Fuzzalots Puppy expresses its feelings through various sounds and a color-changing light on its chest. Observe these cues to understand its needs.

Understanding Moods and Interactions:

- **Red Light: Hungry or Thirsty**

  When the puppy's chest glows red and it makes unhappy sounds, it indicates hunger or thirst. Use the included feeding bottle accessory to feed it. This will calm the pet, and its light will change to a contented color.

- **Blue Light: Sad, Scared, or Cranky**

  If the puppy's chest glows blue and it makes sounds indicating distress, it needs comfort. Gently pet its head to soothe it. The light will change, and the puppy will respond with happy sounds.

- **Other Interactions:**

  The puppy has over 25 sounds and reactions. Continue to interact with it by petting and feeding to discover all its responses and keep it happy.

MAINTENANCE

Cleaning Instructions:

- Surface clean only. Do not immerse the toy in water, as this can damage electronic components.
- Use a soft, damp cloth to wipe away dirt or stains.
- Allow the toy to air dry completely before further use.
- Do not use harsh chemicals or abrasive cleaners.

Storage:

When not in use for extended periods, remove the battery to prevent leakage and store the toy in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Toy is not responding or sounds are weak:**

  Check the battery. Replace with a fresh AA alkaline battery if necessary. Ensure the battery is inserted with correct polarity.

- **Lights are not changing color:**

  Ensure the toy is turned on and the battery has sufficient power. If the issue persists after replacing the battery, contact customer support.

- **Toy makes unexpected sounds or behavior:**

  Try turning the toy off and then on again. If the problem continues, replace the battery.

SPECIFICATIONS

Product Dimensions	5.5 x 3.12 x 5 inches
Item Weight	6.4 ounces
Item Model Number	F19265X1
Manufacturer Recommended Age	4 years and up
Batteries	1 AA battery (included)
Manufacturer	Hasbro
Release Date	July 1, 2021

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official FurReal website or contact Hasbro customer service directly. Details are typically provided on the product packaging or the manufacturer's official channels.
You can visit the FurReal Store for more information:FurReal Store