Grunkel MW-20

Grunkel MW-20 Microwave Oven User Manual

Model: MW-20

Important Safety Instructions

Please read these instructions carefully before installing and operating your microwave oven. Keep this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or injury.

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure the microwave is placed on a flat, stable surface with adequate ventilation.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Only use utensils suitable for microwave ovens.

Setup and Installation

Unpacking

Carefully remove the microwave oven from its packaging. Remove all packing materials, including any protective film or tape from the oven surfaces. Inspect the oven for any damage during transit. If any damage is found, do not operate the appliance and contact customer support.

Placement

Place the microwave oven on a flat, stable, heat-resistant surface. Ensure there is sufficient space around the oven for proper ventilation (at least 10 cm at the back and sides, and 20 cm above). Do not block any ventilation openings. Keep the oven away from heat sources, water, and high humidity areas.



Image: The Grunkel MW-20 microwave oven placed on a kitchen counter, illustrating its compact dimensions of approximately 45 cm width, 33 cm depth, and 24 cm height, highlighting its 20-liter capacity.

Turntable Assembly

Your microwave oven comes with a turntable ring and a glass tray. Place the turntable ring securely in the center of the oven cavity. Then, place the glass tray on top of the turntable ring, ensuring it sits properly in the center support.



Image: The interior of the Grunkel MW-20 microwave oven with the door open, showing the glass turntable with a diameter of 245 mm, designed for uniform cooking.

Electrical Connection

Ensure the voltage indicated on the rating label matches your household voltage. Plug the power cord into a grounded electrical outlet. Do not use extension cords or adapters.

Operating Instructions

The Grunkel MW-20 microwave oven features simple rotary controls for power level and cooking time.



Image: The control panel of the Grunkel MW-20 microwave oven, showing two rotary dials for power (up to 6 levels, 700W) and time (up to 30 minutes), along with icons for defrost function and audible signal.

Power Levels

This microwave oven offers up to 6 power levels, including a defrost setting, to suit various cooking needs. The maximum power output is 700W.

1. **Defrost:** For thawing frozen foods.
2. **Low:** For softening butter, melting chocolate, or simmering.
3. **Medium-Low:** For stews and delicate sauces.
4. **Medium:** For reheating and general cooking.
5. **Medium-High:** For faster cooking of denser foods.
6. **High (700W):** For rapid heating and boiling.

Setting Cooking Time

The mechanical timer allows you to set cooking times up to 30 minutes. To set the time, turn the timer knob clockwise to the desired duration. The oven will start automatically once the timer is set.

General Cooking Procedure

1. Place the food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. Turn the **Power** knob to select the desired power level.
4. Turn the **Timer** knob to set the desired cooking time.
5. The oven will begin cooking. An audible signal will sound when the cooking cycle is complete.
6. To stop cooking before the timer finishes, simply open the oven door. Close the door to resume, or turn the timer knob to '0' to cancel.

Defrost Function

To defrost food, turn the **Power** knob to the defrost setting (indicated by a snowflake icon). Then, set the desired defrosting time using the **Timer** knob. It is recommended to turn the food over periodically during defrosting for even results.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and efficient operation of your microwave oven.

Cleaning the Oven Interior

- Always unplug the microwave before cleaning.
- Wipe the interior cavity after each use with a damp cloth to remove food splatters. For stubborn stains, use a mild detergent or a microwave-safe cleaner.
- The glass turntable and turntable ring can be removed and washed in warm soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the interior surfaces.



Image: The interior of the Grunkel MW-20 microwave oven illuminated by its LED light, providing clear visibility for cleaning and inspection.

Cleaning the Oven Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- Clean the door and door seals regularly to ensure proper closure and prevent microwave leakage.
- Do not allow water to drip into the ventilation openings.



Image: The Grunkel MW-20 microwave oven with its door open, showcasing the ergonomic handle designed for easy and comfortable opening.

Troubleshooting

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Oven does not start.	Power cord not plugged in. Door not closed properly. Fuse blown or circuit breaker tripped.	Plug into outlet. Close door securely. Check fuse or reset circuit breaker.
Food not heating.	Power level set too low. Cooking time too short. Incorrect utensil used.	Increase power level or cooking time. Ensure microwave-safe dishes are used.
Turntable not rotating.	Turntable not correctly placed. Debris under turntable.	Ensure turntable and ring are correctly positioned. Clean under the turntable.
Unusual noise during operation.	Food container touching oven walls. Turntable not centered.	Adjust food container. Reposition turntable.

Problem	Possible Cause	Solution

If the problem persists after checking these solutions, please contact Grunkel customer support.

Specifications

Brand	Grunkel
Model Number	MW-20
Capacity	20 Liters
Power Output	700 Watts
Power Levels	Up to 6 (including Defrost)
Timer	Up to 30 minutes (mechanical)
Dimensions (W x D x H)	44.5 cm x 34 cm x 26.5 cm
Weight	10 kg
Material	Painted Metal
Special Features	Defrost function, LED interior lighting, Glass turntable (245mm diameter)
Included Components	Turntable ring, Glass turntable

Warranty and Support

For warranty information, technical assistance, or any questions not covered in this manual, please contact Grunkel customer support.
Keep your purchase receipt as proof of purchase for warranty claims.
You can find more information about Grunkel products and support on their official store: Grunkel Official Store

© 2024 Grunkel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question