NKF RMT-B115A

NKF RMT-B115A Remote Control Instruction Manual

For Sony Blu-ray DVD Players

Introduction

This manual provides essential instructions for the NKF RMT-B115A replacement remote control. This remote is designed to function as a direct replacement for original Sony Blu-ray DVD Player remotes, offering the same functionality without the need for complex programming.

Setup

The RMT-B115A remote control requires no programming or pairing. Simply install batteries, and it is ready for use with compatible Sony Blu-ray DVD Players.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, illustrating correct battery placement.

Operating Instructions

This remote control provides full functionality for compatible Sony Blu-ray DVD Players. The buttons on the remote correspond to the standard functions found on original Sony remotes.

Compatible Models

The RMT-B115A remote control is compatible with the following Sony Blu-ray DVD Player models:

- BDP-BX2
- BDP-BX57
- BDP-S360
- BDP-S470
- BDP-S560
- BDP-S570
- BDP-S580
- BDP-S760
- BDP-S2100
- BDP-BX58
- BDP-S480

Button Functions Overview



Image: Front view of the remote control, displaying all functional buttons.

- **OPEN/CLOSE:** Opens and closes the disc tray.
- **INPUT:** Selects the input source.
- **TV I/O (Power):** Turns the TV power on or off.
- **I/O (Power):** Turns the Blu-ray DVD Player power on or off.
- **Number Buttons (0-9):** For direct track selection or inputting numbers.
- **VOL +/-:** Adjusts the volume.
- **AUDIO:** Selects audio tracks or modes.
- **SUBTITLE:** Selects subtitle languages.
- **DISPLAY:** Shows on-screen information.
- **YELLOW, BLUE, RED, GREEN:** Color-coded function buttons, specific to disc content or menu options.
- **TOP MENU:** Accesses the disc's top menu.

- **POP UP/MENU:** Accesses the disc's pop-up menu.
- **RETURN:** Returns to the previous screen or menu.
- **OPTIONS:** Displays options menu.
- **HOME:** Accesses the player's home menu.
- **Navigation (Up, Down, Left, Right, Enter):** Navigates through menus and selections.
- **PREV (Previous):** Skips to the previous track/chapter.
- **PAUSE:** Pauses playback.
- **PLAY:** Starts or resumes playback.
- **NEXT:** Skips to the next track/chapter.
- **NETFLIX:** Direct access to the Netflix application.
- **STOP:** Stops playback.
- **QRIOCITY:** Direct access to the Qriocity service (may vary by region/model).

Maintenance

Proper care ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Always use new AAA alkaline batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

Troubleshooting

If you experience issues with your remote control, refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are correctly installed with the proper polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the Blu-ray DVD player's infrared sensor.
  - Ensure you are within the effective range and line of sight of the player.
- **Certain Functions Not Working:**
  - Verify that your Sony Blu-ray DVD player model is listed in the 'Compatible Models' section.
  - Some functions may be specific to certain disc content or player settings.

Specifications

Feature	Detail
Model Number	RMT-B115A
Product Dimensions	5.8 x 2 x 0.8 inches
Item Weight	2.8 ounces
Batteries Required	2 x AAA Alkaline Batteries

Manufacturer	NKF
Color	Black
Special Feature	Ergonomic Design
Max Supported Devices	1

Customer Support

For any questions or concerns regarding your NKF RMT-B115A remote control, please contact the seller directly. We are committed to resolving any issues you may encounter.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question