Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung WW80T936ASH

Samsung QuickDrive 8000-series Washing Machine

Model: WW80T936ASH

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Samsung QuickDrive 8000-series WW80T936ASH washing machine. Please read these instructions thoroughly before using the appliance and retain them for future reference.



Figure 1: Front view of the Samsung QuickDrive 8000-series WW80T936ASH washing machine.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Ensure the power cord is not damaged and is properly grounded.
- Do not install or store the appliance where it will be exposed to temperatures below freezing or exposed to the weather.
- Do not wash items that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances.
- Keep children and pets away from the appliance during operation.

Setup and Installation

Proper installation is crucial for the performance and longevity of your washing machine. Refer to the following steps for correct setup.

1. **Unpacking:** Remove all packaging materials, including the shipping bolts from the rear of the machine. Keep the bolts for future transport.
2. **Location:** Place the washing machine on a firm, level floor. Ensure there is adequate space around the machine for ventilation and maintenance. Avoid direct sunlight or areas with high humidity.
3. **Leveling:** Use a spirit level to ensure the machine is perfectly level. Adjust the leveling feet at the bottom of the machine as needed. A stable machine reduces vibration and noise during operation.
4. **Water Supply Connection:** Connect the hot and cold water inlet hoses to the corresponding hot and cold water taps. Ensure connections are tight to prevent leaks.
5. **Drain Hose Connection:** Securely attach the drain hose to a standpipe or laundry tub, ensuring it is properly routed to prevent kinks. The drain hose should be positioned at a height between 60 cm and 90 cm from the floor.
6. **Power Connection:** Plug the power cord into a grounded electrical outlet. Do not use extension cords or adapters.



Figure 2: Rear view of the washing machine with hose connections.

Operating Instructions

Follow these steps to operate your Samsung QuickDrive washing machine effectively.

Control Panel Overview



Figure 3: Control panel with program dial and display.

- **Power Button:** Turns the washing machine on or off.
- **Program Dial:** Rotate to select desired wash cycle (e.g., Eco 40-60, SuperSpeed 39').
- **Display:** Shows cycle information, remaining time, and error codes.
- **Start/Pause Button:** Starts or pauses the selected wash cycle.
- **Option Buttons:** Customize wash settings such as temperature, rinse count, and spin speed.

Loading Laundry

1. Open the washing machine door.
2. Load laundry into the drum, ensuring not to overload. Leave enough space for clothes to tumble freely. The capacity is 8 kg.
3. Close the door firmly.



Figure 4: Washing machine with door open, ready for loading.

Adding Detergent and Softener

1. Pull out the detergent drawer located on the top left of the control panel.
2. Add the appropriate amount of detergent to the main wash compartment (II).
3. Add fabric softener to the softener compartment (flower symbol).
4. Push the detergent drawer back in until it clicks. This model features a dual-compartment auto-dosing system for convenience.



Figure 5: Detergent dispenser drawer.

Selecting and Starting a Wash Cycle

1. Press the **Power** button to turn on the machine.
2. Rotate the **Program Dial** to select your desired wash cycle. Available cycles include QuickDrive, AI Wash, and SuperSpeed 39'.
3. Adjust cycle options (temperature, rinse, spin speed) using the corresponding buttons if needed.
4. Press the **Start/Pause** button to begin the wash cycle.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

- **Cleaning the Detergent Drawer:** Periodically remove the detergent drawer and rinse it under running water to remove any detergent residue.
- **Cleaning the Drum:** Run a 'Drum Clean' cycle (if available) or a hot wash with no laundry and a cup of white vinegar or a washing machine cleaner to prevent odors and residue buildup.
- **Cleaning the Drain Filter:** Locate the drain filter at the bottom front of the machine. Open the cover, drain any residual water, and unscrew the filter. Clean it thoroughly and reinsert. Perform this every few months.
- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Troubleshooting

Refer to this section for solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Washing machine does not start	Power cord unplugged; Door not closed properly; Start/Pause button not pressed.	Check power connection; Ensure door is latched; Press Start/Pause.
Water not draining	Drain hose kinked or blocked; Drain filter clogged.	Check drain hose for obstructions; Clean the drain filter.
Excessive vibration/noise	Machine not level; Shipping bolts not removed; Overloaded drum.	Adjust leveling feet; Remove shipping bolts; Reduce laundry load.
Detergent residue in dispenser	Detergent drawer clogged; Insufficient water pressure.	Clean the detergent drawer; Check water supply and pressure.

If the problem persists after attempting these solutions, please contact Samsung customer support.

Specifications

Key technical specifications for the Samsung QuickDrive 8000-series WW80T936ASH washing machine:

- **Model Number:** WW80T936ASH/S2
- **Capacity:** 8 Kilograms
- **Maximum Spin Speed:** 1600 RPM
- **Voltage:** 230 VAC
- **Access Location:** Front-loader
- **Drum Material:** Steel
- **Weight:** 79000 Grams (79 kg)
- **Included Components:** Samsung WW80T936ASH unit
- **Cycle Options:** Eco, QuickDrive, AI Wash, SuperSpeed 39'
- **Detergent Dispenser:** Dual-compartment with auto-dosing

Warranty and Support

Your Samsung QuickDrive 8000-series WW80T936ASH washing machine comes with a manufacturer's warranty. Specific warranty details are typically provided at the point of purchase or within the product packaging. Please retain your proof of purchase for warranty claims.
For technical assistance, service requests, or further information, please visit the official Samsung support website or contact their customer service directly. You can find contact details on the Samsung website or in the documentation provided with your appliance.

© 2023 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08SRHSD9D

More documents and user manuals: **https://manuals.plus/**