SagaSave Vinyl Cutter Blades Set with Blade Holder

SagaSave Tungsten Steel Vinyl Cutter Blades and Holder Instruction Manual

Model: Vinyl Cutter Blades Set with Blade Holder

1. Introduction

This manual provides instructions for the proper use, setup, and maintenance of your SagaSave Tungsten Steel Vinyl Cutter Blades and Blade Holder. This set is designed for precision cutting with most standard cutting plotters.

2. Product Components

The SagaSave Vinyl Cutter Blades set includes the following items:

- 5 x 30° Tungsten Steel Blades (Blue cap)
- 5 x 45° Tungsten Steel Blades (Red cap)
- 5 x 60° Tungsten Steel Blades (Yellow cap)
- 1 x Aluminum Alloy Cutting Plotter Blade Holder



Image 2.1: Overview of the SagaSave 15-piece Tungsten Steel Vinyl Cutter Blades set, including the blade holder and blades with colored protective caps (blue, red, yellow).



Image 2.2: Close-up view of the individual SagaSave vinyl cutter blades, showing the different angles (30°, 45°, 60°) indicated by their respective colored caps (blue for 30°, red for 45°, yellow for 60°).



Image 2.3: Detailed view of the SagaSave aluminum alloy blade holder and a single tungsten steel blade, illustrating how the blade fits into the holder mechanism.

3. Specifications

Component	Detail
Blade Material	Tungsten Steel
Blade Holder Material	Aluminum Alloy (surface oxidation)
Blade Angles	30°, 45°, 60° (5 pieces each)

Blade Handle Diameter	2mm
Blade Overall Length	23.5mm
Blade Tip Diameter	1.0mm
Plotter Holder Size	45 x 29 x 11mm
Compatibility	Roland and most domestic and imported plotters

4. Setup

Follow these steps to prepare your blades and holder for use with a cutting plotter:

1. **Select the Appropriate Blade:** Choose the blade angle (30°, 45°, or 60°) suitable for your cutting material and design complexity. Refer to Section 5 for guidance on blade selection.
2. **Remove Protective Cap:** The blades are shipped with a rubber protective cap. Carefully pull the blade out of its cap to expose the sharp tip. *Exercise caution as the blade tips are extremely sharp.*
3. **Insert Blade into Holder:** Unscrew the bottom part of the blade holder. Insert the selected blade into the opening, ensuring it seats properly.
4. **Adjust Blade Exposure:** Screw the bottom part of the holder back on. Adjust the blade exposure by turning the knurled golden ring on the holder. The blade tip should protrude just enough to cut through your material without scoring the cutting mat excessively. A common method is to set the blade exposure so that it barely touches the material surface when the holder is placed flat.
5. **Install Holder into Plotter:** Refer to your cutting plotter's instruction manual for specific steps on how to install the blade holder into the plotter's carriage.

5. Operating Instructions

The choice of blade angle is crucial for achieving optimal cutting results. Different angles are suited for various materials and design details:




Image 5.1: Illustrative diagram detailing the recommended applications for 30°, 45°, and 60° cutting plotter blades based on material thickness and font size.

- **30° Blades (Blue Cap):**
  Ideal for cutting large fonts, thick materials (approximately 1mm), and reflective materials or masking tapes. The shallower angle provides more stability for thicker media.
- **45° Blades (Red Cap):**
  Suitable for normal fonts and materials up to 1mm thick, such as vinyl for traffic signs. This is a general-purpose blade for a wide range of applications.
- **60° Blades (Yellow Cap):**
  Best for small fonts and very thin materials (up to 0.5mm), including various thin vinyls. The steeper angle allows for finer detail and sharper turns.

Always perform a test cut on a scrap piece of your material to verify blade exposure and cutting pressure settings before starting your main project.

6. Maintenance

- **Cleaning:** After use, gently clean any material residue from the blade tip and holder. Use a soft brush or compressed air. Avoid using harsh chemicals.
- **Storage:** Always store blades with their protective rubber caps on to prevent accidental injury and to protect the blade tip from damage. Store the blades and holder in a dry, safe place away from children.
- **Replacement:** Replace blades when you notice a decrease in cutting quality, such as ragged edges, skipped cuts, or difficulty cutting through materials that were previously easy.

7. Safety Precautions

- **Sharp Edges:** Blades are extremely sharp. Handle with extreme care to avoid cuts and injuries.
- **Protective Caps:** Always use the protective rubber caps when blades are not in use or during storage.
- **Keep Away from Children:** Store all components out of reach of children and pets.

- **Proper Disposal:** Dispose of dull or broken blades responsibly in a puncture-proof container.

8. Troubleshooting

- **Poor Cut Quality:**
  - Check blade exposure: Adjust the blade to protrude slightly more.
  - Check blade sharpness: Replace the blade if it appears dull or damaged.
  - Verify cutting pressure: Adjust the pressure settings on your cutting plotter.
  - Ensure material is flat: Make sure the vinyl or material is securely adhered to the cutting mat and free of bubbles or wrinkles.
- **Blade Not Cutting:**
  - Confirm blade is properly inserted into the holder.
  - Increase blade exposure.
  - Increase cutting pressure.
  - Check if the blade is broken or severely dull.
- **Blade Dragging/Skipping:**
  - Reduce blade exposure.
  - Decrease cutting pressure.
  - Clean the blade tip of any debris.
  - Ensure the blade holder rotates freely.

9. Warranty and Support

Information regarding specific warranty terms for SagaSave products is not provided in this manual. For warranty claims, technical support, or further assistance, please refer to the retailer where the product was purchased or contact SagaSave customer service directly through their official channels.

© 2023 SagaSave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question