Rexel 2020600XEU

Rexel Auto+ 600X Automatic Cross-Cut Shredder

USER MANUAL

Introduction

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Rexel Auto+ 600X Automatic Cross-Cut Shredder. Please read this manual thoroughly before using the shredder and keep it for future reference.

The Rexel Auto+ 600X is designed for secure disposal of confidential documents, offering both automatic and manual shredding capabilities for various materials.

Setup

1. **Unpacking:** Carefully remove the shredder from its packaging. Ensure all packing materials are removed from inside the shredder and the waste bin. Inspect the shredder for any signs of damage during transit. If damaged, do not operate and contact your supplier.





Image: The Rexel Auto+ 600X shredder with its waste bin door open, showing the internal mechanism and the large capacity bin. This view highlights the overall design and the accessibility of the bin for emptying.

2. **Placement:** Position the shredder on a flat, stable surface. The shredder is equipped with swivel casters for easy movement. Ensure there is adequate space around the unit for ventilation and access to the waste bin.
3. **Waste Bin Installation:** Ensure the 110-liter removable waste bin is correctly inserted into the shredder. The shredder will not operate if the bin is not properly seated or if the bin door is open.



Image: The Rexel Auto+ 600X shredder with a graphic indicating its 110-liter waste bin capacity. The bin door is slightly ajar, emphasizing its removable nature and large volume for shredded material.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The shredder is designed for use with standard electrical supplies.

Operating Instructions

Automatic Shredding

The Auto+ 600X features an automatic feed mechanism, allowing you to load a stack of documents and let the shredder do the work. This saves significant time compared to manual feeding.

- **Capacity:** The shredder can automatically shred up to 600 sheets of A4 (80gsm) paper at once.
- **Loading:** Open the automatic feed tray and carefully place the stack of documents into the tray. Ensure the paper is aligned properly.
- **Operation:** Close the automatic feed tray. The shredder will automatically detect the paper and begin shredding.



Image: A close-up view of the Rexel Auto+ 600X shredder's automatic feed tray, showing a stack of paper ready for shredding. Overlays indicate a 600-sheet capacity and P4 cross-cut security level, demonstrating its high volume and security features.

Manual Shredding

For smaller quantities of paper or other materials, use the manual feed slot.

- **Capacity:** The manual feed slot can shred up to 15 sheets of A4 paper simultaneously.
- **Accepted Materials:** In addition to paper, the manual feed can shred credit cards, paper clips, and staples.
- **Feeding:** Insert the material into the manual feed slot. The shredder will detect the material and begin shredding.



Image: The Rexel Auto+ 600X shredder with a stack of 15 A4 sheets being fed into the manual shredding slot. This illustrates the shredder's capability for smaller, quick shredding tasks.



Image: A front view of the Rexel Auto+ 600X shredder, featuring icons that indicate its ability to shred paper clips, staples, and credit cards. This highlights the versatility of the shredder beyond just paper.

Features and Indicators

- **Anti-Jam System:** The shredder is equipped with an anti-jam system to prevent paper jams. If a jam occurs, the shredder will attempt to clear it automatically.

- **Infrared Fill Level Sensor:** An infrared sensor monitors the waste bin's fill level, indicating when it needs to be emptied to prevent overfilling.
- **Touch Interface:** The intuitive touch interface provides easy control over the shredder's functions.
- **Run Time:** The shredder has a continuous run time of 240 minutes (4 hours), suitable for high-volume shredding tasks.



Image: The Rexel Auto+ 600X shredder with a graphic indicating a 4-hour continuous run time. This emphasizes the shredder's capability for extended operation, ideal for large shredding jobs.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your shredder.

- **Emptying the Waste Bin:** When the infrared fill level sensor indicates the bin is full, or when shredding is complete, open the bin door and remove the 110-liter waste bin. Dispose of the shredded material responsibly. Reinsert the bin securely.
- **Cleaning the Shredder Head:** Periodically clean the shredder head to remove paper dust and debris. Use a soft brush or cloth. Ensure the shredder is unplugged before cleaning.
- **Oiling the Cutters:** For cross-cut shredders, regular oiling of the cutting blades is recommended to maintain performance and prevent wear. Apply shredder oil across the paper entry slot while the shredder is running in reverse (if applicable, or as per specific instructions for your model). Refer to the manufacturer's recommended oiling frequency.
- **Fan Cooling System:** The integrated fan cooling system helps maintain optimal operating temperature during extended use. Ensure the ventilation slots are not obstructed.

Troubleshooting

This section addresses common issues you might encounter with your shredder.

Problem	Possible Cause	Solution
Shredder does not turn on.	No power, bin not properly inserted, bin door open.	Check power connection. Ensure waste bin is fully inserted and the bin door is closed.
Paper jam.	Overfeeding, stapled/clipped paper (if not designed for it), material too thick.	Reduce paper quantity. Use reverse function to clear jam. If persistent, unplug and carefully remove jammed paper.
Shredder stops during operation.	Overheat protection activated, waste bin full.	Allow shredder to cool down (usually 20-30 minutes). Empty the waste bin.
Shredded material not falling into bin.	Bin full, shredder head clogged.	Empty the waste bin. Clean the shredder head and cutters.

Specifications

- **Model:** Rexel Auto+ 600X (2020600XEU)
- **Shred Type:** Cross-Cut
- **Security Level:** P4
- **Automatic Sheet Capacity:** 600 sheets (A4, 80gsm)
- **Manual Sheet Capacity:** 15 sheets (A4, 80gsm)
- **Waste Bin Capacity:** 110 Liters
- **Continuous Run Time:** 240 minutes (4 hours)
- **Shreds:** Paper, Credit Cards, Paper Clips, Staples
- **Dimensions (W x H x D):** 510 mm x 960 mm x 570 mm
- **Weight:** 39 Kilograms

- **Special Features:** Anti-Jam System, Swivel Casters, Fan Cooling System, Infrared Fill Level Sensor, Touch Interface



Image: The Rexel Auto+ 600X shredder shown with its key dimensions labeled: 1030 mm height, 510 mm width, and 590 mm depth. This provides a clear visual reference for its physical size.

Warranty and Support

Your Rexel Auto+ 600X Automatic Cross-Cut Shredder comes with a**2-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your shredder, please contact Rexel customer service or your local dealer. Keep your proof of purchase for warranty validation.

For more information, visit the official Rexel website or refer to the contact details provided with your product packaging.

© 2023 Rexel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question