LEXiBOOK MP320PAZ

Lexibook Paw Patrol Portable Karaoke Digital Player - User Manual

Model: MP320PAZ

Introduction

Welcome to the world of musical fun with your new Lexibook Paw Patrol Portable Karaoke Digital Player! This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly to ensure safe and optimal use of your karaoke player.

Safety Information

This product is designed for children aged 3 years and up. Adult supervision is recommended during use. Please observe the following safety guidelines:

- Do not expose the device to water or excessive moisture.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the provided USB-C cable for charging.
- Keep small parts, such as micro SD cards, out of reach of very young children to prevent choking hazards.
- Do not attempt to disassemble or repair the device yourself. Contact qualified personnel for service.
- Ensure proper ventilation when charging.

Product Overview and Features

The Lexibook Paw Patrol Portable Karaoke Digital Player is designed for interactive musical entertainment. Key features include:

- **Wireless Bluetooth Connectivity:** Connect wirelessly to Bluetooth-equipped devices for streaming music.
- **Dual Microphones:** Two microphones are included, allowing for duets and shared singing experiences.
- **Multiple Audio Inputs:** Features AUX-IN slots, a USB port, and TF/micro SD card slots (up to 32 GB) for versatile music playback from external audio devices.
- **Headphones Jack:** For private listening.
- **Record Function:** Record your singing performances.
- **Voice Changer Function:** Enjoy hours of fun with three voice tunes: high pitched, deep pitched, or echo voice.

- **Multicolour Light Effects:** Dynamic light effects enhance the karaoke experience.
- **Rechargeable Battery:** Equipped with a 1,200 mAh rechargeable battery, charged via USB-C.
- **Storage Compartment:** Conveniently store cables and accessories.



Front view of the Lexibook Paw Patrol Portable Karaoke Digital Player, showcasing the main unit with two attached microphones and Paw Patrol characters on the display.



The karaoke player demonstrating its multicolour light effects, illuminating the Paw Patrol characters on the front panel.



Close-up view highlighting the voice changer and recording function buttons on the karaoke player's control panel.

Package Contents

Please check the box for the following items:

- 1 x Lexibook Paw Patrol Portable Karaoke Digital Player
- 2 x Microphones
- 1 x USB-C Charging Cable
- 1 x AUX-IN Cable (if included, check packaging)
- User Manual (this document)



The product packaging, showing the karaoke player and its accessories clearly visible inside the box.

Setup

1. Charging the Battery

1. Locate the USB-C charging port on the back of the karaoke player.
2. Connect the provided USB-C cable to the player and the other end to a compatible USB power adapter (not included) or a computer's USB port.
3. Allow the device to charge fully before first use. The charging indicator light (if present) will change or turn off when charging is complete.

2. Connecting Microphones

1. Insert the microphone cables into the designated microphone jacks on the sides of the player.
2. Ensure the plugs are fully inserted for proper connection.

3. Powering On/Off

1. Locate the Power button, usually on the control panel or side of the device.
2. Press and hold the Power button for a few seconds to turn the player ON or OFF.



Rear view of the karaoke player, indicating the locations of the USB port, AUX-IN jack, headphone jack, and micro SD card slot.

Operating Instructions

1. Bluetooth Connection

1. Turn on the karaoke player. It will automatically enter Bluetooth pairing mode.
2. On your Bluetooth-enabled device (e.g., smartphone, tablet), go to Bluetooth settings and search for available devices.
3. Select "LEXIBOOK KARAOKE" or a similar name from the list to pair.
4. Once paired, you can play music from your device through the karaoke player.



The karaoke player shown wirelessly connected to a smartphone via Bluetooth, illustrating music streaming capability.

2. Using AUX-IN, USB, and TF/Micro SD Card Slots

- **AUX-IN:** Connect an external audio device (e.g., MP3 player) using a 3.5mm audio cable to the AUX-IN jack.
- **USB Port:** Insert a USB flash drive containing MP3 music files into the USB port.
- **TF/Micro SD Card:** Insert a TF (TransFlash) or micro SD card (up to 32 GB) with MP3 music files into the designated slot.
- Use the "MODE" button on the player to switch between input sources (Bluetooth, AUX, USB, TF/Micro SD).

3. Recording Function

1. Ensure a TF/micro SD card or USB drive is inserted for storage.
2. Press the "REC" button to start recording your singing.
3. Press "REC" again to stop recording. Your recording will be saved to the inserted storage device.

4. Voice Changer Function

- Activate the voice changer by pressing the dedicated voice changer button (often indicated by a microphone icon with an arrow).
- Press repeatedly to cycle through the available voice effects: high pitched, deep pitched, and echo voice.

5. Multicolour Light Effects

- The player features integrated multicolour light effects that activate during playback.
- There may be a dedicated button (often a lightbulb icon) to turn these effects ON or OFF.

6. Character Selector (Paw Patrol)

- Rotate the central dial or press the character selection buttons to change the displayed Paw Patrol character.

- Each character selection may trigger unique sounds, phrases, or songs related to that character.

Maintenance

Proper care will extend the life of your karaoke player:

- **Cleaning:** Wipe the surface of the player with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge it regularly, even if not in constant use.
- **Cable Management:** Utilize the built-in storage compartment for cables to prevent tangling and damage.



The open back compartment of the karaoke player, showing space for storing cables and small accessories.

Troubleshooting

Problem	Possible Cause	Solution
Player does not turn on.	Low battery; Power button not pressed correctly.	Charge the battery fully. Press and hold the Power button firmly.
No sound from microphones.	Microphones not properly connected; Volume too low.	Ensure microphones are fully plugged in. Increase the volume using the '+' button.
Bluetooth connection fails.	Player not in pairing mode; Device too far; Interference.	Ensure player is in Bluetooth mode. Move devices closer. Restart both devices.

Problem	Possible Cause	Solution
Cannot play music from USB/SD card.	Incorrect file format (only MP3 supported); Card/drive not inserted correctly; Corrupted files.	Ensure files are MP3. Reinsert card/drive. Try a different card/drive.
Voice changer not working.	Function not activated; Microphone not active.	Press the voice changer button. Ensure microphone is on and connected.

Specifications

Feature	Detail
Brand	LEXiBOOK
Model Number	MP320PAZ
Product Dimensions	3.19 x 10.98 x 8.35 inches
Item Weight	1.2 pounds
Power Source	1,200 mAh Rechargeable Lithium Ion Battery (via USB-C)
Connectivity	Bluetooth, AUX-IN, USB, TF/Micro SD Card Slot
Supported Media	MP3 (from USB/TF/Micro SD)
Recommended Age	3 years and up
Color	Blue/Red

Warranty and Support

This Lexibook product comes with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Lexibook website. For technical support, troubleshooting assistance, or replacement parts, please contact Lexibook customer service through their official channels.
You can find more information and contact details on the LEXiBOOK Store on Amazon.

© 2024 Lexibook. All rights reserved. Paw Patrol © ™ Spin Master Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question