**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**HCDZ CT-LED2, CT-1590N, CT-1514N, CT-1514S, CT-1582S, CT-1584S, CT-13, CT-15115, CT-1511S, CT-138S, CT-1315N, CT-1315S**

# HCDZ Replacement Remote Control User Manual

For ClearTunes CT-LED2, CT-1590N, CT-1514N, CT-1514S, CT-1582S, CT-1584S, CT-13, CT-15115, CT-1511S, CT-138S, CT-1315N, CT-1315S LED TVs

## Introduction

This manual provides instructions for the HCDZ Replacement Remote Control, designed for various ClearTunes LED TV models. This remote control is an infrared (IR) replacement unit and requires no programming. Simply insert batteries, and it is ready for use.

## Setup: Battery Installation

The remote control requires **two AAA batteries** (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



*Image: Back of the remote control with the battery cover removed, illustrating the battery compartment.*

**Important:**

- Do not mix new and old batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.

## Operating Instructions

This HCDZ replacement remote control is designed to work immediately with compatible ClearTunes LED TV models once batteries are installed. No additional programming or setup is required.

1. Ensure fresh batteries are correctly installed in the remote control.
2. Point the remote control directly at the infrared sensor on your ClearTunes LED TV.
3. Press the desired function button (e.g., Power, Volume Up/Down, Channel Up/Down) to operate your television.



*Image: Back of the remote control, illustrating the sealed battery compartment after installation.*

## Maintenance and Care

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place. Avoid exposing it to direct sunlight, extreme heat, or high humidity.
- **Battery Replacement:** Replace all batteries with new ones when the remote's performance degrades.
- **Environmental Factors:** Do not expose the remote sensor to direct sunlight or strong lighting apparatuses, as this may cause malfunction.

## Troubleshooting

If the remote control is not functioning as expected, consider the following:

- **Check Batteries:** Ensure batteries are inserted correctly with the proper polarity (+/-) and are not depleted. Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the TV's infrared sensor. Obstructions can block the signal.
- **Remote Sensor:** Ensure the TV's infrared sensor is not blocked or dirty.
- **Distance:** Operate the remote within a reasonable distance from the TV.
- **TV Compatibility:** Verify that your ClearTunes LED TV model is listed as compatible with this HCDZ replacement remote control.

## Specifications

| Feature | Detail |
| --- | --- |
| Brand | HCDZ |
| Connectivity Technology | Infrared (IR) |

| | |
|---|---|
| Compatible Devices | ClearTunes LED Televisions (CT-LED2, CT-1590N, CT-1514N, CT-1514S, CT-1582S, CT-1584S, CT-13, CT-15115, CT-1511S, CT-138S, CT-1315N, CT-1315S) |
| Max Number of Supported Devices | 1 |
| Special Feature | No programming needed, works out of package |
| Batteries Required | 2 x AAA batteries (not included) |
| Item Weight | 1.6 ounces |
| Package Dimensions | 3 x 2 x 1 inches |

## Warranty and Support

Information regarding product warranty or customer support for this HCDZ replacement remote control is not provided in this manual. Please refer to the product packaging or contact the retailer for details on warranty coverage and support options.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B08TWQTM7F**

More documents and user manuals: **https://manuals.plus/**