**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Braun EP325SI**

# Braun Food Processor 12-in-1 Model EP325SI User Manual

Your comprehensive guide to safe and efficient operation

## 1. Introduction

Congratulations on your purchase of the Braun Food Processor 12-in-1, Model EP325SI. This versatile kitchen appliance is designed to simplify your meal preparation with its powerful 800W motor and a wide range of functions including chopping, slicing, grating, blending, juicing, and dough kneading. Please read this manual carefully before first use to ensure safe operation and optimal performance of your appliance. Keep this manual for future reference.

## 2. Important Safety Instructions

**Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.**

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or other liquids. Clean with a damp cloth only.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts. Keep hands and utensils away from cutting blades during operation to prevent injury and/or damage to the food processor.
- Do not use the appliance for anything other than its intended use.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or adjustment.
- Do not use outdoors.
- Always ensure the lid is securely locked in place before operating the appliance.
- Blades are sharp. Handle with care.

## 3. Package Contents

Your Braun Food Processor 12-in-1 comes with a variety of components to assist with all your culinary needs. Please check that all items are present:

- Motor Unit (Base)
- 2.1 Liter Food Processor Bowl
- Food Processor Lid with Pusher
- Universal Blade (Chopping/Mixing)
- Dough Tool
- Slicing/Grating Discs (Fine, Coarse, Julienne)
- 1.2 Liter Blender Jug with Lid
- Citrus Juicer Attachment (Cone and Strainer)
- Juice Extractor Attachment
- Multi-mill (Grinder)




*Image 1: All components of the Braun Food Processor 12-in-1, Model EP325SI.*

# 4. Product Overview and Setup

Familiarize yourself with the main parts of your food processor before assembly.

## 4.1 Main Components

1. **Motor Unit:** The base containing the motor and control panel.
2. **Control Panel:** Features speed settings (1, 2) and a Pulse function.
3. **Food Processor Bowl:** Main processing bowl with a handle.

4. **Lid with Feeder Tube:** For the food processor bowl, with an opening to add ingredients.
5. **Pusher:** Used to guide ingredients through the feeder tube.

### 4.2 Initial Setup

1. Place the motor unit on a clean, dry, and stable surface.
2. Ensure the appliance is unplugged from the power outlet.
3. Wash all detachable parts (bowls, lids, blades, discs, attachments) in warm soapy water, rinse thoroughly, and dry. The motor unit should only be wiped with a damp cloth.




*Image 2: Braun Food Processor assembled with the main processing bowl.*

## 5. Operating Instructions

Your food processor features two speed settings (1 and 2) and a Pulse function (P). Speed 1 is for lighter tasks, Speed 2 for heavier loads, and Pulse provides short bursts of maximum power for better control.

## 5.1 Food Processor (Chopping, Slicing, Grating)

1. Place the food processor bowl onto the motor unit and turn clockwise until it locks.
2. Insert the desired blade (universal blade for chopping) or disc (for slicing/grating) onto the central spindle.
3. Add ingredients to the bowl. For slicing/grating, place ingredients into the feeder tube.
4. Secure the lid onto the bowl and turn clockwise until it locks.
5. Plug in the appliance and select the desired speed (1, 2, or P).
6. After processing, switch off, unplug, and carefully remove the lid and blade/disc before emptying the bowl.




*Image 3: Food processor bowl with salad ingredients ready for processing.*

## 5.2 Blender

1. Ensure the blender jug is securely assembled with its blade unit.
2. Place the blender jug onto the motor unit and turn clockwise until it locks.
3. Add ingredients to the jug (do not exceed the MAX fill line).
4. Secure the blender lid.
5. Plug in and select the desired speed (typically Speed 2 or Pulse for blending).
6. After blending, switch off, unplug, and carefully remove the jug.




*Image 4: Blender jug filled with fruits for a smoothie.*

## 5.3 Citrus Juicer

1. Place the food processor bowl onto the motor unit.
2. Insert the citrus juicer strainer into the bowl, then place the juicer cone onto the spindle.
3. Plug in the appliance.
4. Press a halved citrus fruit onto the rotating cone to extract juice. The juice will collect in the bowl.
5. After juicing, switch off, unplug, and disassemble.




*Image 5: Citrus juicer attachment ready for use.*

## 5.4 Juice Extractor

1. Place the food processor bowl onto the motor unit.
2. Insert the juice extractor basket and lid onto the bowl.
3. Place a glass or container under the juice spout.
4. Plug in and select Speed 2.
5. Feed fruits or vegetables into the feeder tube using the pusher.
6. After extraction, switch off, unplug, and disassemble.




*Image 6: Juice extractor attachment in operation.*

### 5.5 Dough Making

1. Place the food processor bowl onto the motor unit.
2. Insert the dough tool onto the central spindle.
3. Add dry ingredients to the bowl, then gradually add liquids through the feeder tube while the appliance is running.
4. Secure the lid. Plug in and select Speed 1 or 2, or use the Pulse function for mixing.
5. Process until the dough forms a ball. Do not over-process.

## 6. Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Braun Food Processor.

- **Always unplug the appliance** before cleaning.

- **Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse it in water or any other liquid.
- **Detachable Parts:** All detachable parts (bowls, lids, blades, discs, attachments) are dishwasher-safe (top rack recommended) or can be washed by hand in warm soapy water. Rinse thoroughly and dry.
- **Blades and Discs:** Handle with extreme care as they are very sharp. Use a brush to clean if necessary.
- **Storage:** Store the appliance and its accessories in a dry place, out of reach of children.

## 7. Troubleshooting

If you encounter any issues with your food processor, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not start | Not plugged in; Bowl/lid not correctly locked; Overload protection activated. | Check power connection; Ensure bowl and lid are securely locked; Unplug, wait 15 minutes, reduce load, then restart. |
| Poor processing results | Too much/too little food; Incorrect speed; Ingredients too large. | Adjust quantity; Use appropriate speed/pulse; Cut ingredients into smaller pieces. |
| Motor stops during operation | Overload protection activated. | Switch off, unplug, remove some ingredients, wait 15 minutes, then restart. |

## 8. Specifications

| Feature | Detail |
|---|---|
| Model | EP325SI (also known as FP3235SI) |
| Power | 800 W |
| Voltage | 220 V |
| Food Processor Bowl Capacity | 2.1 Liters |
| Blender Jug Capacity | 1.2 Liters |
| Speed Settings | 2 Speeds + Pulse Function |
| Material | Plastic (BPA-free food contact parts) |
| Dishwasher Safe Parts | Yes (all detachable parts) |
| Dimensions (D x W x H) | 34 x 53 x 38 cm |
| Weight | 8.2 kg |

## 9. Warranty and Support

Your Braun Food Processor 12-in-1, Model EP325SI, is covered by a**2-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for any warranty claims.
For technical support, service, or to inquire about spare parts, please visit the official Braun website or contact your local

Braun service center. You can find more information and contact details at: Braun Household Support

© 2023 Braun. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B08V11HCW8**

More documents and user manuals: **https://manuals.plus/**