GAERUO Electric Trimmer and Shaver

GAERUO Electric Trimmer and Shaver User Manual

Model: Electric Trimmer and Shaver

1. Important Safety Information

Read all instructions before using this appliance. Keep this manual for future reference.

- This appliance is designed for trimming and shaving facial and body hair. Do not use for any other purpose.
- The appliance is **IPX7 waterproof** and suitable for wet or dry use, including in the shower. However, do not immerse the charging cable or adapter in water.
- Keep the appliance away from children.
- Do not use the appliance if the blade is damaged or broken, as this may cause injury.
- Only use the charging cable provided with the appliance.
- Ensure the appliance is fully dry before connecting it to the charger.



Image: The GAERUO Electric Trimmer is IPX7 waterproof, allowing for safe wet and dry use and easy cleaning under running water.

2. Product Overview

The GAERUO Electric Trimmer and Shaver is designed for versatile grooming with precision and comfort.

Key Features:

- **Dual-Sided Blade:** Features a stainless steel, self-sharpening dual-sided blade for efficient trimming and edging.
- **Contour Following System:** The removable head adjusts to facial and body contours for a close and comfortable shave.
- **IPX7 Waterproof:** Fully washable for easy cleaning and safe wet or dry use.
- **Powerful Motor:** Equipped with a high-performance motor operating at 5500 RPM for effective hair removal with low noise.

- **Rechargeable Battery:** Long-lasting Li-ion battery with quick charge capability via USB.
- **Comb Attachments:** Includes 1mm, 3mm, and 5mm comb guides for varying hair lengths.



Image: Overview of the GAERUO Electric Trimmer's multi-functional design and features.



Image: Detail of the dual-sided blade and the intelligent contour following system.

3. Setup

3.1 Charging the Trimmer

Before first use, fully charge the trimmer. The device is powered by a Li-ion battery and can be charged via a USB cable.

1. Connect the USB charging cable to the trimmer's charging port.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., phone charger, car charger, computer, power bank).
3. The charging indicator light will illuminate during charging.
4. A full charge takes approximately 1.5 hours and provides up to 60 minutes of runtime.
5. The quick charge feature provides enough power for one shave with just a 5-minute charge.



Image: The trimmer connected for USB charging, illustrating its quick charge capability.

3.2 Attaching Comb Guides

The trimmer comes with 1mm, 3mm, and 5mm comb guides to achieve desired hair lengths.

1. Ensure the trimmer is turned off.
2. Select the desired comb guide (1mm, 3mm, or 5mm).
3. Align the comb guide with the trimmer blade and press it firmly until it clicks into place.
4. To remove, gently pull the comb guide away from the blade.

4. Operating Instructions

The GAERUO Electric Trimmer and Shaver is suitable for both wet and dry use on various body parts.

4.1 General Trimming and Shaving

1. Ensure the trimmer is charged.
2. For trimming, attach the desired comb guide (1mm, 3mm, or 5mm). For a closer shave or edging, use without a comb guide.
3. Press the power button to turn on the trimmer.
4. Hold the trimmer at a slight angle against the skin.
5. Move the trimmer slowly and steadily against the direction of hair growth for optimal results.
6. For wet shaving, apply shaving gel or foam to the skin before use.
7. After use, press the power button to turn off the trimmer.



Image: The trimmer is designed for full body care, including face, body, hair, and underarm areas.



Image: The GAERUO trimmer functions as an all-in-one tool for wet & dry edging, bald styling, and multifunctional body shaving.

5. Maintenance

5.1 Cleaning the Trimmer

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the trimmer and disconnect it from any charging cable.
2. Remove any attached comb guides.
3. The cutter head is detachable. Gently remove it for thorough cleaning.
4. Rinse the blade and the detachable cutter head directly under running water.
5. Shake off excess water and allow all parts to air dry completely before reattaching the cutter head or storing the trimmer.
6. Do not use abrasive cleaners or harsh chemicals on the trimmer.



Image: The trimmer's waterproof design allows for easy cleaning after use.

6. Troubleshooting

If you encounter issues with your GAERUO Electric Trimmer, refer to the following common solutions:

- **Trimmer does not turn on:** Ensure the battery is sufficiently charged. Connect the trimmer to a power source and allow it to charge for at least 5 minutes before attempting to turn it on again.
- **Poor trimming performance:**
  - Check if the blade is clean and free from hair debris. Clean the blade as described in the Maintenance section.
  - Ensure the trimmer is fully charged. Low battery can affect motor performance.
  - The blade may be worn. Contact customer support for assistance if the blade is dull despite proper cleaning and charging.

- **Unusual noise during operation:** Turn off the trimmer and check for any hair or debris lodged in the blade assembly. Clean thoroughly. If the noise persists, discontinue use and contact customer support.

7. Specifications

Brand	GAERUO
Model	Electric Trimmer and Shaver
Power Source	Battery Powered (Li-ion)
Charging Time	Approx. 1.5 hours
Runtime	Approx. 60 minutes
Waterproof Rating	IPX7
Blade Material	Stainless Steel
Comb Guides Included	1mm, 3mm, 5mm
Special Features	USB Rechargeable, Wet & Dry Use, Contour Following System

8. Warranty and Support

GAERUO provides a one-year manufacturer's after-sales service for this product.

If you have any questions, require technical assistance, or need to claim warranty service, please contact GAERUO customer support. Refer to your purchase documentation for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question