JANOME JUNO E1015

Janome Juno E1015 Sewing Machine

INSTRUCTION MANUAL

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Janome Juno E1015 sewing machine. Please read this manual thoroughly before using the machine to ensure proper handling and to achieve optimal sewing results.

2. Safety Instructions

- Always unplug the machine from the electrical outlet when removing covers, lubricating, or when making any other user servicing adjustments mentioned in this instruction manual.
- Keep fingers away from all moving parts. Special care is required around the sewing machine needle.
- Always use the proper needle plate. The wrong plate can cause the needle to break.
- Do not pull or push fabric while stitching. This may deflect the needle, causing it to break.
- Turn the sewing machine off when making any adjustments in the needle area, such as threading the needle, changing the needle, threading the bobbin, or changing the presser foot.
- Never operate the machine with any air openings blocked. Keep ventilation openings of the sewing machine and foot controller free from the accumulation of lint, dust, and loose cloth.

3. Setup

3.1 Unpacking and Placement

Carefully remove the sewing machine from its packaging. Place the machine on a stable, flat surface. Ensure there is adequate lighting for your workspace.

3.2 Power Connection

Connect the power cord to the machine's power input and then plug it into a standard electrical outlet. Ensure the machine's power switch is in the 'OFF' position before connecting to power.

3.3 Machine Overview



Image 1: Front view of the Janome Juno E1015 sewing machine, showing the main body, needle area, stitch selector dials, and power switch.

Familiarize yourself with the main components of your sewing machine, including the handwheel, stitch selector dials, presser foot lifter, needle clamp, and bobbin winder.

3.4 Threading the Machine

1. Place a spool of thread on the spool pin.
2. Guide the thread through the upper thread guides as indicated by the numbered path on the machine.
3. Thread the needle from front to back.

3.5 Winding the Bobbin

1. Place an empty bobbin onto the bobbin winder spindle.
2. Guide the thread from the spool through the bobbin winding tension disc.
3. Wrap the thread around the bobbin a few times, then push the bobbin winder spindle to the right.
4. Press the foot controller to start winding. Stop when the bobbin is full.

4. Operating Instructions

4.1 Stitch Selection

The Janome Juno E1015 offers various stitch patterns. Use the stitch selector dial to choose your desired stitch. Refer to the stitch pattern guide on the machine's body.



Image 2: Close-up view of the stitch selector dial and stitch pattern guide on the Janome Juno E1015, showing various stitch options labeled A through G.

4.2 Sewing Basics

1. Raise the presser foot using the presser foot lifter.
2. Place the fabric under the presser foot.
3. Lower the presser foot.
4. Turn the handwheel towards you to bring the needle down into the fabric, then back up.
5. Press the foot controller gently to begin sewing. Increase pressure for faster sewing.
6. To reverse stitch, press and hold the reverse lever.

5. Maintenance

5.1 Cleaning

Regularly clean lint and dust from the bobbin case area and feed dogs using a small brush. Unplug the machine before cleaning. Do not use harsh chemicals.

5.2 Needle Replacement

Replace the needle frequently, especially if it becomes bent, dull, or if you notice skipped stitches. Ensure the flat side of the needle faces the back of the machine when inserting.

5.3 Storage

When not in use, cover the machine to protect it from dust. Store in a dry, cool place.

6. Troubleshooting

- **Skipped Stitches:** Check if the needle is inserted correctly, if it's bent or dull, or if the correct needle type is being used for the fabric.
- **Thread Breaking:** Ensure the machine is threaded correctly, the tension is appropriate, and the thread is not old or poor quality. Check for burrs on the needle or thread path.
- **Fabric Not Feeding:** Verify that the presser foot is lowered and the feed dogs are engaged. Adjust stitch length if necessary.
- **Machine Not Starting:** Confirm the power cord is securely plugged in, the power switch is on, and the foot controller is connected.

7. Specifications

Feature	Specification
Brand	JANOME
Model Number	JUNO E1015
Dimensions (L x W x H)	2.79 x 24.64 x 16.51 cm
Weight	2.1 Kilograms
Material	Stainless Steel, Plastic
Power Source	Electric Cable

8. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Janome website. Keep your proof of purchase for warranty claims.
For technical assistance or service, contact Janome customer support through their official channels. Do not attempt to service the machine beyond the maintenance steps outlined in this manual.

© 2023 Janome. All rights reserved.