Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PEXMOR stadiumseat03

PEXMOR Folding Stadium Seat User Manual

Model: stadiumseat03

Introduction

This manual provides detailed instructions for the safe and effective use of your PEXMOR Folding Stadium Seat. Please read this manual thoroughly before initial use and retain it for future reference. This product is designed to provide comfortable seating on bleachers and other outdoor surfaces.



Image: A PEXMOR stadium seat in use on bleachers.



Image: The PEXMOR Folding Stadium Seat.

Safety Information

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 330 pounds (150 kg).
- **Secure Attachment:** Always use the integrated straps and buckles to securely attach the seat to bleachers or benches to prevent movement and ensure stability.
- **Stable Surface:** Ensure the seat is placed on a dry, stable, and level surface to maintain traction and prevent tipping.
- **Inspection:** Before each use, inspect the seat for any signs of damage, wear, or loose components. Do not use if damaged.
- **Children:** Keep children away from moving parts during folding and unfolding to prevent pinching.

Package Contents

The package includes:

- 1 x PEXMOR Folding Stadium Seat

- 1 x Carrying Bag

Setup Instructions

1. **Unfolding the Seat:**

   Place the folded stadium seat on a flat surface. Gently press down on the seat portion to unfold it into the upright position. The backrest will automatically extend.



Image: The stadium seat in various stages of unfolding, illustrating its 5 adjustable positions and weight capacity.

2. **Adjusting Reclining Position:**

   The seat features 5 adjustable reclining positions. To adjust, gently push the backrest forward slightly, then recline it to your desired angle. The internal mechanism will lock it into place.

3. **Securing to Bleachers:**

   For use on bleachers, locate the straps and buckles underneath the seat. Wrap these straps around the bleacher bench and secure the buckles to prevent the seat from sliding or tipping.



Image: Detail of the anti-slip bottom and securing straps for bleacher attachment.

Operating Instructions

- **Using Side Pockets:**

  The seat is equipped with a detachable zippered side pocket suitable for beverages and snacks, and a left side pocket for items like a phone. Utilize these pockets for convenient storage during use.



Image: Detailed view of the various storage pockets on the stadium seat.

- **Armrest Functionality:**

  The armrests can be folded down to expand the seating space, offering a wider experience if preferred.



Image: Comparison of seat widths with armrests up and down.

Care and Maintenance

- **Cleaning:** Wipe clean with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the seat is completely dry before folding and storing to prevent mildew.
- **Storage:** Store in a cool, dry place away from direct sunlight when not in use.

Storage and Portability

To fold the seat for storage or transport:

1. Ensure the backrest is in its fully upright position.
2. Gently push the backrest forward until it lies flat against the seat base.
3. The seat can then be placed into the included carrying bag or carried using its integrated shoulder strap.



Image: Instructions for folding and carrying the stadium seat.

Troubleshooting

Problem	Possible Cause	Solution
Backrest does not stay in position.	Internal locking mechanism may be worn or damaged.	Ensure the backrest is pushed slightly forward before reclining to engage the mechanism. If the issue persists, contact customer support.
Seat slides on bleachers.	Straps not secured or surface is wet/unstable.	Ensure straps are tightly secured around the bleacher. Verify the bleacher surface is dry and stable.
Difficulty folding the seat.	Backrest not fully upright or mechanism jammed.	Ensure the backrest is in the fully upright position before attempting to fold it flat. Check for any obstructions.

Specifications

Feature	Detail
Brand	PEXMOR
Model Name	stadiumseat03
Color	Blue
Material (Exterior)	420D Waterproof Polyester (Oxford)
Fill Material	High-Density Foam
Dimensions (Approximate, 25" model)	14"D x 25"W x 18"H (when upright, armrests up)
Seat Depth	21 inches
Item Weight	7.7 Pounds (3.5 kg)
Maximum Weight Capacity	330 Pounds (150 kg)
Reclining Positions	5
Foldable	Yes
Care Instructions	Wipe Clean
UPC	810158421257

Warranty Information

This PEXMOR product comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or warranty claims regarding your PEXMOR Folding Stadium Seat, please contact PEXMOR customer service through the retailer where the product was purchased or visit the official PEXMOR website for contact details.
Online Support: PEXMOR Brand Store on Amazon

© 2023 PEXMOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08W4ZV6K3

More documents and user manuals: **https://manuals.plus/**