SEB MLX650117

SEB MS-650117 Chopper Bowl Lid Instruction Manual

For Moulinex and Tefal Masterchef 2000 Kitchen Machines

1. Product Overview

This document provides instructions for the SEB MS-650117 chopper bowl lid, a replacement part designed for specific Moulinex and Tefal kitchen machine models. This lid is an essential component for safely operating your food processor's chopper attachment, ensuring proper function during food preparation tasks.



Image: The SEB MS-650117 chopper bowl lid, designed for kitchen machines.

2. Compatibility

The MS-650117 chopper bowl lid is compatible with the following kitchen machine brands and models:

- **Compatible Brands:** MOULINEX, TEFAL
- **Compatible Models:** FP211110870, FP210510870, DO211111870

Please verify your appliance's model number to ensure proper fit and function.

3. Setup and Installation

1. **Preparation:** Ensure your kitchen machine is unplugged from the power outlet before attempting installation.
2. **Attach Chopper Bowl:** Place the chopper bowl onto the motor unit of your kitchen machine, ensuring it is securely locked into position according to your appliance's specific instructions.

3. **Insert Blade:** Carefully place the chopper blade onto the central spindle inside the chopper bowl.
4. **Position Lid:** Align the MS-650117 lid with the top of the chopper bowl. Ensure the locking tabs or grooves on the lid match those on the bowl.
5. **Secure Lid:** Gently press down and rotate the lid clockwise until it clicks into place, indicating it is securely locked. The appliance will not operate if the lid is not correctly installed and locked.

Always ensure the lid is properly secured before operating the kitchen machine to prevent injury and ensure optimal performance.

4. Operating Instructions

Once the chopper bowl and lid are securely installed, you can proceed with your food preparation tasks. This lid is designed to facilitate the milling of various ingredients.

- **Recommended Use:** This lid is suitable for milling spices, such as pepper and salt, when used with the appropriate chopper blade and bowl.
- **Operation:** With the lid securely in place, plug in your kitchen machine and select the desired speed setting for chopping or milling. Refer to your main kitchen machine manual for specific operating instructions.
- **Safety:** Never attempt to open the lid or reach into the chopper bowl while the appliance is operating. Always wait for the blades to come to a complete stop before removing the lid.

5. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your chopper bowl lid.

- **Cleaning:** After each use, unplug the kitchen machine and carefully remove the lid. Wash the lid by hand using warm, soapy water. Rinse thoroughly and dry completely before storage.
- **Dishwasher Safety: This lid is NOT dishwasher safe.** Washing in a dishwasher may cause damage or deformation.
- **Storage:** Store the lid in a clean, dry place, away from direct sunlight or extreme temperatures.

6. Troubleshooting

If you encounter issues with your chopper bowl lid, consider the following:

- **Lid Not Fitting:** Ensure you have the correct model lid for your chopper bowl. Check for any food debris or obstructions preventing the lid from seating properly.
- **Appliance Not Starting:** Most kitchen machines have a safety interlock system. Ensure the lid is correctly aligned and securely locked into place. If the lid is not properly secured, the appliance will not power on.
- **Damage:** Inspect the lid for any cracks, chips, or deformities that might affect its fit or function. A damaged lid should be replaced.

If problems persist, consult your main kitchen machine's instruction manual or contact the manufacturer for further assistance.

7. Specifications

Brand	SEB
Model Number	MLX650117

ASIN	B08W8GSQQJ
Manufacturer	SEB
Country of Origin	China
Operation Mode	Manual (as part of a larger appliance)
Dishwasher Safe	No

8. Warranty and Support

Specific warranty information for this replacement part is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the documentation that came with your original kitchen machine or contact the manufacturer, SEB, directly. You may also contact the retailer from whom you purchased this lid.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question