Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lovehoney Thrill

Lovehoney Thrill Bullet Vibrator User Manual

Introduction

Thank you for choosing the Lovehoney Thrill Bullet Vibrator. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your device. Please read these instructions carefully before first use and retain them for future reference.

Important Safety Information

- **External Use Only:** This device is designed exclusively for external stimulation.
- **Not for Anal Use:** Do not use this product for anal penetration.
- **Consult a Doctor:** If you experience any discomfort or adverse reactions, discontinue use immediately and consult a medical professional.
- **Keep Out of Reach of Children:** This product is intended for adult use only.



Image: The Lovehoney Thrill Bullet Vibrator, emphasizing its external use only.

Package Contents

- 1 x Lovehoney Thrill Bullet Vibrator (Purple)

Setup

Battery Installation

1. Twist the base of the vibrator counter-clockwise to open the battery compartment.
2. Insert one (1) AAA battery into the compartment, ensuring the correct polarity (+/-) as indicated inside.*(Battery not included)*
3. Twist the base clockwise to securely close the compartment. Ensure it is tightly sealed to maintain waterproofing.



Image: The Lovehoney Thrill Bullet Vibrator, indicating the need for 1 AAA battery (not included).

Operating Instructions

Power On/Off and Mode Selection

The Thrill Bullet Vibrator features a simple push-button operation located at the base of the device.

- **To Power On:** Press and hold the button for approximately 2 seconds until the vibrations begin.
- **To Change Vibration Mode:** Briefly press the button to cycle through the 10 available settings (3 speeds and 7 patterns).
- **To Power Off:** Press and hold the button for approximately 2 seconds until the vibrations stop.



Image: The Lovehoney Thrill Bullet Vibrator, highlighting its 3 speeds and 7 vibration patterns.

Care and Maintenance

Cleaning

The Thrill Bullet Vibrator is waterproof and submersible, making it easy to clean.

- Always clean the device before and after each use.
- Wash with warm water and a toy cleaner or mild antibacterial soap.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the material.

Storage

- Store the vibrator in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent potential reactions.

- Remove the battery if the device will not be used for an extended period to prevent leakage.



Image: The Lovehoney Thrill Bullet Vibrator, demonstrating its waterproof and submersible design.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is dead or incorrectly inserted.	Replace with a fresh AAA battery, ensuring correct polarity. Ensure battery compartment is securely closed.
Vibrations are weak.	Low battery power.	Replace the AAA battery.
Device turns off unexpectedly.	Low battery power or loose battery connection.	Replace the AAA battery. Ensure the battery compartment is tightly sealed.

Specifications

- **Model Name:** Thrill
- **Material:** Plastic
- **Color:** Purple
- **Power Source:** 1 x AAA Battery (not included)
- **Vibration Modes:** 10 (3 speeds, 7 patterns)
- **Waterproof:** Yes, submersible
- **Manufacturer:** Lovehoney

Warranty and Support

Information regarding warranty and customer support for the Lovehoney Thrill Bullet Vibrator is not provided within this manual. Please refer to the product packaging or the official Lovehoney website for details on warranty coverage and how to contact customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08WLZBZW6

More documents and user manuals: **https://manuals.plus/**