Hitachi RSM318HDDO

Hitachi 1.5 Ton 3 Star Split AC ZUNOH 3100f (Model RSM318HDDO) User Manual

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Hitachi 1.5 Ton 3 Star Split AC, Model ZUNOH 3100f (RSM318HDDO). Please read this manual thoroughly before using the air conditioner and keep it for future reference.

Your Hitachi AC is designed with an advanced microcontroller to optimize cooling performance by continuously monitoring indoor and outdoor conditions. It features inner grooved copper tubing for enhanced heat transfer and includes a filter cleaning alert to ensure consistent cooling efficiency.

2. Safety Information

Important Safety Instructions:

- Always ensure the air conditioner is installed by a qualified technician to prevent electrical shock, fire, or injury.
- Do not attempt to repair or modify the unit yourself. Contact authorized service personnel for all repairs.
- Ensure the power supply matches the specifications listed on the unit's nameplate.
- Do not insert fingers or objects into the air inlet or outlet.
- Keep flammable materials away from the unit.
- Regularly clean the air filters to maintain efficiency and air quality.
- If any abnormal operation, smell, or sound occurs, immediately turn off the unit and disconnect the power supply. Contact customer support.

3. Package Contents

Verify that all the following items are included in your package:

- 1 x Indoor Unit
- 1 x Outdoor Unit
- 1 x Interconnecting Pipe
- 1 x Remote Control
- 1 x User Manual (this document)
- 1 x Warranty Card

4. Setup and Installation

Professional installation is highly recommended for optimal performance and safety. This section provides general guidelines.

4.1 Indoor Unit Placement

The indoor unit should be mounted on a wall in a location that allows for even air distribution throughout the room, away from direct sunlight or heat sources. Ensure there is sufficient space around the unit for proper airflow and maintenance.



Figure 1: Front view of the Hitachi ZUNOH 3100f indoor unit.



Figure 2: Diagram showing the dimensions (height: 294 mm, width: 968 mm, depth: 240 mm) of the Hitachi AC indoor unit.

4.2 Outdoor Unit Placement

The outdoor unit should be placed on a stable, level surface, away from obstructions that could impede airflow. Ensure adequate ventilation and avoid locations exposed to excessive dust or corrosive gases. Maintain specified clearances from walls and other objects.



Figure 3: Diagram showing the dimensions (height: 548 mm, width: 750 mm, depth: 288 mm) of the Hitachi AC outdoor unit.

4.3 Refrigerant Piping

The indoor and outdoor units are connected by an interconnecting pipe, typically made of copper. This pipe carries the R32 refrigerant between the units. Proper insulation and sealing are crucial for efficient operation and to prevent refrigerant leaks.



Figure 4: A coiled copper pipe used for connecting the indoor and outdoor units of the air conditioner.

5. Operating Instructions

Your Hitachi AC is operated using the provided remote control. Ensure the remote control has fresh

batteries and is pointed towards the indoor unit when transmitting commands.



Figure 5: The remote control for the Hitachi AC, displaying various function buttons for mode, temperature, fan speed, and timer.

5.1 Remote Control Functions

- **Power Button:** Turns the unit ON or OFF.
- **Mode Selection:** Cycle through modes like COOL, DRY, AUTO, FAN.
- **Temperature Adjustment:** Use the UP/DOWN arrows to set the desired temperature.
- **Fan Speed:** Adjust fan speed (LOW, MED, HIGH, AUTO).
- **Timer ON/OFF:** Set a specific time for the unit to turn ON or OFF automatically.
- **Filter Button:** Resets the filter cleaning reminder after cleaning.
- **H. Swing:** Controls the horizontal swing of the air deflector.

5.2 Operating Modes

- **COOL Mode:** Provides cooling by lowering the room temperature to the set level.
- **DRY Mode:** Reduces humidity in the room without significant cooling.
- **FAN Mode:** Circulates air without heating or cooling.
- **AUTO Mode:** The unit automatically selects the appropriate operating mode (Cool, Dry, Fan) based on the room temperature.

6. Maintenance

Regular maintenance ensures optimal performance, energy efficiency, and longevity of your air conditioner.

6.1 Air Filter Cleaning

Your Hitachi AC features a unique alert that reminds you to clean the air filters at regular intervals. Dirty filters can reduce cooling efficiency and air quality.

1. Turn off the air conditioner and disconnect the power supply.
2. Open the front panel of the indoor unit.
3. Carefully remove the air filters.
4. Clean the filters using a vacuum cleaner or wash them gently with lukewarm water and a mild detergent.
5. Rinse thoroughly and allow them to dry completely in a shaded area before reinserting.
6. Close the front panel.
7. Press the 'Filter' button on the remote control to reset the cleaning reminder.

6.2 General Cleaning

- Wipe the indoor unit's exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the outdoor unit's coils are free from dust, leaves, and other debris. This may require professional cleaning.

7. Troubleshooting

Before contacting service, please check the following common issues:

Problem	Possible Cause	Solution
Unit does not start	No power supply; Remote control batteries low; Timer is set.	Check power connection and circuit breaker; Replace batteries; Cancel timer setting.
Insufficient cooling	Dirty air filters; Blocked outdoor unit; Doors/windows open; Temperature setting too high.	Clean air filters; Clear obstructions from outdoor unit; Close doors/windows; Lower temperature setting.
Unusual noise	Loose parts; Unit not level; Obstruction in fan.	Contact service technician; Ensure unit is on a stable surface; Check for obstructions.
Water leakage from indoor unit	Blocked drain pipe; Improper installation.	Contact service technician for inspection and repair.

If the problem persists after attempting these solutions, please contact authorized service personnel.

8. Specifications

Key technical specifications for the Hitachi 1.5 Ton 3 Star Split AC ZUNOH 3100f (Model RSM318HDDO):

Feature	Specification
Brand	Hitachi
Model Name	ZUNOH 3100f
Model Number	RSM318HDDO
Capacity	1.5 Tons
Energy Efficiency	3 Star Rating (BEE)
Annual Energy Consumption	1157 Kilowatt Hours
Noise Level (Indoor)	43 Decibels
Refrigerant	R32
Core Material	Copper
Voltage	230 Volts
Wattage	5303 Watts
Special Features	Air Purification Filter, Anti Bacterial Filter, Dehumidifier, Dust Filter
Controller Type	Remote Control
Item Weight	60400 Grams (Total)




Figure 6: Energy efficiency guide for the Hitachi AC, showing ISEER rating and annual energy consumption.

9. Warranty and Support

9.1 Warranty Information

This product comes with a **6-month supplier-backed warranty**. Please refer to the included warranty card for detailed terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, service requests, or warranty claims, please contact:

- **Manufacturer:** Hitachi India Private Limited, Tower B, World Mark 1, Aerocity, New Delhi-110037
- **Importer:** Importer Name ltd., Street No. 24/4, New Delhi, India - 110011
- **Contact:** +91-111-000-2400
- **Email:** service@importer.com

When contacting support, please have your model number (RSM318HDDO) and purchase details ready.

© 2023 Hitachi. All rights reserved. Information subject to change without notice.