Fischer & Honsel 40145

Fischer & Honsel Pool TW 40145 LED Floor Lamp User Manual

Model: 40145

Introduction

This manual provides essential instructions for the safe and efficient use of your Fischer & Honsel Pool TW 40145 LED Floor Lamp. This lamp is designed with durable, energy-saving LED technology, offering continuous dimming, three color temperature settings (CCT), and separately switchable light sources for versatile illumination.



Image: The Fischer & Honsel Pool TW 40145 LED Floor Lamp in brass finish, featuring an uplighter and a flexible reading arm.

Important Safety Instructions

- Read all instructions carefully before assembly and operation.
- This product is intended for **indoor use only**. Do not expose to moisture or extreme temperatures.
- Ensure the power supply voltage matches the lamp's requirements (230 Volts).
- Always unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Do not attempt to modify or repair the lamp. Contact qualified service personnel for assistance.
- Keep packaging materials away from children to prevent choking hazards.
- Position the lamp on a stable, level surface to prevent tipping.

Package Contents

Verify that all components are present and undamaged before proceeding with assembly.

- 1 x Fischer & Honsel Pool TW 40145 LED Floor Lamp (main body, base, uplighter, reading arm)
- 1 x User Manual

Setup Instructions

1. Unpacking

Carefully remove all components from the packaging. Retain packaging for future transport or returns. Inspect all parts for any signs of damage. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

2. Assembly

Assembly typically involves connecting the lamp sections and securing the base. While assembly is generally straightforward, ensure all connections are tight and stable. It is recommended to assemble the lamp on a soft surface, such as a thick blanket, to prevent scratches.

1. Attach the base to the lowest pole section, ensuring it is securely fastened. Check for any nuts or screws that need tightening.
2. Connect the subsequent pole sections, twisting or screwing them together as designed. Ensure the electrical wiring passes freely through the sections without pinching.
3. Attach the uplighter and the flexible reading arm to their designated positions on the main pole.
4. Once fully assembled, ensure the lamp stands upright and is stable.



Image: Diagram illustrating the dimensions of the floor lamp: 182 cm height, 32 cm base diameter, and 53 cm depth including the reading arm.

Operating Instructions

The Fischer & Honsel Pool TW 40145 LED Floor Lamp features intuitive touch controls for power, dimming, and color temperature adjustment.

1. Power On/Off

To turn the lamp on or off, briefly touch the designated touch control area on the lamp's body. The uplighter and reading arm can be switched on/off separately.

2. Dimming Function

The lamp offers continuous dimming for both the uplighter and the reading arm. To adjust the brightness, press and hold the touch control area. The light intensity will gradually increase or decrease. Release your finger when the desired brightness is reached.

3. Color Temperature (CCT) Adjustment

The lamp allows you to select from three distinct color temperature levels to suit your mood or activity:

- **2700 K (Warm White):** Provides a cozy and comfortable ambiance.
- **3350 K (Neutral White):** Ideal for general illumination and promoting concentration.
- **4000 K (Cool White):** Enhances activity and alertness, suitable for task lighting.

To cycle through these CCT settings, briefly touch the CCT control area. Each touch will switch to the next color temperature.

4. Separate Light Control

The uplighter and the flexible reading arm can be controlled independently. This allows for maximum flexibility in creating your desired lighting environment. Use the dedicated touch controls for each light source to adjust their power, dimming, and CCT settings individually.





Image: The floor lamp highlighting the touch controls for dimming and CCT adjustment, with examples of different color temperatures.

Maintenance

Cleaning

Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp's surfaces. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.

LED Light Source

The lamp is equipped with integrated LED light sources that are designed for long-term use and are not user-replaceable. Do not attempt to remove or replace the LEDs.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Loose connection.	Ensure the lamp is securely plugged into a working power outlet. Check all assembled sections for tight connections.
Dimming function not working.	Incorrect operation.	Ensure you are pressing and **holding** the touch control for dimming, not just tapping.
Color temperature not changing.	Incorrect operation.	Ensure you are briefly **tapping** the CCT control area to cycle through settings.
Lamp is wobbly after assembly.	Loose base or pole connections.	Carefully re-check and tighten all connections, especially the base. Ensure all included fastening components are used.

Technical Specifications

Model Number: 40145

Brand: Fischer & Honsel

Dimensions (L x W x H): 32 x 53 x 182 cm

Weight: 7.61 Kilograms

Material: Metal (base), Glass (shade)

Finish Type: Matte

Color: Brass

Light Source Type: LED

Number of Bulbs: 2 (integrated LED)

Wattage: 38 kWh (total)

Voltage: 230 Volts

Control Method: Touch

Features: Dimmable, Adjustable Color Temperature (CCT: 2700K, 3350K, 4000K), Flexible Arm

Usage: Indoor use only

Warranty and Support

This product is covered by the standard manufacturer's warranty. For specific warranty details, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Fischer & Honsel customer service through their official website or the contact information provided by your retailer.