Ariete 4618

Ariete 4618 Airy Fryer XXL Instruction Manual

Model: 4618

Introduction

This manual provides comprehensive instructions for the safe and efficient use, setup, operation, maintenance, and troubleshooting of your Ariete 4618 Airy Fryer XXL. Please read all instructions carefully before first use and retain this manual for future reference.

The Ariete 4618 Airy Fryer XXL utilizes 360° hot air circulation technology to cook food with minimal oil, offering a healthier alternative to traditional frying methods. Its generous 5.5-liter capacity is suitable for preparing meals for families.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Overview

Familiarize yourself with the components of your Ariete 4618 Airy Fryer XXL.



Image: Front view of the Ariete 4618 Airy Fryer XXL in red, showing the digital display and handle.

- **Digital Control Panel:** For setting temperature, time, and selecting preset programs.
- **Frying Basket:** Removable basket for holding food during cooking.

- **Basket Handle:** For safe insertion and removal of the frying basket.
- **Air Outlet Vent:** Located at the rear of the appliance for hot air exhaust.
- **Power Cord:** For connecting the appliance to an electrical outlet.

Setup

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Initial Cleaning:** Before first use, clean the frying basket and any removable parts with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance for proper ventilation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image: The Ariete 4618 Airy Fryer XXL placed on a kitchen counter, ready for use.

Operating Instructions

General Operation

1. **Prepare Food:** Place your ingredients into the frying basket. For best results, do not overfill the basket.
2. **Insert Basket:** Slide the frying basket back into the air fryer until it clicks into place.
3. **Power On:** Plug in the appliance. The digital display will illuminate.
4. **Set Temperature and Time:** Use the temperature and time controls on the digital panel to set your desired cooking parameters. The temperature range is typically from 80°C to 200°C. The timer can be set up to 60 minutes.

5. **Start Cooking:** Press the start button to begin the cooking process. The air fryer will automatically preheat if necessary.
6. **Shaking (Optional):** For even cooking, especially with smaller items like fries, pull out the basket halfway through the cooking time and shake the contents. Then reinsert the basket to resume cooking.
7. **Completion:** The air fryer will beep when the cooking time is complete and automatically shut off.
8. **Remove Food:** Carefully pull out the basket using the handle. Place the basket on a heat-resistant surface. Use tongs to remove the cooked food.

Preset Programs

The Ariete 4618 Airy Fryer XXL features 7 preset programs for common food items. These programs automatically set optimal temperature and time for convenience.



Image: Close-up of the digital control panel displaying icons for 7 preset cooking programs, including fries, cakes, fish, meat, chicken, shellfish, and red meat.

To use a preset program:

1. Prepare and load food into the basket.
2. Select the desired preset program icon on the digital control panel. The air fryer will automatically adjust the temperature and time.
3. Press the start button.

The 7 preset programs include:

- French Fries
- Cakes/Desserts
- Fish
- Meat
- Chicken
- Shellfish
- Red Meat



Image: Diagram illustrating the 360° hot air circulation within the air fryer basket, ensuring even cooking.

Cooking Guide

The following table provides general guidelines for cooking various food types. Cooking times and temperatures may vary based on food quantity, size, and desired crispiness. Always ensure food is cooked thoroughly to safe internal temperatures.



Image: A variety of air-fried foods, including french fries, chicken nuggets, and pastries, demonstrating the versatility of the appliance.

Recommended Cooking Times and Temperatures

Food Item	Temperature (°C)	Time (Minutes)	Notes
Fresh Fries (thin)	180-200	15-25	Shake basket halfway
Frozen Fries	180-200	20-30	Shake basket halfway
Chicken Drumsticks	180	20-25	Flip halfway
Fish Fillets	160	10-20	
Steak	180-200	8-15	Flip halfway, adjust for doneness
Vegetables (mixed)	160-180	10-18	Toss halfway

Food Item	Temperature (°C)	Time (Minutes)	Notes
Baked Goods (e.g., muffins)	160	15-20	Use appropriate bakeware



Image: A serving of crispy golden french fries, a common dish prepared in air fryers.



Image: A plate of perfectly fried calamari rings, showcasing the air fryer's ability to cook seafood.



Image: A bowl of golden-brown arancini (fried rice balls), illustrating the air fryer's capability for various fried snacks.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Basket and Pan:** The frying basket and pan are non-stick and can be washed with warm soapy water and a non-abrasive sponge. For stubborn food residue, soak them in warm water for about 10 minutes before cleaning. They may also be dishwasher safe (refer to specific product details if available, otherwise hand wash is recommended).
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
5. **Heating Element:** Gently clean the heating element with a cleaning brush to remove any food residue.
6. **Storage:** Ensure all parts are thoroughly dry before storing the appliance. Store in a cool, dry place.

Troubleshooting

Refer to the following table for common issues and their solutions.

Common Troubleshooting Guide

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet malfunction; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the basket firmly until it clicks into place.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped.	Do not overfill the basket. Shake or flip food items halfway through cooking.
Food is not crispy.	Not enough oil (for certain foods); temperature too low; cooking time too short.	Lightly brush or spray food with a small amount of oil. Increase temperature or cooking time as needed.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and pan thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the pan to prevent smoke.
Appliance smells during first use.	New appliance odor.	This is normal and will dissipate after a few uses. Ensure good ventilation.

Specifications

Technical details for the Ariete 4618 Airy Fryer XXL.



Image: Side view of the Ariete 4618 Airy Fryer XXL with key dimensions labeled: 31cm (width), 22.5cm (depth), 37.5cm (height).

- **Brand:** Ariete
- **Model Number:** 4618
- **Capacity:** 5.5 Liters
- **Power / Wattage:** 1800 Watts
- **Voltage:** 220 Volts
- **Material:** Aluminum, Plastic
- **Product Dimensions (D x W x H):** 39 x 22.5 x 37.5 cm
- **Item Weight:** 5.3 Kilograms

- **Auto Shutoff:** Yes
- **Special Features:** Temperature Control

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Ariete website. Keep your proof of purchase for warranty claims.
For further assistance, you may contact Ariete customer service through their official channels.Visit Ariete Support

© 2023 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question