ULANZI Select MT-17

ULANZI Select MT-17 Mini Vlog Tripod Instruction Manual

Model: MT-17

Introduction

Thank you for choosing the ULANZI Select MT-17 Mini Vlog Tripod. This compact and versatile tripod is designed to provide stable support for various devices, including smartphones, cameras, action cameras, webcams, and projectors. Its lightweight and portable design makes it an ideal companion for vlogging, photography, and video recording on the go.
Key features include:

- **Lightweight and Portable:** Weighing only 147g, it is easy to carry.
- **360° Adjustable Detachable Ball Head:** Allows for flexible angle adjustments with a simple press of a button.
- **Adjustable Heights:** Features 2-stage adjustments, from 109mm to 152mm.
- **Versatile Use:** Easily switches between tripod, handheld grip, and selfie stick modes.
- **Durable Construction:** Made from ABS and Aluminum with an anti-skid silicone plate.
- **Expandable:** Includes a 1/4 screw hole for attaching additional accessories.

Package Contents

Please ensure all items are present in your package:

- ULANZI Select MT-17 Mini Vlog Tripod
- Detachable Ball Head

Your browser does not support the video tag.

Official product overview video demonstrating the features and usage of the ULANZI MT-17 Mini Tripod.

Setup

1. **Unfolding the Tripod Legs:**

   Gently pull the three legs outwards from the main body of the tripod until they are fully extended and stable. The legs are designed to provide a firm base for your device.



Image: The ULANZI MT-17 Mini Tripod with its legs fully unfolded, ready for use as a stable base.

2. **Attaching the Ball Head:**

   The ball head comes pre-attached. If detached, align the 1/4-inch screw on the tripod's top with the screw hole on the bottom of the ball head. Rotate the ball head clockwise until it is securely fastened. Ensure it is tight to prevent wobbling.

Image: Illustration showing the detachable ball head being screwed onto the tripod body.

3. **Mounting Your Device:**

   Locate the 1/4-inch screw on the top of the ball head. Screw your camera, smartphone holder, webcam, or projector onto this screw until it is firmly attached. The anti-skid silicone plate on the ball head provides extra grip and protects your device.

Image: The tripod shown with different devices mounted, including a camera, smartphone, action camera, and LED light, demonstrating its versatility.

Operating Instructions

1. **Adjusting the Ball Head Angle:**

To adjust the angle of your mounted device, press the compressible button located on the side of the ball head. While holding the button, position your device to the desired angle. Release the button to lock the ball head in place. This allows for 360° rotation and tilt adjustments.

Image: A user's hands pressing the compressible button on the ball head to adjust its angle, illustrating the quick release and lock mechanism.

2. **Adjusting Tripod Height:**

   The tripod features a thumbwheel mechanism for height adjustment. Rotate the thumbwheel counter-clockwise to loosen, extend the legs to one of the two available stages (109mm or 152mm), and then rotate clockwise to secure the height. Ensure the legs are evenly extended for stability.

Image: The tripod illustrating its two adjustable height settings, 109mm and 152mm, with the thumbwheel for adjustment.

3. **Switching Modes (Tripod, Handheld Grip, Selfie Stick):**

   - **Tripod Mode:** Extend the legs fully and place the tripod on a flat, stable surface.
   - **Handheld Grip Mode:** Fold the legs together to form a comfortable grip. Hold the tripod firmly for stable handheld shooting.
   - **Selfie Stick Mode:** While in handheld grip mode, extend the height if desired for a longer reach.

4. **Using the 1/4 Screw Hole for Accessories:**

   The tripod body includes an additional 1/4-inch screw hole. This allows you to attach external accessories such as a magic arm, LED light, or microphone, expanding your creative possibilities.

Image: Detailed view highlighting the 1/4-inch screw hole on the tripod body, the compressible button for ball head adjustment, and the anti-skid silicone plate.

Maintenance

- **Cleaning:** Wipe the tripod with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is clean and dry before storage.
- **Inspection:** Periodically check all screws and moving parts to ensure they are secure. Tighten any loose connections as needed.
- **Avoid Overloading:** Do not exceed the maximum load capacity of 1.5kg to prevent damage to the tripod and your equipment.

Troubleshooting

Problem	Possible Cause	Solution
Device wobbles on tripod	Device not securely mounted; ball head not tightened; tripod legs uneven.	Ensure device is screwed tightly onto the ball head. Press the ball head button and release to lock. Verify tripod legs are fully extended and on a flat surface.
Ball head does not hold position	Compressible button not fully released; device too heavy.	Ensure the compressible button is fully released after adjusting the angle. Check if the device weight exceeds the 1.5kg maximum load.

Problem	Possible Cause	Solution
Tripod legs collapse easily	Legs not fully extended or locked; thumbwheel not tightened.	Ensure legs are fully extended and the thumbwheel is tightened to secure the height.

Specifications

Feature	Detail
Model Number	MT-17
Product Dimensions	3.94 x 3.94 x 1.97 inches (folded)
Item Weight	5.2 ounces (147g)
Adjustable Heights	109mm (4.29 inches) to 152mm (5.98 inches)
Max Load Capacity	1.5 kg
Material	ABS, Aluminum, Silicone
Mounting Screw	Standard 1/4-inch
Additional Screw Hole	1/4-inch (for accessories)

Warranty and Support

ULANZI Select products are manufactured to high quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official ULANZI website. If you encounter any issues or have questions regarding your MT-17 Mini Vlog Tripod, please contact ULANZI customer support through their official channels.
For further assistance, please visit the ULANZI Select Store on Amazon.

© 2024 ULANZI Select. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question