Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EDISON ELECTRIC VT-1202D/W

EDISON ELECTRIC 12 Liter Electric Pressure Cooker

Model: VT-1202D/W User Manual

1. Introduction

Thank you for choosing the EDISON ELECTRIC 12 Liter Electric Pressure Cooker, Model VT-1202D/W. This appliance is designed to simplify your cooking process, allowing you to prepare a variety of delicious meals efficiently. It features a digital screen for easy control, multiple cooking programs, a timer function, and an automatic keep-warm feature. The inner pot is made of granite, offering durability and ease of cleaning. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- This appliance cooks under pressure. Improper use may result in scalding injury. Make certain unit is properly closed before operating.
- Never force open the pressure cooker. Make sure internal pressure is completely released before opening.
- Do not fill the unit over 2/3 full. When cooking foods that expand during cooking, such as rice or dehydrated vegetables, do not fill the unit over 1/2 full.
- Always check the pressure release valve and float valve for clogging before use.
- The inner pot is dishwasher safe for convenient cleaning.

3. Product Overview

Familiarize yourself with the components of your EDISON ELECTRIC Electric Pressure Cooker.



Figure 1: Main Unit with Control Panel
This image displays the complete EDISON ELECTRIC 12 Liter Electric Pressure Cooker, highlighting its digital control panel with various cooking presets and the wooden design accents on the lid handle and base.



Figure 2: Cooker with Inner Pot Inserted
A top-down view of the pressure cooker, showing the granite-coated inner pot correctly seated within the main unit. This illustrates how the pot fits inside the appliance before the lid

is secured.



Figure 3: Granite Inner Pot
A detailed view of the removable inner pot, showcasing its non-stick granite coating. This pot is designed for even heat distribution and easy cleaning.

Figure 4: Accessories
This image shows the included measuring cup and rice spoon, essential tools for accurate ingredient measurement and serving.

Components:

- **Main Unit:** The outer housing of the pressure cooker, containing the heating element and control panel.
- **Inner Pot:** Removable 12-liter granite-coated pot for cooking.
- **Lid:** Features a locking mechanism, pressure release valve, and float valve.
- **Control Panel:** Digital display and touch buttons for program selection and settings.
- **Measuring Cup:** For precise liquid and ingredient measurements.
- **Rice Spoon:** For serving cooked rice and other dishes.

4. Setup

1. **Unpacking:** Carefully remove all packaging materials and accessories from the box.
2. **Initial Cleaning:** Before first use, wash the inner pot, lid, and accessories (measuring cup, rice spoon) with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the pressure cooker on a stable, level, heat-resistant surface, away from direct sunlight and heat sources. Ensure there is adequate space around the unit for ventilation.
4. **Insert Inner Pot:** Place the clean and dry inner pot into the main unit. Ensure it is seated correctly and makes full contact with the heating element.

5. Operating Instructions

The EDISON ELECTRIC pressure cooker features easy-touch cooking programs and a digital display for intuitive operation.

Basic Operation:

1. **Add Ingredients:** Place your food and liquids into the inner pot. Do not exceed the MAX fill line (2/3 full for most foods, 1/2 full for expanding foods like rice).
2. **Close Lid:** Place the lid on the cooker and turn it clockwise until it locks securely. Ensure the pressure release valve is in the 'Sealing' position.
3. **Plug In:** Connect the power cord to a grounded electrical outlet. The digital display will illuminate.
4. **Select Cooking Program:** Use the touch control panel to select your desired cooking program (e.g., Rice, Fish, Chicken, Meat, Soup, Matatiz, Hashi, Grape Leaves). The display will show a default cooking time.
5. **Adjust Time (Optional):** If desired, use the '+' and '-' buttons to adjust the cooking time.
6. **Start Cooking:** The cooker will automatically begin the preheating process, then build pressure and start cooking.
7. **Pressure Release:** Once cooking is complete, the cooker will beep and switch to the 'Keep Warm' mode. Allow the pressure to release naturally, or carefully turn the pressure release valve to the 'Venting' position for quick release (use caution as hot steam will be released).
8. **Open Lid:** Once the float valve drops, indicating all pressure has been released, turn the lid counter-clockwise and open it away from your face.

Special Features:

- **Timer Feature (Preset Timer):** Allows you to delay the start of cooking. Press the 'Preset Timer' button, then use '+' and '-' to set the desired delay time.
- **Automatic Heating (Keep Warm):** After cooking, the appliance automatically switches to a 'Keep Warm' function to maintain food temperature until serving.



Figure 5: Cooked Meal Example

This image demonstrates a meal, likely rice with chicken, prepared inside the EDISON ELECTRIC pressure cooker, showcasing the appliance's cooking capabilities.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your pressure cooker.

1. **Unplug and Cool:** Always unplug the cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot:** The granite-coated inner pot is dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely. Avoid using harsh chemicals or abrasive cleaners that could damage the non-stick coating.
3. **Lid:** Wash the lid, including the sealing gasket, pressure release valve, and float valve, with warm, soapy water. Ensure all food particles are removed from the valves. Rinse and dry thoroughly. The sealing gasket can be removed for deeper cleaning if necessary, but ensure it is reinstalled correctly before next use.
4. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Accessories:** Wash the measuring cup and rice spoon with warm, soapy water, rinse, and dry.
6. **Storage:** Store the cleaned and dried pressure cooker in a dry place.

7. Troubleshooting

If you encounter issues with your EDISON ELECTRIC pressure cooker, refer to the following common problems and solutions:

- **Cooker not building pressure:**
  - Ensure the lid is properly closed and locked.
  - Check that the pressure release valve is set to the 'Sealing' position.
  - Verify the sealing gasket is correctly installed and not damaged.
  - Ensure there is sufficient liquid in the inner pot for pressure to build.
- **Steam leaking from the lid:**
  - Check the sealing gasket for proper placement or damage. Replace if necessary.
  - Ensure the lid is fully closed and locked.

- **Food not cooking properly:**
  - Verify the correct cooking program and time were selected.
  - Ensure the cooker reached full pressure during the cooking cycle.
  - Check the amount of liquid and ingredients used.
- **Digital display not working:**
  - Ensure the power cord is securely plugged into a working outlet.
  - Try plugging the cooker into a different outlet.

If the problem persists after attempting these solutions, please contact EDISON ELECTRIC customer support.

8. Specifications

Feature	Specification
Brand	EDISON ELECTRIC
Model Number	VT-1202D/W
Capacity	12 Liters
Product Dimensions	16.14 x 13.18 x 9.84 cm
Item Weight	11 Kilograms
Special Features	Dishwasher Safe (Inner Pot), Locking Lid
Control Method	Touch
Operation Mode	Automatic
Inner Pot Material	Granite (Non-stick, Anti-scratch)

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official EDISON ELECTRIC website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08X4RD333

More documents and user manuals: **https://manuals.plus/**