MSI H510M-A PRO

MSI H510M-A PRO Motherboard User Manual

Model: H510M-A PRO

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your MSI H510M-A PRO Micro-ATX Motherboard. Designed to support 10th and 11th Gen Intel Core processors, this motherboard offers a stable and efficient platform for personal computing. Please read this manual thoroughly before proceeding with installation to ensure correct setup and optimal performance.

2. Safety Information

Always observe the following safety precautions during installation and operation:

- Disconnect the power cord from the wall outlet before touching any component.
- Wear an electrostatic discharge (ESD) wrist strap or frequently touch a grounded metal object to prevent static damage to components.
- Handle components by their edges to avoid touching sensitive parts.
- Ensure proper ventilation within your PC case to prevent overheating.
- Keep the motherboard away from moisture and extreme temperatures.

3. Package Contents

Verify that all items are present in your motherboard package:

- MSI H510M-A PRO Motherboard
- I/O Shield
- 2 x SATA Cables
- M.2 Screws
- Quick Installation Guide (not included in this digital manual)



Image: MSI H510M-A PRO Motherboard with its retail box, I/O shield, two SATA cables, and M.2 screws.

4. Motherboard Layout

Familiarize yourself with the key components and connectors on your MSI H510M-A PRO motherboard.



Image: Top-down view of the MSI H510M-A PRO Motherboard, showing the LGA 1200 CPU socket, DDR4 DIMM slots, PCIe slots, M.2 slot, and various headers.

Rear I/O Panel

The rear I/O panel provides external connectivity for your peripherals.




Image: Detailed view of the rear I/O panel with labels for USB 2.0 ports, USB 3.2 Gen 1 ports, PS/2 port, HDMI port, VGA port, LAN port, and audio jacks.

- **HDMI 2.0b Port:** Connects to display devices, supporting up to 4K resolution at 60Hz (requires CPU with integrated graphics).
- **VGA Port:** Connects to older display devices (requires CPU with integrated graphics).
- **USB 3.2 Gen 1 Type-A Ports:** Two ports for high-speed USB devices (5Gb/s).
- **USB 2.0 Ports:** Multiple ports for standard USB devices.
- **LAN Port:** Intel I219V 1G LAN for network connectivity.
- **Audio Jacks:** 7.1 HD Audio with Audio Boost for speaker/headphone connections.
- **PS/2 Port:** For legacy keyboard or mouse connections.

5. Setup and Installation

Follow these steps to install the components onto your motherboard.

5.1. CPU Installation

1. Locate the LGA 1200 CPU socket on the motherboard.
2. Open the CPU socket lever and lift the metal load plate.
3. Carefully align the notches on your 10th or 11th Gen Intel Core processor with the socket.
4. Gently place the CPU into the socket without forcing it.
5. Close the load plate and secure it with the lever.
6. Install the CPU cooler according to its manufacturer's instructions.

5.2. RAM (DDR4) Installation

1. Locate the two DDR4 DIMM slots.
2. Open the clips at both ends of the DIMM slot.
3. Align the notch on the DDR4 memory module with the notch in the DIMM slot.
4. Insert the memory module firmly into the slot until the clips snap into place.
5. Ensure both clips are fully closed.

5.3. M.2 SSD Installation

1. Locate the M.2 Gen3 x4 32Gb/s slot.
2. Remove the M.2 standoff screw from the motherboard.
3. Insert the M.2 SSD into the slot at an angle.
4. Gently push down the M.2 SSD and secure it with the M.2 screw.

5.4. Graphics Card Installation

1. Locate the PCIe 4.0 x16 slot (reinforced with steel armor).
2. Remove the corresponding expansion slot cover from your PC case.
3. Align your graphics card with the PCIe slot.
4. Press down firmly until the card is seated and the retention clip snaps into place.
5. Secure the graphics card to the case with a screw.

5.5. SATA Device Installation

1. Connect one end of a SATA data cable to a SATA port on the motherboard.
2. Connect the other end of the SATA data cable to your SATA hard drive or SSD.
3. Connect a SATA power cable from your power supply to the SATA device.

5.6. Front Panel Connectors

Connect the cables from your PC case's front panel (USB, audio, power button, reset button, LED indicators) to the corresponding headers on the motherboard. Refer to the motherboard's silkscreen labels for correct pin alignment.

5.7. Power Supply Connection

1. Connect the 24-pin ATX main power connector from your power supply to the motherboard.
2. Connect the 8-pin (or 4-pin) ATX 12V CPU power connector from your power supply to the motherboard.

6. Operating the Motherboard

6.1. Initial Boot and BIOS Setup

After assembling your system, connect a monitor, keyboard, and mouse. Power on the system. During startup, press the **DEL** key repeatedly to enter the BIOS/UEFI setup utility. Here you can configure boot order, system time, and other advanced settings.

6.2. Driver Installation

After installing your operating system, install the necessary drivers for the motherboard's components (chipset, LAN, audio, etc.). These drivers are typically available on the MSI website for your specific motherboard model.

7. Maintenance

7.1. Cleaning

Regularly clean your PC case and motherboard to prevent dust buildup, which can lead to overheating. Use compressed air to remove dust from fans, heatsinks, and other components. Ensure the system is powered off and unplugged before cleaning.

7.2. BIOS Updates

Periodically check the MSI website for BIOS/UEFI updates. BIOS updates can improve system stability, add support for new hardware, or fix bugs. Follow the instructions provided by MSI carefully when performing a BIOS update to avoid system damage.

8. Troubleshooting

If you encounter issues, consider the following common troubleshooting steps:

- **No Display:** Ensure the monitor is connected to the correct port (on the graphics card or motherboard I/O if using integrated graphics). Check if the graphics card is properly seated and powered.
- **System Not Booting:** Verify all power cables (24-pin ATX, 8-pin CPU) are securely connected. Reseat RAM modules. Check CPU installation.
- **Peripheral Not Detected:** Ensure the device is properly connected. Try a different port. Install necessary drivers.
- **Overheating:** Check CPU cooler installation and fan operation. Ensure proper case airflow. Clean dust from components.
- **BIOS Reset:** If system becomes unstable after BIOS changes, clear the CMOS by temporarily removing the CMOS battery or using the designated jumper (refer to motherboard diagram for location).

9. Specifications

Feature	Specification
Brand	MSI
CPU Socket	LGA 1200

Feature	Specification
Compatible Processors	10th & 11th Gen Intel Core Processors, Pentium Gold & Celeron Processors
RAM Memory Technology	DDR4
Max RAM Capacity	64 GB (Dual DIMMs, 3200MHz)
PCIe Slot	1 x PCIe 4.0 x16 (with steel frame)
M.2 Slot	1 x M.2 Gen3 x4 32Gb/s
LAN	Intel I219V 1G LAN
Video Output	HDMI 2.0b (4K/60Hz), VGA
USB Ports	2 x USB 3.2 Gen 1 Type-A (5Gb/s), USB 2.0 ports
Audio	7.1 HD Audio with Audio Boost
Form Factor	Micro-ATX

10. Warranty and Support

For warranty information, technical support, or further assistance, please refer to the warranty card included with your product or visit the official MSI website. You can find drivers, FAQs, and contact information for customer service there.
MSI Official Website: www.msi.com

© 2023 MSI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question