ZOKOP XQB45-ZK4

ZOKOP Full-Automatic Portable Compact Laundry Washer

Model: XQB45-ZK4 | Brand: ZOKOP

1. Introduction and Overview

Thank you for choosing the ZOKOP Full-Automatic Portable Compact Laundry Washer. This appliance is designed for convenience and efficiency, offering a compact solution for your laundry needs. With a 10 lbs capacity, 10 wash programs, and 8 water level selections, it is suitable for light to medium laundry loads in various settings such as apartments, dormitories, or RVs.

Key features include a 24-hour smart delay function, child protection lock, a clear lid for monitoring, and a durable stainless steel inner tub. Its automatic imbalance adjustment ensures stable operation during the spin cycle.

2. Safety Information

Please read all instructions carefully before using the appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply matches the specifications (110V / 60Hz).
- Do not operate the machine with a damaged power cord or plug.
- Keep the appliance away from heat sources and direct sunlight.
- Do not immerse the machine in water or spray water directly onto it.
- Always unplug the machine before cleaning or performing any maintenance.
- Do not allow children to operate or play with the appliance. The child protection feature automatically shuts off the washer when the lid is open.
- Ensure the drain hose is properly secured to prevent water leakage.
- Do not wash items that are waterproof or easily float, as this may cause imbalance.

3. Product Components and Dimensions



Front view of the ZOKOP Portable Washing Machine.



The washing machine showing its compact dimensions: 16 inches (L) x 16 inches (W) x 30 inches (H).



Top view of the washing machine with key components labeled: Top Cover, Inlet Valve, Filter, Frame, Inner Tub, Operation Panel, Body, and Base.



Close-up view of the stainless steel inner tub and the built-in lint filter.



Rear view of the washing machine, showing the power cord and water inlet/drain connections.

4. Setup and Installation

The ZOKOP portable washing machine is designed for easy setup. The package includes the washing machine unit, an inlet hose, a drain hose, and this manual.

4.1 Placement

- Place the washing machine on a firm, level surface to minimize vibration during operation.

- Ensure there is adequate space around the machine for ventilation and access.
- Adjust the bottom feet to ensure stability and levelness.

4.2 Water Connection

- **Inlet Hose:** Connect the inlet hose (35 inches long) to the water inlet valve on the back of the machine and to a suitable water faucet. Ensure a tight connection to prevent leaks.
- **Drain Hose:** Attach the drain hose (30 inches long) to the drain outlet on the machine. Position the other end of the drain hose into a sink, bathtub, or toilet for proper drainage. Ensure the drain hose is not kinked or blocked.

4.3 Power Connection

- Plug the power cord into a standard 110V / 60Hz electrical outlet.
- Ensure the outlet is properly grounded and capable of handling the appliance's power requirements.

5. Operating Instructions

The control panel features an LED display, 10 programs, and 8 water level selections for versatile washing options.



Close-up of the intuitive control panel with LED display and function buttons.

5.1 Control Panel Functions

- **Power Button:** Turns the machine on/off.
- **Start/Pause Button:** Starts or pauses the selected wash cycle.
- **Water Level Button:** Selects one of the 8 available water levels (1-8L) to match your load size.
- **Program Button:** Cycles through the 10 wash programs.
- **LED Display:** Shows remaining time, error codes, and selected settings.

5.2 Wash Programs

Select the appropriate program based on your laundry type and soil level:

Program No.	Program Name	Description

Program No.	Program Name	Description
01	Common	Standard wash cycle for everyday laundry.
02	Soak	Pre-soak cycle for heavily soiled items.
03	Wash	Wash only cycle.
04	Quick	Short wash cycle for lightly soiled items.
05	Normal	Regular wash cycle.
06	Spin	Spin only cycle to remove excess water.
07	Rinse	Rinse only cycle.
08	Air Dry	Air drying function.
09	Wash and Rinse	Combines wash and rinse cycles.
10	Rinse and Spin	Combines rinse and spin cycles.

5.3 Water Level Selection

The machine offers 8 water level selections to optimize water usage based on the load size. Use the Water Level button to cycle through the options. The display will indicate the selected level.

5.4 Smart Delay Function

The 24-hour intelligent delay washing function allows you to set a delayed start time for your wash cycle. Press the Program button to select the desired start time (2-24 hours).

5.5 Child Protection

For safety, the washer features an automatic shutoff when the lid is opened during operation. Once the lid is closed, the washer will resume its cycle.

6. Maintenance

Regular maintenance ensures the longevity and efficient operation of your washing machine.

6.1 Cleaning the Lint Filter

The machine has a built-in lint filter. It is recommended to clean the lint filter at least once a month to prevent lint buildup and ensure proper drainage. Refer to the diagram in Section 3 for the filter's location within the inner tub.

6.2 General Cleaning

- Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the inner tub periodically to prevent residue buildup.
- Ensure the machine is dry after use, especially the inner tub, to prevent mold and mildew.

7. Troubleshooting

If you encounter issues with your washing machine, please refer to the following common troubleshooting tips:

- **Machine does not start:** Check if the power cord is securely plugged in. Ensure the lid is fully closed. Press the Power button, then Start/Pause.
- **No water filling:** Check if the water faucet is turned on and the inlet hose is properly connected and not kinked.
- **Water not draining:** Ensure the drain hose is not kinked, blocked, or positioned too high.
- **Excessive vibration/noise:** Ensure the machine is on a level surface and the load is balanced inside the tub. The automatic imbalance adjustment feature will attempt to correct this, but manual redistribution of clothes may be necessary.
- **Error codes on LED display:** Consult the specific error code in your detailed manual (if provided) or contact customer support.

8. Specifications

Feature	Specification
Brand	ZOKOP
Model	XQB45-ZK4
Color	Gray
Cabinet Material	PP Plastic
Motor Material	Aluminum
Inner Tub Material	Stainless Steel
Product Dimensions (L x W x H)	16 x 16 x 30 inches
Net Weight	35 lbs
Form Factor	Top-Loading
Water Level Selections	8 (1-8L)
Rated Voltage and Frequency	110V / 60Hz
Rated Wash / Spin Capacity	10 lbs
Length of Inlet Pipe	35 inches
Length of Drain Pipe	30 inches

Feature	Specification
Programs	10
Special Features	Full-automatic, 24-Hour Smart Delay, Child Protection, Automatic Imbalance Adjustment, Adjustable Foot

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or contact ZOKOP customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 ZOKOP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the size or part number for the replacement lint filter for the ZOKOP XQB70-168 washing machine?

The manual for the ZOKOP portable washing machine series (including models like the XQB45-ZK4 and XQB60-ZK6-A) identifies the part as a built-in lint filter located inside the stainless steel inner tub. However, the manual...

Read full answer

Is there a way to disconnect, turn off, or lower the volume of the beeper on the Zokop QXB50-168 washing machine?

Based on the available documentation for Zokop portable washing machines, there is no built-in software setting or button combination to turn off, mute, or lower the volume of the beeper. The audible alerts for...

Read full answer