**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**soges CS-ZJ02-FG**

# soges L-Shaped Gaming Desk Instruction Manual

Model: CS-ZJ02-FG | Brand: soges

## Introduction

Thank you for choosing the soges L-Shaped Gaming Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. Designed for versatility and durability, this desk offers a spacious and stable workspace for various activities, from gaming and office work to creative projects.
Key features include a generous L-shaped desktop, robust metal frames for enhanced stability, and a convenient movable CPU holder. Please read this manual thoroughly before beginning assembly or use.

## Setup & Assembly

Before you begin, ensure all parts are present and undamaged. Assembly is best performed with two people.

### Package Contents

- Desktop Panels (L-shaped sections and corner piece)
- Metal Frame Components (legs, support bars)
- Movable CPU Holder
- Assembly Hardware (screws, bolts, washers, Allen wrench)
- Adjustable Leg Pads

### Assembly Steps

1. **Step 1: Unpack and Identify Parts.** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided labels or diagrams.



*Image: An overhead view of the unassembled desk components, including the L-shaped desktop pieces, metal frame parts, and hardware, spread out on a floor. This helps in identifying all parts before starting assembly.*

2. **Step 2: Assemble the Metal Frames.** Connect the leg components and support bars to form the L-shaped frame. Ensure all connections are secure but do not fully tighten screws at this stage. This allows for minor adjustments later.



*Image: The L-shaped metal frame of the desk, fully assembled but without the wooden desktop panels attached. This illustrates the structural base of the desk.*

3. **Step 3: Attach Desktop Panels.** Carefully place the desktop panels onto the assembled metal frame. Align the pre-drilled holes in the desktop with the holes in the frame. Use the shorter screws (Screw C) to fix the desktop to the frame. *Warning: Using longer screws (Screw D) may damage the desktop.*




*Image: A close-up view showing the connection point where two desktop panels meet at the corner, illustrating how they fit together on the frame.*

4. **Step 4: Tighten All Screws.** Once all desktop panels are in place and aligned, gradually tighten all screws using the provided Allen wrench. Avoid overtightening to prevent damage to the metal frame or desktop.




*Image: A fully assembled L-shaped desk with a gaming setup, including multiple monitors and a computer tower, demonstrating the desk's intended use.*

5. **Step 5: Attach Adjustable Leg Pads.** Screw the adjustable leg pads into the bottom of each desk leg. These pads help stabilize the desk on uneven floors.




*Image: A close-up of the adjustable leg pad at the bottom of a desk leg, with arrows indicating its rotational adjustment for leveling.*

6. **Step 6: Place Movable CPU Holder.** Position the movable CPU holder as desired under the desk. This stand helps protect your computer host from moisture and allows for easy repositioning.




*Image: The movable CPU stand with a computer tower placed on it, demonstrating its function and portability.*

## Operating Instructions

The soges L-Shaped Gaming Desk is designed for versatile use in various settings.

- **Workstation Setup:** Utilize the expansive L-shaped surface to accommodate multiple monitors, a keyboard, mouse, and other office essentials. The corner section is ideal for a monitor or for organizing documents.
- **Gaming Configuration:** The large surface area provides ample space for gaming peripherals, multiple screens, and comfortable arm movement.
- **CPU Placement:** Use the included movable CPU holder to keep your computer tower off the floor, protecting it from dust and moisture, and allowing for easy access or repositioning.
- **Leveling:** If the desk feels wobbly, adjust the individual leg pads by rotating them until the desk is stable and level on your floor.

## Maintenance

Proper care will extend the life and appearance of your desk.

- **Cleaning:** Wipe the desktop and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood surface.
- **Weight Distribution:** Distribute weight evenly across the desk surface. Avoid placing excessively heavy items on one concentrated area. The recommended weight limit for stability is 250 lbs.
- **Screw Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary, but do not overtighten.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Desk wobbles or is uneven. | Uneven floor surface; leg pads not adjusted. | Adjust the individual leg pads by rotating them until the desk is stable. |
| Screws do not seem to fit or poke through. | Incorrect screw size used; overtightening. | Ensure you are using the correct screw (e.g., shorter Screw C for desktop). Do not overtighten screws, as this can warp the metal or damage the wood. |
| Desktop panels are not flush at the seams. | Panels not properly aligned during initial assembly; screws tightened prematurely. | Loosen all screws, realign the desktop panels, and then gradually tighten all screws. Minor variations may occur due to manufacturing tolerances. |
| Missing parts or damaged components. | Shipping damage or packaging error. | Contact soges customer support immediately for assistance. |

## Specifications

| Feature | Detail |
|---|---|
| Brand | soges |
| Model Number | CS-ZJ02-FG |
| Product Dimensions | 21.7"D x 59"W x 30"H |
| Color | Rustic Brown |
| Base Material | Metal |
| Top Material Type | Wood (E1 degree solid particle wood) |
| Special Feature | Adjustable Leg Pads, Movable CPU Holder |
| Maximum Weight Recommendation | 250 Pounds |
| Item Weight | 65.03 Pounds |
| Required Assembly | Yes |

## Warranty & Support

The soges L-Shaped Gaming Desk comes with a**Limited Lifetime Warranty**. For any questions, concerns, or to report missing/damaged parts, please contact soges customer support. You can find contact information on the official soges website or through your purchase platform.
For further assistance, please visit the soges Store on Amazon.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question