Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY R025H HL03037

ALLIMITY R025H HL03037 Replacement Remote Control Instruction Manual

Model: R025H HL03037
Brand: ALLIMITY

Introduction

This manual provides instructions for the ALLIMITY R025H HL03037 replacement remote control. This remote is designed to function with various Hitachi LCD Projector models, offering a direct replacement for your original remote. Please read this manual carefully to ensure proper setup and operation.

Compatible Hitachi LCD Projector Models:

- CP-EU4501WN, CP-EU5001WN, CP-EW3051WN, CP-EW3551WN, CP-EX3051WN, CP-EX3551WN, CP-EX4551WN, CP-EW4051WN, CP-EX5001WN, CP-EW5001WN
- CP-EX303, CP-EX353, CP-WU5500, CP-WX5500, CP-X5550, CP-WU5505, CP-WX5505, CP-X5555, CP-WU5506M, CP-WX5506M
- LP-AW4001, LP-AW3001, LP-AX3001, LP-EU5002, LP-EX5002, LP-EW5002, LP-TW4001, LP-TW3001, LP-WU3500, LP-WX3500

Setup

1. Battery Installation

The remote control requires two (2) AA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image: Back view of the R025H HL03037 remote control with the battery cover removed, illustrating the correct orientation for inserting two AA batteries into the compartment.

2. First Use

After installing the batteries, the remote control is ready for use. Aim the remote control directly at the infrared (IR) sensor on your

Hitachi LCD projector. Ensure there are no obstacles between the remote and the projector's sensor.

Operating Instructions

The R025H HL03037 remote control provides full functionality for your compatible Hitachi LCD projector. Below is a general overview of common button functions. Refer to your projector's specific manual for detailed functions of each button.



Image: Front view of the R025H HL03037 remote control, displaying the layout of all control buttons, including power, input, volume, menu, and navigation keys.

- **Power Button ( ):** Turns the projector on or off.
- **Input:** Selects the input source (e.g., HDMI, VGA).
- **Volume (+/-):** Adjusts the audio volume.
- **Menu:** Accesses the projector's on-screen menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate through menus and confirm selections.
- **ESC:** Exits the current menu or function.
- **Freeze:** Pauses the current image on the screen.
- **Zoom (+/-):** Adjusts the image zoom level.
- **Focus (+/-):** Adjusts the image focus.
- **Aspect:** Changes the aspect ratio of the projected image.
- **Mute:** Mutes or unmutes the audio.
- **Blank:** Temporarily blanks the screen.
- **Reset:** Resets certain projector settings.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are installed correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the projector's IR sensor.
  - Make sure you are within the effective range of the projector's IR sensor.
- **Certain buttons not working:**
  - Verify that your projector model is listed as compatible.
  - Some advanced functions might require specific projector settings or modes. Refer to your projector's manual.

Specifications

Model Number	R025H HL03037 (AMT-R025H-hita)
Product Material	Plastic

Connective Technology	Infrared (IR)
Power Source	2 x AA Batteries (not included)
Product Dimensions	7 x 2 x 0.65 inches (approx.)
Item Weight	2.1 ounces (approx.)
Compatible Devices	Hitachi LCD Projectors (specific models listed in Introduction)
Special Feature	Ergonomic design

Warranty and Support

For any issues or questions regarding your ALLIMITY R025H HL03037 replacement remote control, please contact ALLIMITY customer service. If the remote control does not work with your specific projector model, despite being listed as compatible, or if you encounter any other operational difficulties, our customer service team is available to assist you.
Please refer to your purchase documentation for specific warranty details and contact information. Our goal is to ensure your satisfaction with the product.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Y5BWWM7

More documents and user manuals: **https://manuals.plus/**