KOUWO B08Y6F8SMD

KOUWO 16-inch Electric Crepe Maker User Manual

Model: B08Y6F8SMD

1. Introduction

Thank you for purchasing the KOUWO 16-inch Electric Crepe Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for commercial use.

3. Product Components

Familiarize yourself with the parts of your KOUWO Electric Crepe Maker.



Image 1: Front view of the KOUWO 16-inch Electric Crepe Maker, showing the cooking plate, control knob, and indicator lights.

- **Cooking Plate:** 16-inch diameter cast iron surface for cooking crepes and pancakes.
- **Stainless Steel Body:** Durable housing for the appliance.
- **Temperature Control Knob:** Adjusts the cooking temperature from 50°C to 300°C.
- **Power Indicator Light (Green):** Illuminates when the unit is powered on.
- **Heating Indicator Light (Red):** Illuminates when the heating element is active and turns off when the set temperature is reached.
- **Storage Drawer:** Located beneath the cooking plate for convenient storage.
- **Power Cord:** For connecting to an electrical outlet.



Image 2: Close-up of the front panel, highlighting the temperature control knob and the green and red indicator lights.



Image 3: Rear view of the crepe maker, showing the power cord connection point.

4. Package Contents

Verify that all items are present in the package:

- 1 x KOUWO 16-inch Electric Crepe Maker
- 1 x Wooden Spreader
- 1 x Stainless Steel Spatula



Image 4: The included wooden spreader and stainless steel spatula.

5. Setup

1. **Unpacking:** Carefully remove all packaging materials from the crepe maker.
2. **Placement:** Place the crepe maker on a stable, heat-resistant, and level surface. Ensure there is adequate clearance around the unit for ventilation.
3. **Initial Cleaning:** Before first use, wipe the cooking plate with a damp cloth and mild detergent. Rinse with a clean damp cloth and dry thoroughly.
4. **Power Connection:** Ensure the temperature control knob is in the 'OFF' position. Plug the power cord into a grounded 110V AC electrical outlet.

6. Operating Instructions

Follow these steps to operate your KOUWO Electric Crepe Maker:

1. **Preheating:** Turn the temperature control knob to your desired cooking temperature (e.g., 180°C - 220°C for crepes). The green power indicator light will illuminate, and the red heating indicator light will turn on. The unit will begin to heat up.
2. **Temperature Ready:** The red heating indicator light will turn off once the set temperature is reached. The unit will cycle on and off to maintain the temperature.
3. **Lightly Oil (Optional):** For the first crepe or if needed, lightly brush the cooking surface with a small amount of cooking oil.
4. **Pour Batter:** Pour a small amount of crepe batter onto the center of the hot cooking plate.
5. **Spread Batter:** Immediately use the wooden spreader to quickly and evenly spread the batter in a circular motion from the center outwards to form a thin, round crepe.
6. **Cook Crepe:** Cook for approximately 30-60 seconds, or until the edges begin to crisp and the

surface appears set.

7. **Flip Crepe:** Use the stainless steel spatula to gently lift and flip the crepe. Cook the other side for another 15-30 seconds, or until golden brown.
8. **Remove Crepe:** Once cooked, remove the crepe from the cooking plate using the spatula.
9. **Repeat:** Repeat steps 3-8 for additional crepes.
10. **Finish:** When finished cooking, turn the temperature control knob to the 'OFF' position and unplug the unit from the power outlet. Allow the unit to cool completely before cleaning.

7. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your crepe maker.

- **Cool Down:** Always ensure the appliance is unplugged and completely cool before cleaning.
- **Cooking Plate:** Wipe the non-stick cooking surface with a damp cloth or sponge. For stubborn residue, use a small amount of mild dish soap. Avoid abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating.
- **Exterior:** Clean the stainless steel body with a damp cloth. Dry thoroughly.
- **Storage Drawer:** The stainless steel storage drawer can be removed and washed with warm soapy water, then rinsed and dried.
- **Do Not Immerse:** Never immerse the main unit, cord, or plug in water or any other liquid.
- **Storage:** Store the clean and dry crepe maker in a cool, dry place.

8. Troubleshooting

If you encounter issues with your crepe maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; temperature knob not turned on.	Ensure power cord is securely plugged in. Check power outlet with another appliance. Turn temperature knob to a setting above 'OFF'.
Crepes stick to the plate.	Plate not seasoned; insufficient oil; temperature too low.	Ensure plate is clean. Lightly oil the plate before each crepe. Increase temperature slightly.
Crepes cook unevenly.	Batter spread unevenly; plate not fully preheated.	Ensure batter is spread quickly and evenly. Allow the unit to fully preheat until the red indicator light turns off.
Unit overheats or does not heat enough.	Temperature sensor issue; internal malfunction.	Unplug the unit and allow it to cool completely. If the problem persists, contact customer support.

9. Specifications

Technical details for the KOUWO Electric Crepe Maker:



Image 5: Dimensions of the KOUWO 16-inch Electric Crepe Maker.

- **Model:** B08Y6F8SMD
- **Voltage:** 110 Volts (AC)
- **Power:** 1.7 KW (1700 Watts)
- **Cooking Plate Diameter:** 16 inches (40 cm)
- **Temperature Range:** 50°C - 300°C
- **Material:** Stainless Steel body, Cast Iron plate
- **Product Dimensions (D x W x H):** 16.33" x 15.35" x 7.67"
- **Item Weight:** 32.1 pounds
- **Special Feature:** Temperature Control

10. Customer Support

For any questions, concerns, or assistance regarding your KOUWO Electric Crepe Maker, please do not hesitate to contact us. We are committed to providing support and resolving any issues you may encounter.

Please refer to your purchase documentation or the KOUWO brand store on Amazon for the most current contact information.

Online Support: Visit the KOUWO Store on Amazon