Moen 84506

Moen Lindor 84506 Two-Handle Centerset Bathroom Faucet Instruction Manual

Model: 84506

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Moen Lindor 84506 Two-Handle Centerset Bathroom Faucet. Please read this manual thoroughly before beginning installation or use to ensure proper function and longevity of your product. Keep this manual for future reference.

2. Safety Information

- Always turn off the main water supply before installing or performing any maintenance on the faucet.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Ensure all connections are secure to prevent leaks.

3. Package Contents

Verify that all components are present before beginning installation:

- Moen Lindor 84506 Faucet Assembly (Spout and Handles)
- Mounting Hardware (washers, nuts)
- Hot and Cold Water Supply Lines
- Drain Assembly with Tailpiece
- Installation Tool (if applicable)

4. Setup and Installation

Follow these steps for proper installation of your Moen Lindor 84506 faucet.

4.1 Pre-Installation

1. Turn off the hot and cold water supply valves under the sink. If no shut-off valves are present, turn off the main water supply to the house.
2. Remove the old faucet and clean the sink surface thoroughly.

4.2 Faucet Installation

1. Place the faucet assembly onto the sink deck, aligning the handles and spout with the pre-drilled holes. Ensure the gasket is properly seated under the faucet base.
2. From underneath the sink, secure the faucet assembly using the provided mounting hardware (washers and nuts). Hand-tighten first, then use a wrench to snug them, being careful not to overtighten.
3. Connect the hot and cold water supply lines to the corresponding inlets on the faucet. The hot water line typically connects to the left, and the cold water line to the right. Tighten connections securely.
4. Connect the other ends of the supply lines to the hot and cold water supply valves.

4.3 Drain Assembly Installation

1. Apply a bead of plumber's putty or silicone sealant around the flange of the drain assembly.
2. Insert the drain assembly into the sink drain hole.
3. From underneath the sink, install the rubber washer, friction washer, and mounting nut onto the drain tailpiece. Tighten securely to create a watertight seal.
4. Connect the drain tailpiece to your P-trap assembly.

4.4 Final Steps

1. Slowly turn on the hot and cold water supply valves.
2. Check all connections for leaks. Tighten any leaking connections as needed.
3. Remove the aerator from the spout and turn on the faucet to flush out any debris from the water lines. Run water for approximately one minute.
4. Turn off the faucet, reattach the aerator, and test the faucet for proper operation.

This image displays the Moen Lindor 84506 two-handle centerset bathroom faucet. It features a high-arc spout and two lever handles, all in a polished chrome finish. The base of the faucet is clearly visible with the 'MOEN' logo.

5. Operating Instructions

The Moen Lindor 84506 faucet features two lever handles for precise control of water temperature and flow.

- **Cold Water:** Rotate the right handle counter-clockwise to open for cold water.
- **Hot Water:** Rotate the left handle counter-clockwise to open for hot water.
- **Temperature Control:** Adjust both handles to achieve the desired water temperature.
- **Flow Control:** The further the handles are rotated, the greater the water flow. This faucet is designed with a water-saving feature, providing a maximum flow rate of 1.5 gallons per minute.

6. Maintenance

Regular cleaning and maintenance will help preserve the finish and functionality of your faucet.

6.1 Cleaning the Finish

- Clean the chrome finish with a soft, damp cloth.
- Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- For stubborn spots, use a mild soap and water solution, then rinse thoroughly and dry with a soft cloth.

6.2 Aerator Maintenance

- If water flow decreases or becomes erratic, the aerator may be clogged.
- Unscrew the aerator from the tip of the spout.
- Rinse the aerator screen under running water to remove any debris. A soft brush can be used if necessary.
- Reattach the aerator to the spout, ensuring it is securely tightened.

7. Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Low water flow	Clogged aerator; partially closed supply valves; debris in supply lines.	Clean or replace aerator; fully open supply valves; flush supply lines.
Leaks at connections	Loose connections; damaged washers.	Tighten connections; replace washers if damaged.
Handles are stiff or hard to turn	Mineral buildup in cartridges.	Contact Moen customer support for cartridge replacement or service.
Water temperature not consistent	Issues with water heater or supply.	Check water heater settings; ensure both hot and cold supply lines are open.

8. Specifications

Brand	Moen
Model Number	84506
Finish Type	Chrome
Mounting Type	Deck Mount
Number of Handles	2
Hole Count	3
Maximum Flow Rate	1.5 Gallons Per Minute
Material	Metal (Handle Material: Chrome)
Special Features	Water Saving, Rust Resistant
Product Dimensions	10 x 10 x 10 inches
Item Weight	1 pound
UPC	026508304440

9. Warranty and Support

Moen products are manufactured under the highest standards of quality and workmanship. For warranty information, product registration, or technical assistance, please visit the official Moen website or contact Moen customer service directly. Please have your model number (84506) available when contacting support.

© 2023 Moen Incorporated. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question