Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Techwood TWBG-01

Techwood 15-Serving Indoor/Outdoor Electric Grill (Model TWBG-01) Instruction Manual

Your comprehensive guide to safe and efficient grilling.

1. Introduction

Thank you for choosing the Techwood 15-Serving Indoor/Outdoor Electric Grill. This manual provides essential information for the safe assembly, operation, and maintenance of your new electric grill. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: Fully assembled Techwood Electric Grill, showcasing its double-layer design with various foods cooking on both racks.

2. Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before operating the grill.
- Do not immerse the electrical cord, plug, or temperature control unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors if the electrical components are exposed to rain or moisture. This grill is designed for both indoor and outdoor use, but electrical parts must remain dry.
- Always ensure the grill is placed on a stable, level surface.
- Do not leave the grill unattended during operation.

3. Product Overview and Components

The Techwood Electric Grill features a robust design for versatile grilling. Key components include:

- **Grill Cover:** Helps retain heat and moisture for even cooking. Features an adjustable vent.
- **Main Grilling Surface:** 240 square inches of circular grilling area.
- **Foldable Warming Rack:** Provides extra space to keep food warm without overcooking.
- **Heating Element:** 1600W for fast and efficient heating.
- **Temperature Regulator:** Adjustable dial for precise heat control up to 425°F.
- **Removable Grease Pan:** Collects excess fat and oil for healthier cooking and easy cleanup.
- **Portable Stand:** Allows for both stand-up and countertop use.



Figure 2: Detailed view of the precision heat control and the removable grease pan for convenient cleaning.



Figure 3: The double-layer design provides ample cooking space, including a warming rack for finished items.

4. Setup and Assembly

The Techwood Electric Grill is designed for straightforward assembly. All necessary screws are pre-positioned on the parts, requiring only unscrewing, attaching the corresponding piece, and re-tightening.

1. Unpack all components and ensure all parts are present.
2. Assemble the stand by attaching the main column to the base, then securing the grill unit to the top of the column.
3. Install the heating element into the grill base.
4. Place the main grilling grate over the heating element.
5. Attach the foldable warming rack to the grill cover.
6. Insert the removable grease pan into its designated slot beneath the heating element.
7. Attach the temperature control unit to the side of the grill.

For a visual guide on assembly, please refer to the video below:

Your browser does not support the video tag.

Video 1: This official seller video demonstrates the assembly process of the Techwood 15-Serving Indoor/Outdoor Electric Grill, showing how to connect the stand, heating element, and grilling surfaces.

5. Operating Instructions

Your Techwood Electric Grill is ready for use both indoors and outdoors, provided a standard 110V power outlet is accessible.

1. **Placement:** Position the grill on a stable, heat-resistant surface. Ensure adequate ventilation, especially when using indoors.
2. **Power Connection:** Plug the temperature control unit into a standard 110V outlet.
3. **Preheating:** Turn the temperature regulator to your desired setting. The 1600W heating element ensures rapid preheating. For best results, allow the grill to preheat for 5-10 minutes with the lid closed. The grill cover helps maintain a rapid heating cycle for even cooking.
4. **Cooking:** Place food directly on the main grilling surface. Use the foldable warming rack for items that need to stay warm or to finish cooking gently. The 240 square inches of grilling surface can accommodate up to 15 servings.
5. **Temperature Adjustment:** Adjust the temperature regulator as needed during cooking. The precise control allows for various cooking requirements.
6. **Vent Control:** The grill cover features an adjustable vent. Open the vent to release smoke and moisture, or close it to retain heat and achieve a more roasted effect.
7. **Completion:** Once cooking is complete, turn the temperature regulator to the 'OFF' position and unplug the unit from the outlet. Allow the grill to cool completely before cleaning.



Figure 4: Illustration of the grill's design promoting even heat distribution across the cooking surface for consistent results.

Watch this official seller video for a demonstration of the grill's features and operation:

Your browser does not support the video tag.

Video 2: This official seller video showcases the Techwood 1600W Electric Outdoor Stand Grill, highlighting its features and suitability for various grilling occasions.

6. Maintenance and Cleaning

Regular cleaning will extend the life of your grill and ensure optimal performance.

1. **Cool Down:** Always allow the grill to cool completely before attempting any cleaning.
2. **Remove Grease Pan:** The removable grease pan should be emptied and cleaned after each use. It is recommended to place aluminum foil under the heat source to catch grease and oil for easier disposal.
3. **Clean Grates and Racks:** Both the main grilling grate and the warming rack can be disassembled for easy cleaning. Wash them with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
4. **Clean Heating Element:** The heating element should be wiped clean with a damp cloth. Do not immerse the heating element or temperature control unit in water.

5. **Exterior Cleaning:** Wipe the exterior surfaces of the grill and cover with a damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
6. **Storage:** Store the clean and dry grill in a cool, dry place.

7. Troubleshooting

If you encounter issues with your Techwood Electric Grill, please consult the following common troubleshooting steps:

- **Grill not heating:** Ensure the temperature control unit is securely plugged into both the grill and a functioning power outlet. Check if the outlet is receiving power. Verify the temperature dial is set to an 'ON' position.
- **Uneven heating:** Ensure the grill is preheated sufficiently with the lid closed. Check that the heating element is properly seated.
- **Excessive smoke:** Ensure the grease pan is clean and properly installed. Trim excess fat from meats before grilling. Adjust the lid vent to allow some smoke to escape.
- **Food sticking:** Ensure the grill grates are clean and lightly oiled before placing food.

If problems persist after attempting these steps, please contact customer support.

8. Specifications

Feature	Specification
Brand	Techwood
Model Name	TWBG-01
Product Dimensions	16.9"D x 19.6"W x 31.8"H
Heating Power	1600 Watts (1.6 Kilowatts)
Voltage	120 Volts
Cooking Surface Area	240 Square Inches
Number of Racks	2 (Main + Warming)
Material	Metal
Item Weight	16.6 Pounds
UPC	735279781120, 735279781779

9. Warranty and Support

Techwood offers an 18-month warranty for this product, covering manufacturing defects under normal use. Additionally, a 30-day hassle-free return policy is provided. For warranty claims, technical support, or any inquiries, please refer to the contact information provided in your product packaging or visit the official Techwood website.

© 2025 Techwood. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Z7Z5CP7

More documents and user manuals: **https://manuals.plus/**