Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Olizen AA59-00741A

Olizen AA59-00741A Universal Replacement Remote Control for Samsung Smart TV

Instruction Manual

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Olizen AA59-00741A Universal Replacement Remote Control. Designed for seamless compatibility with a wide range of Samsung Smart TVs, this remote offers a direct replacement experience without the need for complex programming.
Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.

1. Setup

1.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover off.
3. Insert two (2) AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside.
4. Slide the battery cover back into place until it clicks securely.







Figure 1: Back view of the remote control with the battery compartment.

1.2 Initial Use

The Olizen AA59-00741A remote control is designed for immediate use with compatible Samsung Smart TVs. No programming or pairing is required. Simply install the batteries, point the remote towards your TV, and begin operation.

2. Operating the Remote Control

This remote control provides full functionality for your Samsung Smart TV. Below is an overview of the main buttons and their general functions.





Figure 2: Front view of the remote control with button layout.

2.1 Button Functions Overview

- **Power ( )**: Turns the TV on or off.
- **Source**: Selects input sources (HDMI, AV, etc.).
- **Number Buttons (0-9)**: Direct channel selection.
- **Volume (+/-)**: Adjusts the volume level.
- **Mute**: Mutes or unmutes the TV sound.
- **Channel (CH List, Up/Down)**: Changes channels or accesses the channel list.
- **Menu**: Opens the TV's main menu.
- **Guide**: Displays the electronic program guide.
- **Tools**: Accesses quick settings or tools menu.
- **Info**: Displays information about the current program.
- **Directional Pad (Up, Down, Left, Right) & Enter**: Navigates menus and confirms selections.
- **Return**: Goes back to the previous screen or menu.
- **Exit**: Exits the current menu or application.
- **Color Buttons (A, B, C, D)**: Functions vary depending on the TV menu or application.
- **Media Playback Controls (Play, Pause, Stop, Fast Forward, Rewind)**: Controls media playback.
- **E-Manual**: Accesses the TV's electronic manual.
- **P.SIZE (Picture Size)**: Adjusts the picture aspect ratio.
- **AD/SUBT (Audio Description/Subtitles)**: Toggles audio description or subtitles.

2.2 Compatibility

This remote control is compatible with a wide range of Samsung Smart TV models. If your specific TV model is not listed, the remote is generally compatible if its appearance matches your original remote control.
Compatible Remote Control Models include: BN59-01175B, AA59-00818A, AA59-00603A, BN59-01199G, AA59-00622A, AA59-00496A, AA59-01180A, BN59-01268D, AA59-00666A, AA59-01289A, AA59-00600A, AA59-00823A.
Compatible Samsung TV Models include: PN43E440A2F, PN51E440A2F, PN43E450A1F, PN51E450A1F, PN60E530A3F, T28D310NH, PN51E535A3F, PN60E535A3F, T24B350ND, T22B350ND, T27B350ND, UN22F5000AF, UN19F4000AF, UN26EH4000F, UN32EH4000F, UN29F4000AF, UN32EH4050F, UN32F5000AF, UN32EH5000F, UN32F5050AF, UN37EH5000F, UN39FH5000F, UN40EH5050F, UN40EH5000F, UN40EH6000F, UN40F5000AF, UN40EH6050F, UN46EH5000F, UN46EH6000F.



Figure 3: Using the remote control with a Samsung Smart TV.

3. Maintenance

3.1 Cleaning

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.
- Ensure no liquid enters the remote control, especially around buttons and the battery compartment.

3.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

3.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

4. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote has limited range or intermittent response.	Weak batteries; Obstruction between remote and TV; Remote sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight between the remote and the TV's IR sensor. Remove any obstructions.
Specific buttons not working.	Button stuck or damaged; Remote not compatible with a specific TV function.	Gently press the button to ensure it's not stuck. If the issue persists, the button may be damaged. Verify compatibility for advanced functions.
TV does not respond to any remote commands.	TV is off or unplugged; TV's IR sensor is faulty.	Ensure the TV is powered on. Try using the TV's physical buttons. If the TV still doesn't respond, there might be an issue with the TV itself.

5. Specifications

Model Number	AA59-00741A
Brand	Olizen
Connectivity Technology	Infrared (IR)
Maximum Range	Approximately 10 meters
Number of Buttons	40
Compatible Devices	Samsung Smart TVs
Battery Type	2 x AAA (not included)
Dimensions (L x W x H)	23 cm x 4.7 cm x 2.4 cm
Material	FR-ABS
UPC	746198926127



Figure 4: The remote control features an enhanced chip for stable performance and faster response.

6. Warranty and Support

6.1 Warranty Information

This Olizen remote control comes with a **365-day warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

6.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Olizen customer support through the retailer's platform or the official Olizen website. Provide your product model number (AA59-00741A) and a detailed description of the issue for efficient service.

© 2023 Olizen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Z84CWYH

More documents and user manuals: **https://manuals.plus/**