Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kinhank SConXPro

Kinhank Super Console X Pro Instruction Manual

Model: SConXPro | Brand: Kinhank

1. Introduction

The Kinhank Super Console X Pro is a versatile retro gaming console designed to bring classic gaming experiences to your 4K TV. Equipped with an upgraded S905X chip, it supports a wide range of emulators and offers dual system functionality (Emuelec for gaming and Android for media). This manual provides essential information for setting up, operating, and maintaining your console.

2. What's Included

Please verify that all items are present in your package:

- Kinhank Super Console X Pro Unit
- 2 x 2.4GHz Wireless Controllers
- Power Adapter
- HDMI Cable
- USB Hub
- Remote Control
- TF Card (pre-installed with games)



Figure 2.1: Super Console X Pro unit, two wireless controllers, remote, and 128GB TF card.

3. Setup Guide

Follow these steps to set up your Super Console X Pro:

1. **Connect to TV:** Connect the console to your TV using the provided HDMI cable. Insert one end into the HDMI port on the console and the other end into an available HDMI input on your TV.
2. **Connect Power:** Plug the power adapter into the DC IN port on the console and then into a wall outlet.
3. **Connect Controllers:** Insert the USB receiver for the wireless controllers into one of the USB ports on the console. Ensure the controllers have batteries installed.
4. **Power On:** Press the power button on the console or use the remote control to turn on the device.
5. **Select Input:** Switch your TV's input source to the corresponding HDMI port where the console is connected.



Figure 3.1: Console connected to TV for HD output.



Figure 3.2: Detailed view of console ports and dimensions.

4. Operating Instructions

4.1 System Modes (Emuelec & Android)

The Super Console X Pro features a dual-boot system, allowing you to switch between Emuelec (for gaming) and Android (for media and apps).

- **Emuelec:** This is the primary gaming system, pre-loaded with over 55,000 classic games. It supports various emulators for a wide range of retro consoles.
- **Android 7.1:** This mode allows you to watch TV online, install applications, and use the console as a smart TV box.



Figure 4.1: Dual system interface for gaming and media.

4.2 Navigating and Playing Games

Once in Emuelec mode, use the wireless controllers to navigate the game selection menu. Games are organized by console emulator.

- Use the directional pad or analog sticks to browse through the available systems and games.
- Press the 'A' button (or equivalent) to select a game and start playing.
- To exit a game or return to the main menu, consult the specific emulator's hotkey combination (often SELECT + START simultaneously).
- The console supports TF card expansion for adding more games.



Figure 4.2: Console displaying a game from its extensive built-in library.

4.3 Multiplayer Gaming

The Super Console X Pro supports up to 5 players, allowing for shared gaming experiences with friends and family. The included 2.4GHz wireless controllers provide comfortable gameplay from your sofa.



Figure 4.3: Enjoying multiplayer games with the console.

4.4 Online Media and Connectivity

Utilize the Android system for online entertainment:

- Connect to your home network via Wi-Fi or Ethernet cable.
- Use the remote control to navigate the Android interface.
- Access pre-installed media apps or download new ones from the app store.



Figure 4.4: The console can be used for watching TV and online content.

5. Troubleshooting

If you encounter issues, please refer to the following common solutions:

Problem	Possible Solution
Console does not power on.	Ensure the power adapter is securely connected to the console and a working power outlet. Try a different outlet.
No display on TV.	Verify the HDMI cable is properly connected to both the console and the TV. Ensure your TV is set to the correct HDMI input source. Try a different HDMI cable or TV port.
Controllers are not responding.	Check if the USB receiver is firmly plugged into the console. Ensure the controllers have fresh batteries. Re-pair the controllers if necessary (refer to controller specific instructions).

Problem	Possible Solution
Some games are not working.	As noted, some games may not work. Try changing the emulator for that specific game within the Emuelec settings. Ensure the TF card is properly inserted.
System lag or poor performance.	Ensure the console has adequate ventilation. Close any unnecessary applications if in Android mode. For gaming, some emulators or games may be more demanding than others.

6. Specifications

- **Brand:** Kinhank
- **Model:** SConXPro
- **Platform:** Android (Dual System with Emuelec)
- **Controller Type:** Button Control (2.4GHz Wireless)
- **Hardware Interface:** HDMI, USB, Ethernet, AV
- **Display Type:** Digital
- **Memory Storage Capacity:** 128GB (TF Card)
- **Output:** 4K TV HD/AV (1080P/720P)
- **Connectivity:** Wi-Fi, LAN
- **Supported Languages:** 26+
- **Item Weight:** 1.72 pounds (approx. 0.78 kg)
- **Package Dimensions:** 8.5 x 6.81 x 4.45 inches
- **UPC:** 728047891718

7. Maintenance

To ensure the longevity and optimal performance of your console:

- Keep the console in a dry, well-ventilated area away from direct sunlight and heat sources.
- Avoid spilling liquids on the device.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Handle the TF card with care to prevent data corruption.

8. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Kinhank website. Keep your proof of purchase for warranty claims.

© 2025 Kinhank. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZHWD88X

More documents and user manuals: **https://manuals.plus/**