Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC2143619/01

ALLIMITY RC2143619/01 Replacement Remote Control for Philips TVs User Manual

Introduction

Welcome to the user manual for your new ALLIMITY RC2143619/01 Replacement Remote Control. This remote is designed to provide seamless control for a range of Philips TV models without requiring any complex setup. Please read this manual carefully to understand the features and proper operation of your remote control.

Product Overview

This section provides a visual guide to your remote control, highlighting its design and key components.





Front view of the ALLIMITY RC2143619/01 replacement remote control, showcasing all buttons and their layout. The remote is black with clearly labeled white and grey buttons.



An angled view of the ALLIMITY RC2143619/01 remote control, highlighting the ergonomic design and button placement from a different perspective.

Setup

The ALLIMITY RC2143619/01 remote control is designed for immediate use with compatible Philips TV models. No programming or pairing is required.

1. Installing Batteries

To begin using your remote control, follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open it.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the indicators inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Once batteries are installed, the remote is ready for operation.

Operating Instructions

This section details the primary functions of the remote control buttons.

- **Power Button (●):** Turns the TV on or off.
- **Source Button:** Selects input sources (e.g., HDMI 1, AV, Component).
- **Number Buttons (0-9):** Directly selects TV channels.
- **Volume Up/Down (VOL +/-):** Adjusts the audio volume.
- **Channel Up/Down (P +/-):** Changes TV channels sequentially.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Menu Button:** Accesses the TV's main menu.
- **Back Button:** Returns to the previous menu or screen.
- **CC (Closed Captioning):** Toggles closed captions on or off.
- **Audio:** Selects audio tracks or modes.
- **Info:** Displays program information.
- **Guide:** Accesses the electronic program guide (EPG).
- **Format:** Adjusts screen aspect ratio or picture format.
- **Option:** Accesses context-sensitive options.
- **Playback Controls (Play/Pause, Fast Forward, Rewind, Stop):** Controls media playback on compatible devices or TV functions.
- **PREV CH (Previous Channel):** Switches to the last viewed channel.

Compatible TV Models

The ALLIMITY RC2143619/01 remote control is compatible with the following Philips TV models:

- 32HFL3330D/27
- 42PFL5403/77
- 32PFL3403D/F7
- 32PFL3403D27
- 47PFL7403/77
- 40PFL7505D
- 42PFL5203

Troubleshooting

If you encounter issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure the remote is pointed directly at the TV.
- **Limited functionality:**
  - Verify that your TV model is listed in the compatible models section.
  - Some advanced TV functions may require the original remote or specific TV settings.

Specifications

Product Specifications

Feature	Detail
Model Number	RC2143619/01
Brand	ALLIMITY
Compatible Devices	Philips Televisions
Connectivity Technology	Infrared (IR)
Special Feature	No Programming Required
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7 x 2 x 0.6 inches
Item Weight	2.08 ounces

Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's official website. Keep your purchase receipt for warranty claims. As this is a replacement remote, specific warranty details may vary by seller.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZMMCPZV

More documents and user manuals: **https://manuals.plus/**