Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 721353810138

JustFine Replacement Remote Control for LG Smart TVs

This manual provides instructions for the setup, operation, and maintenance of your JustFine replacement remote control.

Setup Guide

Inserting Batteries

Your remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image Description: A view of the back of the JustFine replacement remote control with the battery compartment open, showing two AAA batteries correctly inserted. The battery cover is shown detached next to the remote.

Initial Use

This replacement remote control is pre-programmed and does not require additional programming for compatible LG Smart TVs. Simply insert the batteries, and it should be ready for use.

Operating Instructions

Basic Remote Functions

The remote control provides standard functions for navigating your LG Smart TV:

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the TV's volume level.
- **Channel Up/Down:** Changes TV channels.
- **Number Pad (0-9):** Direct channel input.
- **Input/Source:** Selects different input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **Back/Exit:** Returns to the previous screen or exits a menu.
- **Smart TV/Home Button:** Accesses the Smart TV home screen or app launcher.

Compatibility

This remote control is compatible with the following LG Smart TV models:

- LG 43UM6910PUA
- LG 49UM7300PUA
- LG 50UM7400PUA
- LG 50UM7300AUE
- LG 55UM7400PUA
- LG 55UM7100PUA
- LG 55UM7200PUA
- LG 60UM7200PUA
- LG 65UM7400PUA

Maintenance and Care

To ensure the longevity and optimal performance of your remote control, follow these guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of the remote control with household waste.

Troubleshooting

If you encounter issues with your remote control, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries. Obstruction between remote and TV.	Replace batteries with new AAA batteries, ensuring correct polarity. Remove any objects blocking the signal path to the TV's IR receiver.
Some buttons not working	Dirty contacts or button malfunction.	Clean the remote surface. If the issue persists, contact customer support.
Short operating range	Weak batteries. Interference.	Replace batteries. Ensure no strong light sources or electronic devices are interfering with the IR signal.

Product Specifications

Brand: JustFine

Model Number: 721353810138

Connectivity Technology: Infrared

Compatible Devices: Television (LG Smart TVs)

Battery Type: 2 x AAA (not included)

Maximum Range: 10 Meters

Button Quantity: 20

Color: Black

Special Feature: Ergonomic design

Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty.

For any problems or inquiries, please contact customer support via email. Refer to your purchase documentation for specific contact details.

Hassle-free returns are available within the specified return period.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZVS8Y8S

More documents and user manuals: **https://manuals.plus/**